

A man in a light blue shirt is shown from the side, holding a tablet computer. He is looking at the screen, which displays a software interface with various charts and data. The background is a blurred industrial factory setting with machinery and equipment.

SIEMENS

Application description • 01/2014

Speed control of a SINAMICS G120/S120 with S7-300/400 (STEP 7 V5) via PROFINET RT

SINAMICS G/S

<http://support.automation.siemens.com/WW/view/en/38844967>

Warranty and liability

Note

The Application Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly. These application examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time without prior notice. If there are any deviations between the recommendations provided in these application examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document.

Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Application Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act (“Produkthaftungsgesetz”), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract (“wesentliche Vertragspflichten”). The damages for a breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of Siemens Industry Sector.

Caution

The functions and solutions described in this article confine themselves to the realization of the automation task predominantly. Please take into account furthermore that corresponding protective measures have to be taken up in the context of Industrial Security when connecting your equipment to other parts of the plant, the enterprise network or the Internet. Further information can be found under the Item-ID 50203404.

<http://support.automation.siemens.com/WW/view/en/50203404>

Table of contents

| | | |
|----------|--|-----------|
| | Warranty and liability | 2 |
| 1 | Task..... | 4 |
| | 1.1 Overview | 4 |
| 2 | Solution..... | 5 |
| | 2.1 Overview | 5 |
| | 2.2 Hardware and software components..... | 7 |
| | 2.2.1 Validity | 7 |
| | 2.2.2 Components used | 7 |
| | 2.3 Alternative solution | 8 |
| 3 | Basics | 9 |
| | 3.1 PROFINET communication..... | 9 |
| | 3.1.1 Device name | 9 |
| | 3.1.2 Assign device name via HW Config | 9 |
| | 3.1.3 SINAMICS: Assign device name via parameters..... | 11 |
| | 3.1.4 Topology-based initialization..... | 12 |
| | 3.1.5 Device name assignment rules | 13 |
| | 3.1.6 IP address | 14 |
| 4 | Configuration and programming | 17 |
| | 4.1 HW Config of the SIMATIC CPU..... | 17 |
| | 4.2 HW Config of the SINAMICS drive..... | 20 |
| | 4.3 Download of the HW Config..... | 24 |
| | 4.4 Configuration of the SINAMICS drive | 26 |
| | 4.5 Activation of the servo motor..... | 33 |
| 5 | Commissioning the sample project..... | 36 |
| | 5.1 Overview..... | 36 |
| | 5.2 Commissioning..... | 36 |
| 6 | Operating the sample project | 38 |
| | 6.1 Overview | 38 |
| | 6.2 Operation | 38 |
| 7 | References..... | 40 |
| 8 | Contact..... | 40 |
| 9 | History | 40 |

1 Task

1.1 Overview

Description of the automation task

A drive shall be moved speed-controlled.

For this purpose the drive is operated as IO device connected to an IO controller. In this case, no special control-related tasks are required. This is the reason that a communication via PROFINET RT is configured between controller and drive.


2 Solution

2.1 Overview

Schema

The following figure displays the most important components of the solution:

Fig. 2-1



This application description shows how a SINAMICS drive can be moved speed-controlled using a SIMATIC S7-300/400 (STEP 7 V5). A communication via PROFINET RT is configured between controller and drive.

The SIMATIC CPU sets the required releases so that the servo motor of the SINAMICS drive can be moved speed-controlled. To achieve this, control word ("STW1") and speed setpoint ("NSOLL_B") are sent from the CPU to the drive in OB1. The drive sends its status word ("ZSW1") and actual speed value ("NIST_B") back to the controller. Any upcoming drive faults are acknowledged by the SIMATIC controller via application.

Advantages

The solution described here offers you the following advantages:

- Simple control of the SINAMICS drive.
- Simple design using standard technology.
- The existing system can be expanded quick and simple.

Delimitation

This application does not include a description of:

- the general drive functions of the SINAMICS G120/S120
- the SIMATIC S7-300/400

It is assumed to have basic knowledge of these topics.

Knowledge required

Basic knowledge about configuring SIMATIC control systems with the STEP7 engineering system and configuring SINAMICS drives with STARTER or SIMOTION SCOUT is assumed.

2.2 Hardware and software components

2.2.1 Validity

This application is valid for

- STEP 7 as from V5.x
- STARTER as from V4.x
- SIMOTION SCOUT as from V4.x
- S7-300 as from V3.x
- S7-400 as from V6.x
- SINAMICS S120/G120 as from V4.x

2.2.2 Components used

The application was created with the following components:

Hardware components

Table 2-1

| Component | Qty. | Order number | Note |
|----------------------------|------|--------------------|-----------|
| SIMATIC S7 CPU 319-3 PN/DP | 1 | 6ES7318-3EL01-0AB0 | V3.2.10 |
| SINAMICS S120 CU310-2 PN | 1 | 6SL3040-1LA01-0AA0 | V4.6 HF10 |
| SINAMICS training case | 1 | 6ZB2480-0AD00 | --- |

NOTE

The sample project was created with the hardware components listed here. Alternatively, other components with the same function may be used. A different parameter assignment and different wiring of the components may be required.

When configuring **PROFINET RT-based communication** between an S7-CPU and a CU320-2 PN – or a SINAMICS G120 V4.x with PROFINET interface – then proceed as described for this particular application. A CU310-2 PN is used in the application description and in the sample project.

Software components

Table 2-2

| Component | Qty. | Order number | Note |
|--|------|--------------------|--|
| STEP 7 | 1 | 6ES7810-4CC10-0YA5 | V5.5 SP3 HF2 |
| STARTER | 1 | --- | V4.3 SP3 HF1 (Download) |
| SIMOTION SCOUT (as an alternative to STARTER) | 1 | 6AU1810-1CA43-1XA0 | V4.3 SP1 HF17 |

2 Solution

2.3 Alternative solution

Sample files and projects

The list below contains all the files and projects used in this example.

Table 2-3

| Component | Note |
|---|---|
| 38844967_SIMATIC_SINAMICS_PN_RT_V2_0.zip | This zipped file contains the STEP 7 project. |
| 38844967_SIMATIC_SINAMICS_PN_RT_V2_0_en.pdf | This document |

2.3 Alternative solution

Drive connection via PROFINET IRT

If the control system (e.g. a SIMOTION control system) is to handle control-related tasks, then it is no longer sufficient to use PROFINET RT to connect the drive.

The drive must then be connected using PROFINET IRT (isochronous).

Note

Further information concerning the drive connection via PROFINET IRT can be obtained in the following article.

<http://support.automation.siemens.com/WW/view/en/53477498>

3 Basics

3.1 PROFINET communication

In addition to the MAC address and IP address, PROFINET uses additionally a device name to identify the PROFINET devices. This device name must be unique within the PROFINET network.

3.1.1 Device name

During the commissioning phase a device name is assigned to each PROFINET device by the engineering system (HW Config, NetPro, STARTER, SCOUT, Primary Setup Tool). The device name can be assigned by different ways:

- IO-Controller
 - Engineering Software (HW Config, NetPro, STARTER, SCOUT, Primary Setup Tool)
 - By downloading the HW Config
 - By user program (system function `_setNameOfStation()` for SIMOTION)
- IO-Device
 - Engineering Software (HW Config, NetPro, STARTER, SCOUT, Primary Setup Tool)
 - From IO-Controller via topology-based initialization

The device name will be stored in the device (on MMC or CF card). When replacing this device (e.g. in case of malfunction), this device must be initiated using the device name of the replaced device. For this step more possibilities are available:

- By plugging the MMC or CF card (if available)
- Engineering software (HW Config, NetPro, STARTER, SCOUT, Primary Setup Tool)
- Topology-based initialization by the IO-Controller itself. For this the PROFINET interface must be in factory settings.

It means the new device can assume the function of the replaced device without changing the configuration.

3.1.2 Assign device name via HW Config

Open HW Config and select the PROFINET IO-System. Click in menu under „PLC > Ethernet“ onto “Assign Device Name...“. The dialog assign device name will appear. All configured device names are in dropdown box listed. All recognized PROFINET devices via Network interface are shown under available devices. IO-Controllers are not shown here, because they will get the device name by downloading the HW Config explicit.

Figure 3-1





Figure 3-2



Select the configured device name (A) and select the corresponding device (B) and click on “Assign name” (C). The device name will be transferred to the device.

If the device identification is not clear you can activate the flashing of a specified LED. Select the device and click on “Flashing on” to activate the function. Depending on the device type following LED will start flashing:

Table 3-1

| Device | LED |
|---------------|-----------|
| SIMATIC | LINK-LEDs |
| SIMOTION | SF-LED |
| SINAMICS S120 | RDY-LED |
| SINAMICS G120 | RDY-LED |

3.1.3 SINAMICS: Assign device name via parameters

The device name of a SINAMICS drive can also be specified offline via parameters in the expert list of the CU. By using the STARTER / SCOUT functionality "Load to file system" afterwards the configuration can be transferred directly to the CF card via card reader or to the drive via download of the offline configuration. The device name will be activated in the drive and stored non-volatile after the next run-up (Power OFF/ON required!).

NOTE

Beside the device name, also the IP address and the subnet mask of the drive have to be specified correctly in the expert list of the CU, because these will also be activated in the drive and stored non-volatile after the next run-up.


For the assignment of the device name, the IP address and the subnet mask, proceed as follows:

1. Open the expert list of the CU in the STARTER / SCOUT project.
2. Depending on which PROFINET interface of the drive you are using (onboard PROFINET interface or CBE20), proceed as follows:
 - **Settings for the onboard PROFINET interface**
 - Enter the drives' device name from HW Config into parameter p8920.
 - Enter the drives' IP address from HW Config into parameter p8921.
 - Enter the drives' subnet mask from HW Config into parameter p8923.
 - Set parameter p8925 to the value "[2] Save and activate configuration".
 - **Settings for the CBE20**
 - Enter the drives' device name from HW Config into parameter p8940.
 - Enter the drives' IP address from HW Config into parameter p8941.
 - Enter the drives' subnet mask from HW Config into parameter p8943.
 - Set parameter p8945 to the value "[2] Save and activate configuration".
3. Save the changes carried out in the project. Afterwards mark the drive in the project tree and open its context menu via right clicking. Choose the option "Load to file system".
4. Choose the option "Save normally" as type of saving and click on the button "Select target...". Choose the path of the card reader and start the transmission of the configuration via the button "OK".
5. After the successful transmission of the configuration and subsequent run-up of the drive the device name, the IP address as well as the subnet mask is taken over from the parameters and stored non-volatile.

3.1.4 Topology-based initialization

The device name can be assigned by the PROFINET IO-Controller itself. With the checkbox “Support device replacement without exchangeable medium” the PROFINET feature topology-based initialization is activated. This feature is activated by default.


Figure 3-3



This properties window will open by double clicking on the PN interface of the IO-Controller in HW Config.

Please observe that **the PN interface of IO-Device must be in factory settings** to support this function (in this state the interface has the IP address = 0.0.0.0 and an empty device name = „“). To reset the PROFINET interface to factory settings open HW Config and click on „PLC > Ethernet > Edit Ethernet Node > Reset“ (see following figure).

Figure 3-4



3.1.5 Device name assignment rules

The device name has to follow the rules of DNS (Domain Name System). Following possibilities for DNS names are given:


- Letters (a..z),
- Numbers (0..9) and the signs
- Minus (-) and
- Dot (.) are allowed.

The dot divides the device name into labels. The device name can include more labels, for example:

<CPU name>.<Interface number >.<Name of IO-System>...

- *<Interface number>*, if the device has more than one PN interfaces available (e.g. "X150")
- *<Name of IO-System>*, optional and configured by HW Config (see Figure 3-5).
- Each label must start with a letter and doesn't end with minus or a dot.
- The maximum length of one label is 63 characters.

Figure 3-5



3.1 PROFINET communication

Observe also following additional rules:

- The maximum total length is 127 characters (incl. minus and dot)
- The device name may only include lower case. On the device upper case are replaced through lower case.
- Do not use umlauts (ä, ö, ü)
- Do not use special characters ! " § \$ % & / () = ? * ' _ : ; > < , # + | ~ \ }] [{
- Do not use blanks
- The device name does not start with "port-xyz" (x, y, z = 0..9).
- **Do not use the minus sign on SIMOTION controllers. Up from SIMOTION SCOUT Version 4.3 this limitation is raised.**

3.1.6 IP address

PROFINET uses IP addresses for establishing the PROFINET IO communication and for NRT (Non Real Time Communication e. g. TCP, UDP, S7 communication).

The IP address is also needed to go online to the device. It is recommended to assign an IP address to each PROFINET IO-Device during startup of a project commissions. To do this you have more possibilities:


- IO-Controller
 - Engineering software (HW Config, NetPro, STARTER, SCOUT, Primary Setup Tool)
 - Download of HW Config, please observe the current active IP address of the device!
- IO-Device
 - Engineering software (HW Config, NetPro, STARTER, SCOUT, Primary Setup Tool)

In a PROFINET IO-System it is possible to receive the IP address from the IO-Controller. This feature is activated by default.

For this a correct working PROFINET connection between IO-Controller and IO-Device is required and the active device name must be the same as in the HW Config. Figure 3-6 shows the configuration of a SINAMICS S120. The device with device name "SINAMICS" will get the IP address 192.168.0.3 and the same subnet mask as the IO-Controller.

If the device doesn't receive the IP information from IO-Controller it is maybe not possible to go online with the engineering software (e. g. Starter or SCOUT). In this case assign a fixed IP to the device.

Figure 3-6



The received IP address from IO-Controller is just a temporary address (till next power OFF/ON of the device). The received address is higher prior as a fixed set IP address via engineering software.

After power ON the IP address must be received from IO-Controller first. If the address will not receive, the IP address set by the engineering system or the default IP address 0.0.0.0 (default setting of the PN interface) will be active. An IP address assigned by any engineering software is permanently saved.


If you disable the function „Assign IP address via IO-Controller” the fixed IP address will be used. The IO-Controller will not assign the configured IP address.

The IP address in the device must be unique. Please observe that the IP addresses used by PN interfaces (e.g. X150) and the IP addresses of the standard Ethernet interfaces (e.g. X127) must be in different IP subnets. For example: If you assign an IP address 169.254.11.23 to the PN interface X150 so the device will report an error if the standard Ethernet interface X127 is still assigned to 169.254.11.22 (default IP address of X127).

3 Basics

3.1 PROFINET communication

Figure 3-7





4 Configuration and programming

4.1 HW Config of the SIMATIC CPU



In the sample project, a SIMATIC CPU 319-3 PN/DP V3.2 is used to enter the speed setpoint for the drive. This CPU is configured as follows.

Table 4-1

| No. | Action |
|-----|---|
| 1. | <p>Open the STEP 7 SIMATIC Manager engineering system to create a new project. Add a new SIMATIC 300 Station</p>  <p>Inserts a new station in the current project.</p> |
| 2. | <p>Open HW Config of the SIMATIC CPU.</p>  <p>Press F1 to get Help.</p> |

4 Configuration and programming


4.1 HW Config of the SIMATIC CPU


| No. | Action | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------|--|---------------------|----------|--------------|-----------|-------------|-----------|------|------|---|--|--|--|--|--|--|--|---|-----------------|---------------------|------|---|--|--|--|----|--------|--|--|--|-------|--|--|----|----|--|--|--|-------|--|--|----|-------|--|--|--|-------|--|--|-----|--------|--|--|--|-------|--|--|-----|--------|--|--|--|-------|--|--|---|--|--|--|--|--|--|--|---|--|--|--|--|--|--|--|---|--|--|--|--|--|--|--|
| 3. | <p>Insert a SIMATIC CPU 319-3 PN/DP V3.2 into HW Config.</p>  <table border="1" data-bbox="343 824 1029 1025"> <thead> <tr> <th>Slot</th> <th>Module</th> <th>Order number</th> <th>Firmware</th> <th>MPI address</th> <th>I address</th> <th>Q...</th> <th>C...</th> </tr> </thead> <tbody> <tr> <td>1</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td>CPU 319-3 PN/DP</td> <td>6ES7 318-3EL01-0AB0</td> <td>V3.2</td> <td>2</td> <td></td> <td></td> <td></td> </tr> <tr> <td>X1</td> <td>MPI/DP</td> <td></td> <td></td> <td></td> <td>8191"</td> <td></td> <td></td> </tr> <tr> <td>X2</td> <td>DP</td> <td></td> <td></td> <td></td> <td>8190"</td> <td></td> <td></td> </tr> <tr> <td>X3</td> <td>PN-IO</td> <td></td> <td></td> <td></td> <td>8189"</td> <td></td> <td></td> </tr> <tr> <td>X3A</td> <td>Port 1</td> <td></td> <td></td> <td></td> <td>8188"</td> <td></td> <td></td> </tr> <tr> <td>X3B</td> <td>Port 2</td> <td></td> <td></td> <td></td> <td>8187"</td> <td></td> <td></td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>5</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>Using "F4" automatically arranges the modules present in the HW Config.</p> | Slot | Module | Order number | Firmware | MPI address | I address | Q... | C... | 1 | | | | | | | | 2 | CPU 319-3 PN/DP | 6ES7 318-3EL01-0AB0 | V3.2 | 2 | | | | X1 | MPI/DP | | | | 8191" | | | X2 | DP | | | | 8190" | | | X3 | PN-IO | | | | 8189" | | | X3A | Port 1 | | | | 8188" | | | X3B | Port 2 | | | | 8187" | | | 3 | | | | | | | | 4 | | | | | | | | 5 | | | | | | | |
| Slot | Module | Order number | Firmware | MPI address | I address | Q... | C... | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | CPU 319-3 PN/DP | 6ES7 318-3EL01-0AB0 | V3.2 | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| X1 | MPI/DP | | | | 8191" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| X2 | DP | | | | 8190" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| X3 | PN-IO | | | | 8189" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| X3A | Port 1 | | | | 8188" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| X3B | Port 2 | | | | 8187" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4. | <p>Create a new Ethernet subnet using the "New" button, and assign an IP address and subnet mask (here: 192.168.0.1 / 255.255.255.0).</p>  | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

4 Configuration and programming

4.1 HW Config of the SIMATIC CPU

NOTE The PROFIBUS interface (X2) of the SIMATIC CPU must **not** be networked!
Close the properties window using the "OK" button.





| No. | Action |
|-----|--|
| 5. | <p>By double-clicking on the PROFINET interface (X3) of the SIMATIC CPU, its properties window opens. There, define the device name of the controller (here: "SIMATIC-319.X3").</p>  |

4.2 HW Config of the SINAMICS drive

The SINAMICS drive can either be configured with the OM (ObjectManager, Drive ES BASIC, hardware catalog) or using a GSD file. The drive is configured using the OM in the following.

Table 4-2


| No. | Action |
|-----|---|
| 1. | <p>Drag the CU310-2 PN V4.6 to the already available PROFINET network.</p>  |
| 2. | <p>Select the existing Ethernet subnet and assign a free IP address (here: 192.168.0.2).</p>  |

4 Configuration and programming

4.2 HW Config of the SINAMICS drive

NOTE

In the following dialog, confirm the type as well as the version of the SINAMICS drive using the "OK" button.



| No. | Action |
|-----|---|
| 3. | <p>Double-click the inserted SINAMICS drive to open its properties window. There, define the device name of the drive (here: "SINAMICS-CU310-2.X150").</p> <p>The screenshot shows a dialog box titled "Properties - SINAMICS-CU310-2.X150". It has tabs for "General", "Shared", and "Access", with "General" selected. Fields include: Short designation: S120xCU310x2xPN; Order no. / firmware: 6SL3 040-1LA01-0Axx (CU310-2 PN, S120) / V4.6; Family: SINAMICS; Device name: SINAMICS-CU310-2.X150 (highlighted with a red rectangle). Below is a "Node / PN-IO system" section with fields for Device number (1), IP address (192.168.0.2), and a checked box for "Assign IP address via IO controller".</p> |


4 Configuration and programming


4.2 HW Config of the SINAMICS drive

NOTE

For the steps described in the following, a functional connection is required between the engineering PC and the hardware being used!


In SIMATIC Manager, using the menu item "Options > Set PG/PC Interface..." open the window to set the PG/PC interface. There, for the access point "S7ONLINE", select the network card of your engineering PC that you are using with the supplement "TCPIP.1" (not "TCPIP.Auto.1").



| No. | Action |
|-----|---|
| 4. | <p>The device name configured in HW Config must then be assigned to the SINAMICS drive. To do this, in HW Config select the PROFINET network of the SIMATIC CPU and via "PLC > Ethernet > Assign Device Name..." open the window to assign the name.</p>  |

4 Configuration and programming





4.2 HW Config of the SINAMICS drive

| No. | Action | | | | | | | | |
|------------|---|-------------|-----------------------|-------------|-------------|-----|-------------------|----------|-----------------------|
| 5. | <p>Select the device name configured in HW config using the drop-down menu (1). Then select the SINAMICS drive from the list of available devices (2) and assign the device name using the "Assign name" (3) button.</p>  <p>The screenshot shows the 'Assign device name' dialog box. The 'Device name' dropdown menu is highlighted with a red box and labeled (1). The 'Available devices' table has its first row highlighted with a red box and labeled (2). The 'Assign name' button is highlighted with a red box and labeled (3).</p> <table border="1" data-bbox="339 600 938 860"><thead><tr><th>IP address</th><th>MAC address</th><th>Device type</th><th>Device name</th></tr></thead><tbody><tr><td>...</td><td>00-1F-F8-05-25-3D</td><td>SINAMICS</td><td>SINAMICS-CU310-2.X150</td></tr></tbody></table> | IP address | MAC address | Device type | Device name | ... | 00-1F-F8-05-25-3D | SINAMICS | SINAMICS-CU310-2.X150 |
| IP address | MAC address | Device type | Device name | | | | | | |
| ... | 00-1F-F8-05-25-3D | SINAMICS | SINAMICS-CU310-2.X150 | | | | | | |

Note



The IP address of the SINAMICS drive configured in HW Config is automatically assigned by the IO controller after HW Config has been downloaded (temporary IP address!).

4.3 Download of the HW Config

| No. | Action |
|-----|---|
| 1. | Save and compile the HW Config.  |
| 2. | Download it into the SIMATIC CPU.  |
| 3. | To do this, select the corresponding target device, and confirm your selection using the "OK" button.  |
| 4. | If the SIMATIC CPU is still in the factory setting (i.e. the IP address is 0.0.0.0), a download is only possible after assigning the IP address configured in HW Config. Browse through the network for controllers that can be accessed by pressing the "View" button.  |


4 Configuration and programming

4.3 Download of the HW Config

| No. | Action |
|-----|--|
| 5. | <p>All of the controllers that can be accessed are displayed. Select the corresponding controller by identifying it based on its MAC address and confirm your selection by pressing the "OK" button.</p>  <p>Note First reset the interface of the controller to the factory settings, if the SIMATIC CPU already has an IP address, which does not match the IP address configured in HW Config! ("PLC > Ethernet > Edit Ethernet Node > Browse > Select CPU > OK > Reset")</p> |
| 6. | <p>Confirm the following message with "Yes", to assign the IP address configured in HW Config to the controller (192.168.0.1) (permanent IP address!).</p>  |

4 Configuration and programming



4.4 Configuration of the SINAMICS drive

| No. | Action |
|-----|---|
| 7. | <p>Then switch the SIMATIC CPU back into the "RUN" operating state.</p>  |

4.4 Configuration of the SINAMICS drive



The standard configuration of the SINAMICS drive with the STARTER engineering system is shown below.

Table 4-3

| No. | Action |
|-----|---|
| 1. | <p>Open the current project in the STARTER engineering system from the SIMATIC Manager.</p>  |
| 2. | <p>Establish an online connection to the SINAMICS drive.</p>  <p>Note To establish an online connection, the network card of the engineering PC being used must be in the same IP subnet as the target device. Ensure that this precondition is complied with and if required adapt the IP configuration of your network card!</p> <p>Example</p> <ul style="list-style-type: none"> IP address of the target device 192.168.0.2 subnet mask 255.255.255.0 IP address of the engineering PC 192.168.0.99 subnet mask 255.255.255.0 |




4 Configuration and programming

4.4 Configuration of the SINAMICS drive

| No. | Action |
|-----|---|
| 3. | <p>Select the configured SINAMICS drive (set the checkmark in the checkbox) and confirm your selection by pressing the "OK" button.</p>  <p>The screenshot shows a dialog box titled "Target Device Selection". It contains a table with two columns: "Target device" and "Access point". The first row is highlighted with a red box and contains the text "SINAMICS-CU310-2.X150" under "Target device" and "S7ONLINE" (selected) and "DEVICE" (unselected) under "Access point". Below the table are buttons for "Select all", "Deselect all", "All S7ONLINE", and "All Device". At the bottom, the "OK" button is highlighted with a red box.</p> |
| 4. | <p>After this, restore the factory settings at the SINAMICS (if this has still not been done).</p>  <p>The screenshot shows the SIMATIC Manager interface. A context menu is open over the "SINAMICS-CU310-2.X150" device in the project tree. The "Restore factory settings" option is highlighted with a red box. The status bar at the bottom indicates "ASDX AX08178 USB2.0 to Gigabit Ethernet Online mode".</p> |



4 Configuration and programming

4.4 Configuration of the SINAMICS drive

| No. | Action |
|-----|---|
| 5. | <p>Confirm the following message with "Yes". The drive is then reset to the factory settings.</p>  <p>The screenshot shows a dialog box titled "Restore Factory Settings" with a yellow warning icon. The text reads: "Reset device configuration. Some parameters (e.g. bus address, baud rate, etc.) are not reset." There is a checked checkbox for "Save device parameterization to RDM after completion" and a question "Do you really want to restore the factory settings?". At the bottom are "Yes", "No", and "Help" buttons.</p> |
| 6. | <p>Afterwards carry out the automatic configuration of the drive.</p>  <p>The screenshot shows the SIMATIC Manager software interface. The left-hand project tree is expanded to show "Automatic Configuration" highlighted with a red rectangle. Below the tree, the "Device" window shows "SINAMICS-CU310-2: X150: Control_Unit" with the "Operating state" set to "Carry out first commissioning". The status bar at the bottom indicates "Online mode".</p> |
| 7. | <p>Start the configuration by pressing the "Configure" button. The Drive-CliQ topology of the drive is read out.</p>  <p>The screenshot shows a dialog box titled "Automatic Configuration" with a yellow warning icon. The text reads: "Configure drive unit automatically. The DRIVE-CLiQ topology is determined and the electronic type plates are read out. The data is then loaded to the PG and replaces the configuration in the project." Below the text, there are two status fields: "Status of the drive unit: First commissioning" and "Running operation: Waiting for START". At the bottom, the "Configure" button is highlighted with a red rectangle, along with a "Cancel" button.</p> |

4 Configuration and programming

4.4 Configuration of the SINAMICS drive

| No. | Action |
|-----|--|
| 8. | <p>A servo motor is used in the SINAMICS training case.</p>  |
| 9. | <p>If the firmware version of the drive has changed compared to the last commissioning, after the automatic configuration it may be necessary to "Power OFF/ON" the drive to update the firmware of the Drive-CLiQ components</p>  <p>Note Before "Power OFF/ON" execute the "RAM to ROM" function at the drive to save the previous configuration in a non-volatile way.</p> |

NOTE

If you are working with a SIMOTION training case (MLFB: 6ZB2470-0xx00) and an external CU320-2 PN (or CU320-2 DP + CBE20), please note that after the automatic drive configuration, the following steps still have to be performed:

- At the SIMOTION training case, the blue drive ("SERVO_03") must be reconfigured, as it does not have a Drive-CliQ interface.
All windows, which are not described in the following, can be skipped!
 - Open the drive configuration.
("Drives > SERVO_03 > Configuration > Configure DDS")
 - Connect the enable for the infeed ("p0864") with the fixed binector "1".
 - Select the motor installed in the training case.
("Select standard motor from list > Motor type: 1FK7 synchronous motor > MLFB: 1FK7022-xAK7x-xxxx")
 - Select the encoder type installed in the training case.
("MLFB: 1FK7xxx-xxxxx-xAxx")
 - Close the configuration and save the settings.
- At the two motors ("SERVO_02 + SERVO_03") set the following parameter values. To do this, go offline and open the relevant expert list.

| Parameter | Description | Value |
|-----------|--|--------------|
| p0340 | Automatic calculation | 0 |
| p0210 | Supply voltage | 345 V |
| p0864 | Infeed in operation | 1 |
| p1244[0] | Upper voltage limit for the DC link | 401 V |
| p1248[0] | Lower voltage limit for the DC link | 240 V |
| p1460[0] | P component for the speed controller | 0.01 Nms/rad |
| p1462[0] | Integral time for the speed controller | 20 ms |

Please note that these settings apply only when you are working with a SIMOTION training case!

- Afterwards go online, load the configuration into the drive and carry out the "RAM to ROM" function.



NOTE

If you are working with a SINAMICS training case (MLFB: 6ZB2480-0xx00) and a CU2x0x-2 PN(-F), please note that here it is not possible to automatically configure the drive!

In this particular case, the SINAMICS G120 must be manually configured. For this purpose, use the nameplates for the Power Module (PM) and motor attached to the training case, and enter the corresponding data into the configuration screen forms in STARTER.






4 Configuration and programming

4.4 Configuration of the SINAMICS drive

| No. | Action |
|-----|--|
| 10. | <p>Open the drive telegram configuration using the menu item "Communication > Telegram configuration".</p>  <p>Note Carry out the following steps that are described offline!</p> |
| 11. | <p>The following telegrams are used for cyclic communication between the controller and drive in the sample project:</p> <ul style="list-style-type: none"> SERVO_02 Standard telegram 1, PZD-2/2 CU_S SIEMENS telegram 390, PZD-2/2 <p>Set these telegrams in the drive telegram configuration and align the telegram configuration with HW Config ("Set up addresses").</p>  <p>Note Confirm the message that follows with "Yes". A blue tick after the telegrams indicates that the telegram configuration has been successfully aligned with HW Config.</p> |

4 Configuration and programming

4.4 Configuration of the SINAMICS drive

| No. | Action |
|-----|---|
| 12. | <p>Change to the HW Config of the SIMATIC CPU, and check the size of the process image of the controller (double click on the CPU > tab "Cycle/Clock Memory").</p>  <p>Note If required, adapt the size of the process image of the inputs and outputs so that the input and output data of the SINAMICS drive telegrams are completely inside of the process image of the controller!</p> |
| 13. | <p>Save and compile the configuration of the SINAMICS drive in STARTER and in the HW Config of the SIMATIC CPU.</p>  |
| 14. | <p>Establish an online connection with the drive.</p>  |
| 15. | <p>Download to the SINAMICS drive and load HW Config into the controller.</p>  |
| 16. | <p>Execute the "RAM to ROM" function in the drive to save its configuration in a non-volatile way.</p>  |
| 17. | <p>The communication between the SIMATIC CPU and SINAMICS drive has therefore been configured.</p> |

4.5 Activation of the servo motor

In the sample project, the cyclic communication between SIMATIC CPU and SINAMICS drive is implemented in OB1. The OB1 contains the user program subsequently described.

Table 4-4

| No. | Action |
|-----|--|
| 1. | <div style="border: 1px solid black; padding: 5px;"> <p>▢ Network 1: User program</p> <p>Speed calculation, drive control and failure reset</p> <pre> // speed calculation L "N_SOLL_USER" MD100 L 6.000000e+003 /R L 1.638400e+004 W#16#4000 /R TRUNC T "N_SOLL" MW110 U "boMove" MO.0 SPBN S002 </pre> <p>The user must specify the speed setpoint used to operate the servo motor ("N_SOLL_USER"). The calculation of the speed setpoint is based on the specified definitions of the PROFIdrive profile. 6000 rpm corresponds to the value "W#16#4000". The calculated speed is then buffered so that it can be further accessed ("N_SOLL"). The servo motor is operated with the calculated speed and is stopped again by setting the "boMove" flag.</p> <p>Note The rated speed of the servo motor installed in the training case is 6000 rpm. The maximum speed is 10000 rpm.</p> </div> |

4 Configuration and programming

4.5 Activation of the servo motor

| No. | Action |
|-----|---|
| 2. | <pre> // drive control L W#16#47E → 2#0000_0100_0111_1110 T MW 10 L "N_SOLL" MW110 T "N_SOLL_Drive" AW258 L "ZSW1_Drive" EW256 L W#16#211 → 2#0000_0010_0001_0001 UW L W#16#211 ==I SPBN S001 L W#16#47F → 2#0000_0100_0111_1111 T MW 10 S001: L MW 10 T "STW1_Drive" AW256 SPA S003 </pre> <p>If flag "boMove" is controlled to a value of "1", then the required releases are set in control word 1 ("STW1") of the servo motor (W#16#47E), so that it can be moved.</p> <p>To ensure that the motor is only moved when all releases required are actually present, its status word 1 ("ZSW1") is compared with a constant word that represents the required releases (W#16#211).</p> <p>Only when status word 1 ("ZSW1") matches this value, the bit in control word 1 ("STW1") is set, that switches on the servo motor (W#16#47F). The servo motor is then moved with the speed setpoint entered by the user.</p> |
| 3. | <pre> S002: L 0 T "N_SOLL_Drive" AW258 L W#16#400 → 2#0000_0100_0000_0000 T "STW1_Drive" AW256 // failure reset U "boReset" M1.0 SPBN S003 L W#16#480 → 2#0000_0100_1000_0000 T "STW1_Drive" AW256 S003: NOP 0 </pre> <p>The speed setpoint of the servo motor is 0 rpm as long as the "boMove" flag is not controlled to a value of "1".</p> <p>In control word 1 ("STW1"), only bit 10 ("Control by PLC") is set (W#16#400).</p> <p>If faults are active, flag "boReset" can be controlled to a value of "1".</p> <p>As a consequence, in control word 1 ("STW1") of the servo motor additionally bit 7 ("Acknowledge faults") is set, which acknowledges the fault (W#16#480). In this case, flag "boMove" must have the value "0"!</p> |

4 Configuration and programming

4.5 Activation of the servo motor

NOTE The structure of the relevant (standard) telegram (i.e. STW1, NSOLL_B, etc.) is defined in the PROFIdrive profile. You can find further information about this at the following link:

[SINAMICS S120 / S150 List Manual](#) (Chapter 2.9)

NOTE The following addresses are used in the sample project to control the SINAMICS drive:

- AW 256 Control word 1 ("STW1")
- AW 258 Speed setpoint ("NSOLL_B")
- EW 256 Status word 1 ("ZSW1")

| Slot | Module | Order number | I address | Q address | Diagnostics address |
|-----------|------------------------------|----------------------------|-----------|-----------|---------------------|
| 0 | SINAMICS-CU310-2.X150 | 6SL3 040-1LA01-0Axx | | | 8183* |
| X150 | PN IO | | | | 8182* |
| X150.P1.R | Port 1 | | | | 8185* |
| X150.P2.R | Port 2 | | | | 8184* |
| 1 | SERVO_02 | | | | 8181* |
| 1.1 | Module access point | | | | 8181* |
| 1.2 | Standard message frame 1 | | 256...259 | 256...259 | |
| 1.3 | | | | | |
| 2 | CU 5 | | | | 8180* |
| 2.1 | Module access point | | | | 8180* |
| 2.2 | SIEMENS message frame 39 | | 260...263 | 260...263 | |
| 2.3 | | | | | |

5 Commissioning the sample project

5.1 Overview


An executable sample project is included in the zip archive "38844967_SIMATIC_SINAMICS_PN_RT_V2_0.zip" provided.

5.2 Commissioning

The steps described in the following must be performed to commission the sample project.






Table 5-1

| No. | Action |
|-----|--|
| 1. | All hardware components listed in Table 2-1 (Page 7) are available, and have been upgraded to the required firmware version. |
| 2. | All PROFINET components are networked and accessible from the engineering system. |
| 3. | The Ethernet interface of the engineering system is configured correctly and is working. <u>Example</u> IP address: 192.168.0.99 subnet mask: 255.255.255.0 |
| 4. | Start the STEP 7 SIMATIC Manager engineering system. |
| 5. | Retrieve the sample project "38844967_SIMATIC_SINAMICS_PN_RT_V2_0.zip". |
| 6. | Open the HW Config of the SIMATIC CPU. |
| 7. | Download the HW Config and all blocks from the block container into the controller. |
| 8. | Carry out a node initialization of the SINAMICS drive. To do this, change to HW Config of the controller and select the PROFINET network. Using the menu item "PLC > Ethernet > Assign Device Name..." open the window to assign a name. |



5 Commissioning the sample project

5.2 Commissioning

| No. | Action |
|-----|---|
| 9. | <p>Select the device name configured in HW Config using the drop-down menu (1). Then select the SINAMICS drive from the list of available devices (2) and assign the device name using the "Assign name" (3) button.</p>  <p>Note Only IO devices are listed here. IO controllers receive their device name by downloading the HW Config.</p> |
| 10. | <p>As an alternative, the Primary Setup Tool (PST) can also be used to perform the node initialization. The PST can be downloaded at the following link. http://support.automation.siemens.com/WW/view/en/19440762</p> |
| 11. | <p>Start the STARTER engineering system from the project in the SIMATIC Manager.</p>  |
| 12. | <p>Establish an online connection with the SINAMICS drive.</p>  |
| 13. | <p>Download the configuration of the drive into the target device.</p>  |
| 14. | <p>Then execute the "RAM to ROM" function.</p>  |
| 15. | <p>The sample project is now ready for operation.</p> |

6 Operating the sample project



6.1 Overview

The sample project is operated using the variable table "Drive control" of the SIMATIC CPU in the SIMATIC Manager.

Here, the user can enter the setpoint speed for the servo motor as well as switching the motor on and off. Possibly upcoming faults of the servo motor can also be acknowledged.

6.2 Operation

Table 6-1

| No. | Action |
|-----|---|
| 1. | <p>Open the variable table "Drive control", which is located in the block container of the SIMATIC CPU.</p>  |
| 2. | <p>In the variable table, switch to the online view using button "Monitor variable" (1). Then enter the required speed setpoint in column "Modify value" into flag double word MD100 (unit: rpm) and the value "true" or "1" into flag M0.0 (2). Activate the values by using the button "Activate modify values" (3).</p>  |

6 Operating the sample project

6.2 Operation

| No. | Action |
|-----|---|
| 3. | <p>The speed "N_SOLL_USER" entered by the user is scaled according to the definitions of the PROFIdrive profile and entered at the servo motor as speed setpoint. Further, the required releases are set in control word 1 ("STW1") of the drive to move it.</p> <p>Note The speed setpoint can also be changed if the servo motor is already in operation, i.e. flag "boMove" is set.</p> |
| 4. | <p>By setting flag "boReset", possible faults present at the servomotor can be acknowledged.</p> <p>Note Pending faults can be acknowledged only when the servomotor is not operational, i.e. the "boMove" flag must not be set! Further it should be noted that flag "boReset" is not automatically reset to the value "0". This must be done manually after the acknowledgement of the faults!</p> |

7 References

Table 7-1

| | Topic | Title |
|-----|---------------------------------|---|
| \1\ | Siemens Industry Online Support | http://support.automation.siemens.com |
| \2\ | Download page of the article | http://support.automation.siemens.com/WW/view/en/38844967 |
| \3\ | SINAMICS S120/S150 | http://support.automation.siemens.com/WW/view/en/68041075 (List Manual 2013) |

8 Contact

Siemens AG
 Industry Sector
 I DT MC PMA APC
 Frauenaauracher Strasse 80
 D - 91056 Erlangen, Germany
 mailto: profinet.team.motioncontrol.i-dt@siemens.com

9 History

Table 9-1

| Version | Date | Revision |
|---------|---------|--|
| V1.0 | 12/2006 | First Edition |
| V2.0 | 01/2014 | Revised edition, adaptation to the new hardware and software |