

Controlling distributed I/Os and drives from two controllers via PROFINET (Shared Device via Object Manager)

SIMATIC & SINAMICS

Application Example • May 2012

Applications & Tools

Answers for industry.

SIEMENS

Siemens Industry Online Support

This article is taken from the Siemens Industry Online Support. The following link takes you directly to the download page of this document:

<http://support.automation.siemens.com/WW/view/en/50207311>

Caution

The functions and solutions described in this article confine themselves to the realization of the automation task predominantly. Please take into account furthermore that corresponding protective measures have to be taken up in the context of Industrial Security when connecting your equipment to other parts of the plant, the enterprise network or the Internet. Further information can be found under the Item-ID 50203404.

<http://support.automation.siemens.com/WW/view/en/50203404>

If you have any questions concerning this document please e-mail us to the following address:

profinet.team.motioncontrol.i-dt@siemens.com

You can also actively use our Technical Forum from the Siemens Industry Online Support regarding this subject. Add your questions, suggestions and problems and discuss them together in our strong forum community:

<http://www.siemens.com/forum-applications>

SIEMENS

SIMATIC & SINAMICS Shared Device

Application Example

Problem

1

Solution

2

Basics

3

Configuration

4

Startup of the application

5

**Operation of the
application**

6

Contact

7

History

8

Warranty and liability

Note

The Application Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly. These application examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time without prior notice.

If there are any deviations between the recommendations provided in these application examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document.

Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Application Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act (“Produkthaftungsgesetz”), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract (“wesentliche Vertragspflichten”). The damages for a breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of Siemens Industry Sector.

Table of contents

Warranty and liability	4
1 Problem	6
1.1 Overview	6
2 Solution	8
2.1 Solution overview	8
2.2 Description of the core functionality.....	9
2.3 Required Hardware and Software Components	10
2.4 Alternative solutions.....	11
3 Basics	12
3.1 PROFINET communication.....	12
3.2 PROFIsafe communication	13
4 Configuration	15
4.1 HW Config of the SIMATIC Standard-CPU.....	15
4.2 HW Config of the SIMATIC F-CPU.....	17
4.3 HW Config of the distributed SINAMICS drive.....	23
4.4 Configuring the distributed SINAMICS drive.....	26
4.5 HW Config of the distributed SINAMICS drive as Shared Device.....	33
4.6 Configuring the SINAMICS drive as Shared Device	37
4.7 Activating the drive internal safety functions.....	38
4.8 Configuring the drive internal safety functions	44
4.9 Configuring the distributed SIMATIC ET 200 Station	50
4.10 Configuring the SIMATIC ET 200 Station as Shared Device.....	51
5 Startup of the application	54
5.1 Startup	54
6 Operation of the application	57
6.1 Overview	57
6.2 Distributed SIMATIC ET 200 Station as Shared Device.....	57
6.3 Distributed SINAMICS drive as Shared Device	57
7 Contact	59
8 History	59

1 Problem

1.1 Overview

Introduction

PROFINET IO provides the functionality **Shared Device** in order to access an IO-Device from two IO-Controllers.


Shared Device allows to flexibly assign the input and output data to two different IO-Controllers. This functionality is used to activate the drive internal safety functions from a F-CPU. The command velocity is specified in parallel from a Standard-CPU.

Other possibilities to activate the drive internal safety functions using the terminal extension module TM54F as well as the activation via PROFIBUS with PROFIsafe are described in further application examples.

Overview about the automation task

The following figure provides an overview about the automation task.

Fig. 1-1



A system is automated using a failsafe F-CPU and a Standard-CPU, as well as distributed I/Os and drives via PROFINET.

The Standard-CPU uses the non-failsafe inputs and outputs and specifies the command velocity for the drives.


The F-CPU uses the failsafe inputs and outputs and activates the drive internal safety functions via PROFINET with PROFIsafe.

The following drive internal safety functions are used in the corresponding sample project.

- **STO**
When actuating the emergency OFF switch -S1, STO is selected on the drive 2 (blue), that means, the drive coasts down. The pulses are deleted immediately and the power supply is safely interrupted electronically.
- **SS1**
When actuating the emergency OFF switch -S1, SS1 is selected on the drive 1 (red), that means, the drive does not coast down and is decelerated along the OFF3 ramp. Afterwards, STO is active on this drive.
- **SOS**
When opening the protective door 1 -S2, SOS is selected on the drive 1 (red), that means the standstill position of drive 1 is safely monitored after a configurable delay time.
- **SLS**
When opening the protective door 2 -S3, SLS is selected on the drive 2 (blue), that means the speed of drive 2 is monitored for a configurable maximum value after a configurable delay time. As a fault reaction of SLS upon exceeding of the safe speed, STOP C (SS2) is triggered on the relevant drive.

The safety-relevant signals are recorded via failsafe inputs. In the safety program of the F-CPU, the bits activating the drive internal safety functions are set depending on the safety-relevant signals. The communication to the drive is established via a failsafe PROFIsafe telegram.

Fig. 1-2: Safety-relevant signals




2 Solution

2.1 Solution overview

Display

The following figure displays the most important components of the solution:

Fig. 2-1



This application example shows the activation of the safety functions STO, SS1, SOS and SLS via PROFINET with PROFIsafe on a distributed SINAMICS S120 drive.

Here, the PROFINET functionality **Shared Device** is used, that means the SIMATIC CPU 315-2 PN/DP specifies the command speed and the CPU 317F-2 PN/DP activates the safety functions in the drive.

The SINAMICS Control Unit is integrated into both IO-Controllers via PROFINET as **Shared Device**.

The SINAMICS S120 drive in Booksize format comprises an infeed unit (SLM) and a Double Motor Module (DMM). The motor is controlled via a Control Unit (CU). The two mutually independent servomotors are actuated via the Double Motor Module.

Both drives use different safety functions. The safety-relevant signals (see Fig. 1-2) are recorded via a F-CPU with failsafe inputs of the SIMATIC ET 200. The failsafe PROFIsafe communication allows to individually activate the safety functions for each drive. The F-CPU serves both as F-Host and PROFINET IO-Controller.

Delimitation

This application example does not include a description of the

- general drive functions of the SINAMICS

You must have acquired basic knowledge regarding these topics.


Basic knowledge

You must have acquired basic knowledge regarding the configuring of SIMATIC controllers with the STEP7 engineering system and the configuring of SINAMICS drives with STARTER resp. SIMOTION SCOUT.

2.2 Description of the core functionality

Overview and description of the core functionality

Fig. 2-2



Advantages provided by this solution

The solution presented here provides the following advantages:

- Convenient activation of the drive integrated safety functions
- Convenient setup due to standardized technology
- The existing system can be expanded conveniently and quickly.
- Space-saving and low-cost setup due to drive internal safety functions – no additional hardware required
- An ET200 interface module for standard and failsafe modules

Supplementary conditions

- **No arbitrary assignment of the standard and PROFI-safe telegrams on the drive**
With SINAMICS as **Shared Device**, the F-CPU can only access the PROFI-safe telegrams of the drives. In contrast to this, the Standard-CPU can only access the standard telegrams of the individual drives. That means, an IO-Controller must specify the command speed for all drives, a second IO-Controller (F-CPU) establishes the PROFI-safe communication to all drives. On an ET 200 Station as **Shared Device**, the input and output modules can be arbitrarily assigned to one of the two controllers.
- **You must ensure the sequence of telegrams for the functionality Shared Device via Object Manager.**
First of all, you have to create the telegrams to the SERVOS, then the telegram to the infeed and then – if required – the telegram to the Control Unit.

2.3 Required Hardware and Software Components

The application was generated with the following components:

Hardware components

Table 2-1

Component	No.	MLFB / order number	Note
Safety training case	1		
SIMATIC 317F-CPU	1	6ES7317-2FK14-0AB0	As from firmware V3.2
SIMATIC 315 CPU	1	6ES7315-2EH14-0AB0	As from firmware V3.2
SIMOTION training case	1	6ZB2 470-0AE00	
CU320-2 DP (+ CBE20) alternatively CU320-2 PN alternatively CU310-2 PN	1	6SL3040-1MA00-0AA0 6SL3040-1MA01-0AA0 6SL3040-1LA01-0AA0	As from firmware V4.5 As from firmware V4.5 As from firmware V4.5
CompactFlash Card	1	6SL3054-0ED00-1BA0	
CBE20	1	6SL3055-0AA00-2EB0	Optional for CU320-2
SIMATIC ET 200S HF	1	6ES7151-3BA23-0AB0	As from firmware V7.0

Note

The sample project has been created using the hardware components listed. Alternatively, you can also use other, functionally equivalent components. For this, you may have to use another parameterization and component wiring.

Regarding the **Shared Device** configuration of a CU310-2 PN resp. CU320-2 PN or a SINAMICS G120 V4.5 with PROFINET interface proceed as shown in the application example displayed here. A CU320-2 DP + CBE20 is used in the application example and in the sample project.

Further components supporting **Shared Device** you can take out of following link:

<http://support.automation.siemens.com/WW/view/en/44383954>

Standard software components

Table 2-2

Component	No.	MLFB / order number	Note
STEP7	1	6ES7810-4CC10-0YA5	V5.5 SP2
S7 Distributed Safety	1	6ES7833-1FC02-0YA5	V5.4 SP5
S7 F ConfigurationPack	1	---	V5.5 SP9
STARTER	1	6SL3072-0AA00-0AG0	V4.3
SIMOTION SCOUT	1	---	V4.3.1 (alternativ zu STARTER und Drive ES Basic)
Drive ES BASIC	1	6SW1700-5JA00-4AA0	V5.5

Licenses

Table 2-3

License	MLFB / order number	Note
SINAMICS LICENSE SAFETY INTEGRATED EXTENDED FUNCTIONS	6SL3074-0AA10-0AA0	per axis

Sample files and projects

The following list includes all files and projects that are used in this example.

Table 2-4

Component	Note
50207311_Example_Shared_Device_V2_0.zip	STEP 7 project
50207311_Application_Example_Shared_Device_V2_0_en.pdf	This document

2.4 Alternative solutions

SIMOTION I-Device-F-Proxy

At present, the use of SINAMICS drive as **Shared Device** on a SIMOTION controller is restricted as follows.

As the drive must be configured in the HW Config via a GSD file when using the **Shared Device** functionality, automatic adjustment mechanisms between SCOUT and the HW Config are not supported. Thus, you must explicitly ensure consistency of the telegram configuration in the SIMOTION project.

Note

When using PROFIsafe via PROFINET with SIMOTION and SINAMICS, you must always use the communication via the I-Device-F-Proxy. More detailed information about the I-Device-F-Proxy is provided in the following article.

<http://support.automation.siemens.com/WW/view/en/50207350>

3 Basics

3.1 PROFINET communication

Not only the MAC address but also the device name is used to identify the devices for PROFINET. This device name must be unique across the PROFINET network.

During the commissioning phase, the HW Config or the Primary Setup Tool (PST) is used to make an initial online assignment of a device name for each PROFINET device (a so-called node initiation). This online-assigned device name is stored retentively in the PROFINET device and must match the device name in the project.

If a device is replaced, e.g. because of a defect, the new device has a different MAC address. If it is initiated with the same device name as the replaced device (e.g. by reconnecting a CF card / MMC that stores the device name retentively), it can assume the function of the replaced device without any changes in the configuration (spare part).

Rules for assigning names

A device name must be stored retentively on a PROFINET device. This name must match the device name in the project. The following rules apply in this case:

- The device name stored retentively in the device must only contain lowercase letters.

Note

The device name in the project must only contain uppercase letters. During the initiation, the engineering system replaces the uppercase letters with lowercase letters.

- Letters a-z and digits 0-9 may be used.
- Special characters are not permitted: ! " § \$ % & / () = ? * ' _ : ; > < , # + | ~ \ }] [{
- Blanks are also not permitted.
- The total maximum length for a name is 240 characters.
- Reserved names that cannot be used:
"port-xyz" or "port-xyz-abcde" (a, b, c, d, e, x, y, z = 0...9)
- The minus character must not be used for a SIMOTION controller.

3.2 PROFIsafe communication

Each drive with a configured PROFIsafe telegram represents a F-Device with PROFIsafe communication to the F-Host.

A separate PROFIsafe telegram 30 is created for each drive. This telegram has 6 bytes of input data and 6 bytes of output data. The first two bytes (PZD1) comprise the safety user data each. The remaining bytes are required for failsafe PROFIsafe communication.

F-CPU → Drive

Fig. 3-1: The F-CPU sends the following control signals to the drive.

PROFIsafe control word (S_STW1, PZD1 in telegram 30)															
Byte 0								Byte 1							
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
STO	SS1	SS2	SOS	SLS	Res	Res	Int. Ev. ACK	Res	SLS Limit sel.	SLS Limit sel.	Res	SDI pos.	SDI neg.	Res	Res

Drive → F-CPU

Fig. 3-2: The drive reports the status of the safety functions to the F-CPU.

PROFIsafe-ZSW (S_ZSW1, PZD1 in telegram 30)															
Byte 0								Byte 1							
0	1	2	3	4	5	6	7	0	1	2	3	4	5	6	7
STO act.	SS1 act.	SS2 act.	SOS act.	SLS act.	Res	Res	Int. Ev.	Res	SLS Limit	SLS Limit	SOS sel.	SDI pos. act.	SDI neg. act.	Res	SSM

Note

Unused safety functions must be deselected via a safe high signal in the PROFIsafe control word.

At present, the SINAMICS S120 drive provides the following Safety Integrated Extended Functions according to IEC 61800-5-2. These also include the Safety Integrated Basic Functions.

Table 3-1: Overview about the safety functions of the SINAMICS S120

Name	Function	Description
STO	Safe Torque Off	<ul style="list-style-type: none"> Failsafe interruption of the torque-forming power supply to the motor Restarting is disabled via the power on disable. Stop function of Category 0 acc. to EN 60204-1
SBC	Safe Brake Control	<ul style="list-style-type: none"> SBC is only used with existing motor brake, the motor brake is connected via the outputs to the power connector. SBC always reacts in combination with STO or as soon as internal safety monitors respond with failsafe pulse suppression.

Name	Function	Description
SS1	Safe Stop 1	<ul style="list-style-type: none"> Fast and failsafe monitored drive stopping along the OFF3 ramp Transition to STO upon expiry of a delay time or when reaching creep speed Stop function of Category 1 acc. to EN 60204-1 <p>Braking is not monitored with Safety Integrated Basic Functions. Further, the transition to STO only depends on expiry of the delay time.</p>
SS2	Safe Stop 2	<ul style="list-style-type: none"> Fast and failsafe monitored drive stopping along the OFF3 ramp Transition to SOS upon expiry of a delay time (the drive remains under control) Stop function of Category 2 acc. to EN 60204-1
SOS	Safe Operating Stop	<ul style="list-style-type: none"> Failsafe monitoring of the standstill position (the drive remains under control)
SLS	Safely-Limited Speed	<ul style="list-style-type: none"> Failsafe monitoring of the speed Parameterizable stop reaction when exceeding the limit speed
SSM	Safe Speed Monitor	<ul style="list-style-type: none"> Failsafe display of speed limit violation ($n < nx$)
SDI	Safe Direction	<ul style="list-style-type: none"> As from SINAMICS Firmware V4.4 Failsafe monitoring of the moving direction (positive and negative direction) Parameterizable stop reaction when traversing in the non-released direction

These safety functions can be activated both via PROFIBUS or PROFINET with PROFIsafe, and via a terminal extension module TM54F.



In this example, the safety functions are activated from a SIMATIC F-CPU via PROFINET with PROFIsafe.

4 Configuration

4.1 HW Config of the SIMATIC Standard-CPU



In the sample project, a SIMATIC CPU 315-2 PN/DP V3.2 - which is configured as follows - is used to specify the command speeds for the drives.

Table 4-1

No.	Action
1.	<p>Insert a new SIMATIC Station in the SIMATIC Manager. Open the HW Config to configure the new SIMATIC Station.</p>  <p>Press F1 to get Help.</p>
2.	<p>Insert a SIMATIC CPU 315-2 PN/DP V3.2 in the HW Config.</p>  <p>Press F4 to automatically arrange the existing modules in the HW Config.</p>

4 Configuration



4.1 HW Config of the SIMATIC Standard-CPU

No.	Action
3.	<p>Create a new Ethernet subnet and assign an IP address.</p> 
4.	<p>Double-click the PROFINET interface (see No. 2) to open the properties screen. Define the device name.</p> <p>In the sample project, the device name is "Standard-CPU". The device name remanently stored on the PROFINET device must therefore be "standard-cpu".</p> 

4.2 HW Config of the SIMATIC F-CPU

A safety training case is used to activate the safety functions in the drive. A SIMATIC CPU 317F-2 PN/DP V3.2 - which is configured as follows - is used as F-CPU.



Table 4-2



No.	Action																																																								
1.	Insert another SIMATIC Station in the SIMATIC Manager. Open the HW Config to configure the new SIMATIC station. 																																																								
2.	Insert a SIMATIC CPU 317F-2 PN/DP V3.2 in the HW Config.  <table border="1" data-bbox="320 1263 1075 1464"> <thead> <tr> <th>Slot</th> <th>Module</th> <th>Order number</th> <th>Firmware</th> <th>MPI address</th> <th>I address</th> <th>Q address</th> <th>Comment</th> </tr> </thead> <tbody> <tr> <td>1</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>2</td> <td>CPU 317F-2 PN/DP</td> <td>6ES7 317-2FK14-0AB0</td> <td>V3.2</td> <td>2</td> <td></td> <td></td> <td></td> </tr> <tr> <td>X7</td> <td>MPI/DP</td> <td></td> <td></td> <td></td> <td>0191*</td> <td></td> <td></td> </tr> <tr> <td>X2</td> <td>F-CPU</td> <td></td> <td></td> <td></td> <td>0192*</td> <td></td> <td></td> </tr> <tr> <td>X2</td> <td>Port 1</td> <td></td> <td></td> <td></td> <td>0168*</td> <td></td> <td></td> </tr> <tr> <td>X2</td> <td>Port 2</td> <td></td> <td></td> <td></td> <td>0168*</td> <td></td> <td></td> </tr> </tbody> </table>	Slot	Module	Order number	Firmware	MPI address	I address	Q address	Comment	1								2	CPU 317F-2 PN/DP	6ES7 317-2FK14-0AB0	V3.2	2				X7	MPI/DP				0191*			X2	F-CPU				0192*			X2	Port 1				0168*			X2	Port 2				0168*		
Slot	Module	Order number	Firmware	MPI address	I address	Q address	Comment																																																		
1																																																									
2	CPU 317F-2 PN/DP	6ES7 317-2FK14-0AB0	V3.2	2																																																					
X7	MPI/DP				0191*																																																				
X2	F-CPU				0192*																																																				
X2	Port 1				0168*																																																				
X2	Port 2				0168*																																																				

Press F4 to automatically arrange the existing modules in the HW Config.

4 Configuration


4.2 HW Config of the SIMATIC F-CPU


No.	Action
3.	<p>Select the existing Ethernet subnet and assign an IP address.</p>  <p>The screenshot shows the 'Properties - Ethernet interface PN-IO (R0/S2.2)' dialog box. The 'General' tab is selected. The 'IP address' field contains '192.168.0.2' and the 'Subnet mask' field contains '255.255.255.0'. Below these fields, there is a checkbox for 'Use different method to obtain IP address' which is unchecked. The 'Subnet' list shows 'Ethernet(1)' selected. To the right, the 'Gateway' section has 'Do not use router' selected. At the bottom, there are 'OK', 'Cancel', and 'Help' buttons.</p>
4.	<p>Double-click the PROFINET interface (see No. 2) to open the properties screen. Define the device name.</p> <p>In the sample project, the device name is "F-CPU". The device name remanently stored on PROFINET must therefore be "f-cpu".</p>  <p>The screenshot shows the 'Properties - F-CPU (R0/S2.2)' dialog box. The 'PROFINET' tab is selected. The 'Device name' field contains 'F-CPU'. Below it, there is a checkbox for 'Use different method to obtain device name' which is unchecked, and a checked checkbox for 'Support device replacement without exchangeable medium'. The 'Interface' section shows 'Type: Ethernet', 'Device number: 0', 'Address: 192.168.0.2', and 'Networked: Yes'. At the bottom, there are 'OK', 'Cancel', and 'Help' buttons.</p>

No.	Action
5.	<p>Insert the input and output modules of the safety training case.</p> 
6.	<p>Double-click the relevant module to open the Properties screen. In the <i>Parameters</i> tab, the safety settings are made as follows. The emergency OFF switch is connected to the <i>Channel 0, 12</i> (equivalent).</p>  <p>Please check whether the DIL switch position at the rear of the ET 200M modules corresponds to the configured <i>F_dest_address</i>. In the sample project, the <i>F_dest_address</i> is set to 199.</p>

4 Configuration




4.2 HW Config of the SIMATIC F-CPU

No.	Action
7.	<p>The switch for the protective door 1 -S2 is connected to the <i>Channel 1, 13</i> (antivalent). The switch for the protective door 2 -S3 is connected to the <i>Channel 2, 14</i> (equivalent). The switch -S4 for fault acknowledgement and depassivating the safety modules is connected to the <i>Channel 3</i> (single-channel).</p>  <p>The remaining inputs are not used in the sample project!</p>

No.	Action
8.	<p>The outputs only use the <i>Channel 7</i> to actuate the signal lamp -S4.</p>  <p>Please check whether the DIL switch position at the rear of the ET 200M modules corresponds to the configured <i>F_dest_address</i>. In the sample project, the <i>F_dest_address</i> is set to 200.</p>

4 Configuration

4.2 HW Config of the SIMATIC F-CPU



No.	Action
9.	<p>Double-click the F-CPU in HW Config to open the properties screen.</p>  <p>The screenshot shows the HW Config software interface. The 'Hardware Catalog' on the left lists various modules, with 'CPU 317F-2 PN/DP' highlighted. The main workspace displays a rack configuration with the CPU in slot 2. The 'Properties' window for the CPU is open, showing the 'Protection' tab. The 'Protection' tab includes options for 'Protection level' (1: Access protect. for F CPU, 2: Write-protection, 3: Read/write-protection), a 'Password' field, a 'Reenter password' field, and a checked checkbox for 'CPU contains safety program'.</p>
10.	<p>In the <i>Protection</i> tab select the option “Read/write-protection” and assign a new password (in application example: 1).</p> <p>The CPU contains the safety program to activate the safety functions in the drives. Therefore select the option „CPU contains safety program“.</p>  <p>The screenshot shows the 'Properties - CPU 317F-2 PN/DP - (R0/S2)' dialog box. The 'Protection' tab is selected. The 'Protection level' is set to '3: Read/write-protection'. The 'Password' field contains '1', and the 'Reenter password' field also contains '1'. The checkbox 'CPU contains safety program' is checked.</p>
11.	<p>Save and compile the HW Config.</p>  <p>The screenshot shows the HW Config software interface with the 'Save and compile' button highlighted.</p>

4.3 HW Config of the distributed SINAMICS drive

As from firmware V4.5 SINAMICS drives with the functionality **Shared Device** can be configured directly via the DeviceOM (Object Manager).


For the configuration you have to observe some rules that are shown in the following steps.

Table 4-3




No.	Action
1.	<p>At the beginning of the Shared Device configuration you have to pay attention that the SINAMICS drive is inserted in the HW Config of the Standard-CPU first. Insert the CU320-2 DP + CBE20 in the HW Config of the SIMATIC CPU 315-2 PN/DP.</p> 
2.	<p>Select the existing subnet and assign a new IP address.</p> 

4 Configuration

4.3 HW Config of the distributed SINAMICS drive

No.	Action
3.	<p>Open the properties of the SINAMICS drive. Define the device name "SINAMICS-S120-CBE20". The PROFINET device has to be batized with the same device name. The device name will be stored remanently in small later on the PROFINET device.</p>  <p>When ticking the checkbox "Assign IP address via IO-Controller", the configured IP address 192.168.0.3 is assigned to the SINAMICS device during the startup. For this, the SINAMICS device (IO-Device) must be connected to the IO-Controller.</p>

4.3 HW Config of the distributed SINAMICS drive



No.	Action												
4.	<p>The device name has to be assigned to the SINAMICS drive afterwards. Therefore select the PROFINET IO-system. Open the screen for assigning the device name via <i>PLC > Ethernet > Assign Device Name</i>.</p>  <p>The screenshot shows the HW Config interface for a PROFINET IO-System (100). The 'Ethernet' menu is open, and the 'Assign Device Name...' option is highlighted. The device list below shows a SINAMICS drive with IP address 192.168.0.3 and device name SINAMICS-S120-CBE20.</p>												
5.	<p>To assign the name you have configured in the HW Config select the SINAMICS drive and click on the button <i>Assign name</i>.</p>  <p>The screenshot shows the 'Assign device name' dialog box. The 'Device name' is set to SINAMICS-S120-CBE20 and the 'Device' is SINAMICS. In the 'Available devices' table, the SINAMICS drive is selected. The 'Assign name' button is highlighted with a red box.</p> <table border="1" data-bbox="335 1355 877 1433"> <thead> <tr> <th>IP address</th> <th>MAC address</th> <th>Device type</th> <th>Device name</th> </tr> </thead> <tbody> <tr> <td>...</td> <td>00-0E-8C-CC-62-1A</td> <td>ET 2005</td> <td>im151-3pn-22</td> </tr> <tr> <td>...</td> <td>00-0E-8C-92-55-F3</td> <td>SINAMICS</td> <td>cu320x2xdp</td> </tr> </tbody> </table>	IP address	MAC address	Device type	Device name	...	00-0E-8C-CC-62-1A	ET 2005	im151-3pn-22	...	00-0E-8C-92-55-F3	SINAMICS	cu320x2xdp
IP address	MAC address	Device type	Device name										
...	00-0E-8C-CC-62-1A	ET 2005	im151-3pn-22										
...	00-0E-8C-92-55-F3	SINAMICS	cu320x2xdp										
6.	<p>Save and compile the HW Config.</p> 												



4.4 Configuring the distributed SINAMICS drive

Before inserting the SINAMICS drive as **Shared Device** in HW Config of the F-CPU the configuration of the telegrams in STARTER respectively HW Config has to be finished.

In the following the configuration of the SINAMICS drive with the STARTER engineering system is shown.




Table 4-4



No.	Action
1.	<p>Open the actual project in the STARTER engineering system.</p>  <p>The screenshot shows the SIMATIC Manager interface. On the left, the project tree under 'S_Development' shows 'SINAMICS S120 CBE20' and 'S120_CU320_2_DP' highlighted with a red box. On the right, the 'Commissioning' window is open, also with a red box around its title bar.</p>
2.	<p>Establish an online connection to the SINAMICS drive and restore the factory settings.</p>  <p>The screenshot shows the STARTER interface. A context menu is open over the 'SINAMICS:ST' component in the project tree. The 'Restore factory settings' option is highlighted with a red box. The status bar at the bottom indicates 'Online mode'.</p>

No.	Action									
3.	<p>Perform the automatic drive configuration.</p> 									
4.	<p>The SIMOTION training case has two SERVO engines.</p>  <p>Automatic Commissioning</p> <p>During the automatic commissioning, components have been found that cannot be clearly assigned to a drive object type. Please select the drive object type that is to be created for the components.</p> <p>Default setting for all components: Servo</p> <table border="1" data-bbox="339 1294 1034 1384"> <thead> <tr> <th>Component</th> <th>Drive Object Type</th> <th>Identification</th> </tr> </thead> <tbody> <tr> <td>Drive 1</td> <td>Servo</td> <td>Identification via LED</td> </tr> <tr> <td>Drive 2</td> <td>Servo</td> <td>Identification via LED</td> </tr> </tbody> </table> <p style="text-align: center;">Create Help</p>	Component	Drive Object Type	Identification	Drive 1	Servo	Identification via LED	Drive 2	Servo	Identification via LED
Component	Drive Object Type	Identification								
Drive 1	Servo	Identification via LED								
Drive 2	Servo	Identification via LED								

4 Configuration





4.4 Configuring the distributed SINAMICS drive

No.	Action
5.	<p>On the SIMOTION training case the blue drive (SERVO_03) must be reconfigured after performing the automatic configuration because this is not equipped with a DRIVE-CLiQ interface.</p> <p>a) Go offline.</p>  <p>b) Open the drive configuration (all screens which are not displayed can be skipped).</p>  <p>c) Connect the release for the infeed (p0864) to the fixed binector 1.</p> 

No.	Action																																																																																												
6.	<p>d) Select the correct motor type without DRIVE-CLiQ interface.</p>  <table border="1" data-bbox="587 734 1114 1079"> <thead> <tr> <th>Order no.</th> <th>Rated speed</th> <th>Rated torq...</th> <th>Rated curr.</th> </tr> </thead> <tbody> <tr><td>1FK7011-xAK2x-xxxx</td><td>6000 U/min</td><td>0.08 Nm</td><td>0.5 A</td></tr> <tr><td>1FK7011-xAK7x-xxxx</td><td>6000 U/min</td><td>0.08 Nm</td><td>0.85 A</td></tr> <tr><td>1FK7015-xAK2x-xxxx</td><td>6000 U/min</td><td>0.16 Nm</td><td>0.5 A</td></tr> <tr><td>1FK7015-xAK7x-xxxx</td><td>6000 U/min</td><td>0.16 Nm</td><td>0.85 A</td></tr> <tr><td>1FK7022-xAK2x-xxxx</td><td>6000 U/min</td><td>0.6 Nm</td><td>1.4 A</td></tr> <tr><td>1FK7022-xAK7x-xxxx</td><td>6000 U/min</td><td>0.6 Nm</td><td>1.4 A</td></tr> <tr><td>1FK7024-xAK7x-xxxx</td><td>6000 U/min</td><td>0.6 Nm</td><td>1 A</td></tr> <tr><td>1FK7024-xAK7x-xxxx</td><td>6000 U/min</td><td>0.65 Nm</td><td>1 A</td></tr> <tr><td>1FK7032-xAF2x-xxxx</td><td>3000 U/min</td><td>1 Nm</td><td>1.6 A</td></tr> <tr><td>1FK7032-xAK7x-xxxx</td><td>6000 U/min</td><td>0.8 Nm</td><td>1.3 A</td></tr> <tr><td>1FK7033-xAF2x-xxxx</td><td>3000 U/min</td><td>1.2 Nm</td><td>2 A</td></tr> <tr><td>1FK7033-xAK7x-xxxx</td><td>6000 U/min</td><td>0.9 Nm</td><td>1.5 A</td></tr> <tr><td>1FK7034-xAF2x-xxxx</td><td>3000 U/min</td><td>1.45 Nm</td><td>1.8 A</td></tr> <tr><td>1FK7034-xAK7x-xxxx</td><td>6000 U/min</td><td>1 Nm</td><td>1.3 A</td></tr> </tbody> </table> <p>e) Further, you have to select the encoder type.</p>  <table border="1" data-bbox="379 1406 1088 1630"> <thead> <tr> <th>Order no.</th> <th>Encoder type</th> <th>Resolution</th> <th>Code number</th> </tr> </thead> <tbody> <tr><td>1FK7xxx-xxxxx-xAxx</td><td>Sin/cos incremental C/D</td><td>2048 S/R</td><td>2001</td></tr> <tr><td>1FK7xxx-xxxxx-xExx</td><td>EnDat absolute</td><td>2048 S/R</td><td>2051</td></tr> <tr><td>1FK7xxx-xxxxx-xGxx</td><td>EnDat absolute</td><td>32 S/R</td><td>2052</td></tr> <tr><td>1FK7xxx-xxxxx-xHxx</td><td>EnDat absolute</td><td>512 S/R</td><td>2053</td></tr> <tr><td>1FK7xxx-xxxxx-xJxx</td><td>EnDat absolute</td><td>16 S/R</td><td>2054</td></tr> <tr><td>1FK7xxx-xxxxx-xSxx</td><td>Resolver</td><td>n-speed</td><td>1003</td></tr> <tr><td>1FK7xxx-xxxxx-xTxx</td><td>Resolver</td><td>1-speed</td><td>1001</td></tr> </tbody> </table>	Order no.	Rated speed	Rated torq...	Rated curr.	1FK7011-xAK2x-xxxx	6000 U/min	0.08 Nm	0.5 A	1FK7011-xAK7x-xxxx	6000 U/min	0.08 Nm	0.85 A	1FK7015-xAK2x-xxxx	6000 U/min	0.16 Nm	0.5 A	1FK7015-xAK7x-xxxx	6000 U/min	0.16 Nm	0.85 A	1FK7022-xAK2x-xxxx	6000 U/min	0.6 Nm	1.4 A	1FK7022-xAK7x-xxxx	6000 U/min	0.6 Nm	1.4 A	1FK7024-xAK7x-xxxx	6000 U/min	0.6 Nm	1 A	1FK7024-xAK7x-xxxx	6000 U/min	0.65 Nm	1 A	1FK7032-xAF2x-xxxx	3000 U/min	1 Nm	1.6 A	1FK7032-xAK7x-xxxx	6000 U/min	0.8 Nm	1.3 A	1FK7033-xAF2x-xxxx	3000 U/min	1.2 Nm	2 A	1FK7033-xAK7x-xxxx	6000 U/min	0.9 Nm	1.5 A	1FK7034-xAF2x-xxxx	3000 U/min	1.45 Nm	1.8 A	1FK7034-xAK7x-xxxx	6000 U/min	1 Nm	1.3 A	Order no.	Encoder type	Resolution	Code number	1FK7xxx-xxxxx-xAxx	Sin/cos incremental C/D	2048 S/R	2001	1FK7xxx-xxxxx-xExx	EnDat absolute	2048 S/R	2051	1FK7xxx-xxxxx-xGxx	EnDat absolute	32 S/R	2052	1FK7xxx-xxxxx-xHxx	EnDat absolute	512 S/R	2053	1FK7xxx-xxxxx-xJxx	EnDat absolute	16 S/R	2054	1FK7xxx-xxxxx-xSxx	Resolver	n-speed	1003	1FK7xxx-xxxxx-xTxx	Resolver	1-speed	1001
Order no.	Rated speed	Rated torq...	Rated curr.																																																																																										
1FK7011-xAK2x-xxxx	6000 U/min	0.08 Nm	0.5 A																																																																																										
1FK7011-xAK7x-xxxx	6000 U/min	0.08 Nm	0.85 A																																																																																										
1FK7015-xAK2x-xxxx	6000 U/min	0.16 Nm	0.5 A																																																																																										
1FK7015-xAK7x-xxxx	6000 U/min	0.16 Nm	0.85 A																																																																																										
1FK7022-xAK2x-xxxx	6000 U/min	0.6 Nm	1.4 A																																																																																										
1FK7022-xAK7x-xxxx	6000 U/min	0.6 Nm	1.4 A																																																																																										
1FK7024-xAK7x-xxxx	6000 U/min	0.6 Nm	1 A																																																																																										
1FK7024-xAK7x-xxxx	6000 U/min	0.65 Nm	1 A																																																																																										
1FK7032-xAF2x-xxxx	3000 U/min	1 Nm	1.6 A																																																																																										
1FK7032-xAK7x-xxxx	6000 U/min	0.8 Nm	1.3 A																																																																																										
1FK7033-xAF2x-xxxx	3000 U/min	1.2 Nm	2 A																																																																																										
1FK7033-xAK7x-xxxx	6000 U/min	0.9 Nm	1.5 A																																																																																										
1FK7034-xAF2x-xxxx	3000 U/min	1.45 Nm	1.8 A																																																																																										
1FK7034-xAK7x-xxxx	6000 U/min	1 Nm	1.3 A																																																																																										
Order no.	Encoder type	Resolution	Code number																																																																																										
1FK7xxx-xxxxx-xAxx	Sin/cos incremental C/D	2048 S/R	2001																																																																																										
1FK7xxx-xxxxx-xExx	EnDat absolute	2048 S/R	2051																																																																																										
1FK7xxx-xxxxx-xGxx	EnDat absolute	32 S/R	2052																																																																																										
1FK7xxx-xxxxx-xHxx	EnDat absolute	512 S/R	2053																																																																																										
1FK7xxx-xxxxx-xJxx	EnDat absolute	16 S/R	2054																																																																																										
1FK7xxx-xxxxx-xSxx	Resolver	n-speed	1003																																																																																										
1FK7xxx-xxxxx-xTxx	Resolver	1-speed	1001																																																																																										

4 Configuration



4.4 Configuring the distributed SINAMICS drive

No.	Action																								
7.	f) Store your settings.  g) Go online.  h) Perform a download.  i) Copy RAM to ROM. 																								
8.	The following parameters of both drives (SERVO_02 + SERVO_03) must be checked after the automatic configuration. For this, open the expert list. <table border="1" data-bbox="316 745 1353 1093"> <thead> <tr> <th>Parameter</th> <th>Description</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>p0340</td> <td>Complete calculation</td> <td>0</td> </tr> <tr> <td>p0210</td> <td>Supply voltage</td> <td>345 V</td> </tr> <tr> <td>p0864</td> <td>Infeed in operation</td> <td>1</td> </tr> <tr> <td>p1244[0]</td> <td>Upper voltage limit for the dc link</td> <td>401 V</td> </tr> <tr> <td>p1248[0]</td> <td>Lower voltage limit for the dc link</td> <td>240 V</td> </tr> <tr> <td>p1460[0]</td> <td>P-share for the speed controller (in the sample project)</td> <td>0.01 Nms/rad</td> </tr> <tr> <td>p1462[0]</td> <td>Reset time for the speed controller (in the sample project)</td> <td>20 ms</td> </tr> </tbody> </table>	Parameter	Description	Value	p0340	Complete calculation	0	p0210	Supply voltage	345 V	p0864	Infeed in operation	1	p1244[0]	Upper voltage limit for the dc link	401 V	p1248[0]	Lower voltage limit for the dc link	240 V	p1460[0]	P-share for the speed controller (in the sample project)	0.01 Nms/rad	p1462[0]	Reset time for the speed controller (in the sample project)	20 ms
Parameter	Description	Value																							
p0340	Complete calculation	0																							
p0210	Supply voltage	345 V																							
p0864	Infeed in operation	1																							
p1244[0]	Upper voltage limit for the dc link	401 V																							
p1248[0]	Lower voltage limit for the dc link	240 V																							
p1460[0]	P-share for the speed controller (in the sample project)	0.01 Nms/rad																							
p1462[0]	Reset time for the speed controller (in the sample project)	20 ms																							
9.	Depending on whether you are working offline or online, save your changes by copying <i>RAM to ROM</i> , and load the online data in your offline project. Save your data to enter the uploaded data in the offline project.																								

NOTE



Further information about the configuration of the SINAMICS training case is included in the following article:

<http://support.automation.siemens.com/WW/view/en/27038754>

No.	Action																																
10.	<p>For the cyclic communication between SERVO and Standard-CPU you have to choose a telegram. In the application example standard telegram 1 is used. Create the telegrams for both SERVOS.</p>  <p>The screenshot shows the 'Message frame configuration' dialog with the following table:</p> <table border="1"> <thead> <tr> <th>Object</th> <th>Drive object</th> <th>-No.</th> <th>Message frame type</th> <th>Input data Length</th> <th>Input data Address</th> <th>Output data Length</th> <th>Output data Address</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>SERVO_02</td> <td>2</td> <td>Standard telegram 1, PZD-2/2</td> <td>2</td> <td>256..259</td> <td>2</td> <td>256..259</td> </tr> <tr> <td>2</td> <td>SERVO_03</td> <td>3</td> <td>Standard telegram 1, PZD-2/2</td> <td>2</td> <td>???.???</td> <td>2</td> <td>???.???</td> </tr> <tr> <td>3</td> <td>CU_S_126</td> <td>1</td> <td>SIEMENS telegram 390, PZD-2/2</td> <td>2</td> <td>???.???</td> <td>2</td> <td>???.???</td> </tr> </tbody> </table>	Object	Drive object	-No.	Message frame type	Input data Length	Input data Address	Output data Length	Output data Address	1	SERVO_02	2	Standard telegram 1, PZD-2/2	2	256..259	2	256..259	2	SERVO_03	3	Standard telegram 1, PZD-2/2	2	???.???	2	???.???	3	CU_S_126	1	SIEMENS telegram 390, PZD-2/2	2	???.???	2	???.???
Object	Drive object	-No.	Message frame type	Input data Length	Input data Address	Output data Length	Output data Address																										
1	SERVO_02	2	Standard telegram 1, PZD-2/2	2	256..259	2	256..259																										
2	SERVO_03	3	Standard telegram 1, PZD-2/2	2	???.???	2	???.???																										
3	CU_S_126	1	SIEMENS telegram 390, PZD-2/2	2	???.???	2	???.???																										
11.	<p>For activating the drive internal safety functions <i>PROFIsafe telegram 30</i> (<i>PZD-3/3</i>) is used. Select SERVO_02 respectively SERVO_03 and insert the telegram via <i>Adapt message frame configuration > Add PROFIsafe</i>.</p>  <p>The screenshot shows the 'Message frame configuration' dialog with the following table:</p> <table border="1"> <thead> <tr> <th>Object</th> <th>Drive object</th> <th>-No.</th> <th>Message frame type</th> <th>Input data Length</th> <th>Input data Address</th> <th>Output data Length</th> <th>Output data Address</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>SERVO_02</td> <td>2</td> <td>PROFIsafe standard telegram 30, PZD-3/3</td> <td>3</td> <td>-1..4</td> <td>3</td> <td>-1..4</td> </tr> <tr> <td>2</td> <td>SERVO_03</td> <td>3</td> <td>Standard telegram 1, PZD-2/2</td> <td>2</td> <td>256..259</td> <td>2</td> <td>256..259</td> </tr> <tr> <td>3</td> <td>CU_S_126</td> <td>1</td> <td>SIEMENS telegram 390, PZD-2/2</td> <td>2</td> <td>???.???</td> <td>2</td> <td>???.???</td> </tr> </tbody> </table>	Object	Drive object	-No.	Message frame type	Input data Length	Input data Address	Output data Length	Output data Address	1	SERVO_02	2	PROFIsafe standard telegram 30, PZD-3/3	3	-1..4	3	-1..4	2	SERVO_03	3	Standard telegram 1, PZD-2/2	2	256..259	2	256..259	3	CU_S_126	1	SIEMENS telegram 390, PZD-2/2	2	???.???	2	???.???
Object	Drive object	-No.	Message frame type	Input data Length	Input data Address	Output data Length	Output data Address																										
1	SERVO_02	2	PROFIsafe standard telegram 30, PZD-3/3	3	-1..4	3	-1..4																										
2	SERVO_03	3	Standard telegram 1, PZD-2/2	2	256..259	2	256..259																										
3	CU_S_126	1	SIEMENS telegram 390, PZD-2/2	2	???.???	2	???.???																										

4 Configuration

4.4 Configuring the distributed SINAMICS drive

No.	Action																																												
12.	<p>Afterwards adapt the message frame configuration with HW Config. The correct adaption with HW Config is signaled through blue check marks behind the telegrams.</p>  <p>The screenshot shows the 'Message frame configuration' window in the STARDER software. The window title is 'STARDER - S_Dev - [SINAMICS-S120-CBE20 - Message frame configuration]'. The main area displays the configuration for PROFIdrive and PZD message frames. The communication interface is set to 'PROFINET - COMM BOARD (isochronous)'. The input data corresponds to the send and the output data of the receive direction of the drive object. The 'Master view' table is as follows:</p> <table border="1" data-bbox="531 645 1114 745"> <thead> <tr> <th rowspan="2">Object</th> <th rowspan="2">Drive object</th> <th rowspan="2">No.</th> <th rowspan="2">Message frame type</th> <th colspan="2">Input data</th> <th colspan="2">Output data</th> </tr> <tr> <th>Length</th> <th>Address</th> <th>Length</th> <th>Address</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>SERVO_02</td> <td>2</td> <td>PROFIsafe standard telegram 30, PZD-</td> <td>3</td> <td>0..5</td> <td>3</td> <td>0..5</td> </tr> <tr> <td></td> <td></td> <td></td> <td>Standard telegram 1, PZD-2/2</td> <td>2</td> <td>256..259</td> <td>2</td> <td>256..259</td> </tr> <tr> <td>2</td> <td>SERVO_03</td> <td>3</td> <td>PROFIsafe standard telegram 30, PZD-</td> <td>3</td> <td>6..11</td> <td>3</td> <td>6..11</td> </tr> <tr> <td></td> <td></td> <td></td> <td>Standard telegram 1, PZD-2/2</td> <td>2</td> <td>260..263</td> <td>2</td> <td>260..263</td> </tr> </tbody> </table> <p>At the bottom of the window, there are buttons for 'Adapt message frame configuration', 'Interconnections/diagnostics', 'Align message frame with HW Config', and 'Set up addresses'. The 'Set up addresses' button is highlighted with a red box. The status bar at the bottom indicates 'Offline mode'.</p>	Object	Drive object	No.	Message frame type	Input data		Output data		Length	Address	Length	Address	1	SERVO_02	2	PROFIsafe standard telegram 30, PZD-	3	0..5	3	0..5				Standard telegram 1, PZD-2/2	2	256..259	2	256..259	2	SERVO_03	3	PROFIsafe standard telegram 30, PZD-	3	6..11	3	6..11				Standard telegram 1, PZD-2/2	2	260..263	2	260..263
Object	Drive object					No.	Message frame type	Input data		Output data																																			
		Length	Address	Length	Address																																								
1	SERVO_02	2	PROFIsafe standard telegram 30, PZD-	3	0..5	3	0..5																																						
			Standard telegram 1, PZD-2/2	2	256..259	2	256..259																																						
2	SERVO_03	3	PROFIsafe standard telegram 30, PZD-	3	6..11	3	6..11																																						
			Standard telegram 1, PZD-2/2	2	260..263	2	260..263																																						
13.	<p>Save the settings of the project and exit afterwards the STARDER engineering system.</p> 																																												

NOTE

To ensure the **Shared Device** functionality the following telegram order has to be followed!



First of all create the telegrams of all SERVOS, then the telegram for the infeed (when needed) and afterwards the telegram for the Control Unit.

4.5 HW Config of the distributed SINAMICS drive as Shared Device

4.5 HW Config of the distributed SINAMICS drive as Shared Device


After the SINAMICS drive is successfully configured and compiled it can be copied in the HW Config (right mouse button → *Copy*) and inserted as **Shared Device** in the HW Config of the second IO-Controller.

Table 4-5




No.	Action
1.	<p>Open the HW Config of the Standard-CPU and copy the SINAMICS drive.</p> 
2.	<p>Insert the SINAMICS drive as Shared Device in the HW Config of the F-CPU by marking the Ethernet subnet and clicking with the right mouse button → <i>Paste Shared</i>.</p> 

4 Configuration

4.5 HW Config of the distributed SINAMICS drive as Shared Device

No.	Action																								
3.	<p>There are two ways to set the access to the individual submodules (e.g. PROFIsafe telegram 30) (see also No. 4).</p> <p>The F-CPU needs full access to both PROFIsafe telegrams.</p> <p>Mark the relevant submodule → Right mouse button → <i>Change Access</i> → <i>Full Access</i>.</p> <p>On the other IO-Controller, the access modes are automatically adjusted!</p>																								
4.	<p>Alternatively, you can select the access mode for the individual submodules station-wide by double-clicking the station under the <i>Access</i> tab.</p> <p>The figure shows the HW Config for the SIMATIC CPU 317F-2 PN/DP.</p>  <p>The screenshot shows the 'Access' tab of the 'Properties - SINAMICS-S120-CBE20' dialog. It features a tree view on the left and a table on the right. The tree view shows the following structure:</p> <ul style="list-style-type: none"> Slot / Name [0] SINAMICS-S120-CBE20 <ul style="list-style-type: none"> (1) SERVO_02 <ul style="list-style-type: none"> (1.1) Module access point (1.2) PROFIsafe message frame (1.3) Standard message frame 1 (2) SERVO_03 <ul style="list-style-type: none"> (2.1) Module access point (2.2) PROFIsafe message frame (2.3) Standard message frame 1 (3) CU_S_126 <p>The table below shows the access modes for different IO-controllers:</p> <table border="1" data-bbox="352 1171 1051 1364"> <thead> <tr> <th>IO-controller name:</th> <th>IO system</th> <th>Station</th> <th>Access</th> </tr> </thead> <tbody> <tr> <td>F-CPU</td> <td>PROFINET-IO-System (100)</td> <td>F-CPU</td> <td>...</td> </tr> <tr> <td>Standard-CPU</td> <td>PROFINET-IO-System (100)</td> <td>Standard-CPU</td> <td>Full</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>On the other IO-Controller, the access modes are automatically adjusted!</p>	IO-controller name:	IO system	Station	Access	F-CPU	PROFINET-IO-System (100)	F-CPU	...	Standard-CPU	PROFINET-IO-System (100)	Standard-CPU	Full												
IO-controller name:	IO system	Station	Access																						
F-CPU	PROFINET-IO-System (100)	F-CPU	...																						
Standard-CPU	PROFINET-IO-System (100)	Standard-CPU	Full																						

4.5 HW Config of the distributed SINAMICS drive as Shared Device

No.	Action														
5.	<p>Double-click the PROFIsafe telegram 30 to open the properties screen.</p> <p>Under the <i>Addresses</i> tab, the logic addresses are defined to activate the drive internal safety functions.</p> <p>The <i>F_Des_Add</i> is later required for the drive configuration.</p> <p>The following addresses are used in the sample project.</p> <table border="1" data-bbox="316 539 1355 696"> <thead> <tr> <th rowspan="2">Axis</th> <th colspan="2">Logic address (addresses)</th> <th rowspan="2">F_Dest_Add</th> </tr> <tr> <th>Inputs</th> <th>Outputs</th> </tr> </thead> <tbody> <tr> <td>SERVO_02 (red)</td> <td>Byte 15...20</td> <td>Byte 15...20</td> <td>C5_{hex}</td> </tr> <tr> <td>SERVO_03 (blue)</td> <td>Byte 21...26</td> <td>Byte 21...26</td> <td>C6_{hex}</td> </tr> </tbody> </table>   <p>When activating the drive internal safety functions via PROFIsafe, the set <i>F_Dest_Add</i> (hex) must correspond to the PROFIsafe address in the STARTER (see Section 4.8, No. 2).</p>	Axis	Logic address (addresses)		F_Dest_Add	Inputs	Outputs	SERVO_02 (red)	Byte 15...20	Byte 15...20	C5 _{hex}	SERVO_03 (blue)	Byte 21...26	Byte 21...26	C6 _{hex}
Axis	Logic address (addresses)		F_Dest_Add												
	Inputs	Outputs													
SERVO_02 (red)	Byte 15...20	Byte 15...20	C5 _{hex}												
SERVO_03 (blue)	Byte 21...26	Byte 21...26	C6 _{hex}												
6.	<p>Save and compile the HW Config of the F-CPU as well as the HW Config of the Standard-CPU. The project afterwards is consistent.</p> 														

NOTE

PROFIsafe telegrams can only be assigned to the F-CPU!


Changes in the STARTER engineering system can only be done if they have no effect on the telegram structure, after the configured SINAMICS drive is inserted in the HW Config of the F-CPU as **Shared Device**. Changing the telegrams (type of telegram, etc.) is not possible anymore!

Therefor you have change the access of all telegrams in the HW Config of the Standard-CPU to *Full Access*. Delete the SINAMICS drive in the HW Config of the F-CPU and save both stations. Afterwards you can adapt the telegrams again.

After adapting the telegrams the SINAMICS drive has to be inserted in the HW Config of the F-CPU again as **Shared Device**.

4.6 Configuring the SINAMICS drive as Shared Device

Table 4-6

No.	Action
1.	<p>If the drive shall act as Shared Device, set the parameter p8829 (only with CBE20) in the Control Unit CU320-2 DP to 2 = <i>“Automation and Safety”</i>. For this, the parameter p9 must be set to 1 = <i>“Device configuration”</i>.</p>  <p>Note On the CU320-2 PN, the parameter p8929 for the onboard PN interface X150 must be set to 2 = <i>“Automation and Safety”</i>.</p>

4.7 Activating the drive internal safety functions

In order to activate the drive internal safety functions, the safety training case includes a switchbox with a emergency OFF switch -S1, two rotary switches -S2 and -S3, as well as a switch -S4. These switches are connected to the failsafe input module *SM 326F DI24xDC24V*.

The application example uses a FC1 (F-CALL) which is called in the OB35 (50 ms). The FC1 defines the F-runtime group in which the FB1 (F-Program) is called up. The FB1 includes the safety program and is described in the following.

The comment in the safety program refers to the following axes.







Table 4-7

Comment	Axis
Drive 1	SERVO_02 (red)
Drive 2	SERVO_03 (blue)

Table 4-8

No.	Action
1.	<p>Block: FB1 Failsafe PLC program</p> <p>This program mainly forwards the signals received at the F-DI module to the PROFIsafe telegram.</p> <hr/> <p>Network: 1 1=ACKNOWLEDGEMENT NECESSARY</p> <p>With the setting of ACK_NEC=0 the reintegration will be done automatically (exception communication faults).</p> <div style="display: flex; justify-content: space-between; align-items: flex-start; margin-top: 20px;"> <div style="width: 30%;"> <p>DB1091.DBX 36.3 FALSE "F" GLOBDB" VKE0</p> </div> <div style="width: 30%; text-align: center;"> <p>&</p> </div> <div style="width: 30%;"> <p>DB1092.DBX 0.1 1=ACKNOWLE DGEMENT NECESSARY "F00000 FDI24xDC24 V".ACK NEC = DB1093.DBX 0.1 1=ACKNOWLE DGEMENT NECESSARY "F00010 FDO8xDC24V 2A". ACK NEC =</p> </div> </div> <p>The failsafe modules <i>SM 326F DI24xDC24V</i> and <i>SM 326F DO8xDC24V/2A</i> are automatically deenergized by the setting <code>ACK_NEC = 0</code>.</p>

4.7 Activating the drive internal safety functions







No.	Action
2.	<p>Network: 2 PROFIsafe drive 1 STO</p> <p>With safe VKEl, STO at drive 1 is deactivated permanently.</p>
	
	<p>Network: 3 PROFIsafe drive 1 SS1</p> <p>Activate SS1 at drive 1 with e-stop -S1.</p>
	
	<p>Network: 4 PROFIsafe drive 1 SS2</p> <p>With safe VKEl, SS2 at drive 1 is deactivated permanently.</p>
	
	<p>Network: 5 PROFIsafe drive 1 SOS</p> <p>Activate SOS at drive 1 with -S2. Inverting is necessary because -S2 will be handled as NO (normally open) contact.</p>
	
	<p>Network: 6 PROFIsafe drive 1 SLS</p> <p>With safe VKEl, SLS at drive 1 is deactivated permanently.</p>
	
	<p>Network: 7 PROFIsafe drive 1 acknowledgement</p> <p>Acknowledgement of drive 1 with -S4.</p>
	
	<p>The drive internal safety functions are activated via the PROFIsafe control word.</p> <ul style="list-style-type: none"> • Bit 1 (SS1) is connected to the digital input E0.0 (emergency OFF switch -S1). • Bit 3 (SOS) is connected to the digital input E0.1 (protective door -S2, inverted). • Bit 7 (ACK) is connected to the digital input E0.3 (acknowledgement button). <p>The bits for the unused safety functions require a failsafe high signal.</p>

4 Configuration

4.7 Activating the drive internal safety functions

No.	Action
3.	<div data-bbox="316 304 1209 376" style="border: 1px solid black; padding: 2px;"> <p>Network: 8 PROFIsafe drive 1 SLS velocity step Bit 0</p> <p>With safe VKE0, SLS velocity step Bit 0 is activate permanently.</p> </div> <div data-bbox="331 394 724 539" style="margin-top: 10px;"> </div> <div data-bbox="316 618 1209 689" style="border: 1px solid black; padding: 2px; margin-top: 10px;"> <p>Network: 9 PROFIsafe drive 1 SLS velocity step Bit 1</p> <p>With safe VKE0, SLS velocity step Bit 1 is activate permanently.</p> </div> <div data-bbox="331 707 724 853" style="margin-top: 10px;"> </div> <p data-bbox="316 931 1337 987" style="margin-top: 10px;">The speed level for the safety function SLS is controlled by the bits 9 and 10 in the PROFIsafe control word.</p> <p data-bbox="316 994 1337 1050" style="margin-top: 5px;">As the bit 4 (SLS) is connected to the failsafe high signal, the safety function SLS is not used at the red axis. The connection of these two bits has therefore no importance.</p> <p data-bbox="316 1084 1337 1140" style="margin-top: 10px;">The remaining outputs for the PROFIsafe control word (S_STW1) are reserved and need not be connected.</p>




4.7 Activating the drive internal safety functions

No.	Action
4.	<p>Network: 10 PROFIsafe drive 2 STO</p> <p>Activate STO at drive 2 with e-stop -S1.</p>
	
	<p>Network: 11 PROFIsafe drive 2 SS1</p> <p>With safe VKE1, SS1 at drive 2 is deactivated permanently.</p>
	
	<p>Network: 12 PROFIsafe drive 2 SS2</p> <p>With safe VKE1, SS2 at drive 2 is deactivated permanently.</p>
	
	<p>Network: 13 PROFIsafe drive 2 SOS</p> <p>With safe VKE1, SOS at drive 2 is deactivated permanently.</p>
	
	<p>Network: 14 PROFIsafe drive 2 SLS</p> <p>Activate SLS at drive 2 with -S3.</p>
	
	<p>Network: 15 PROFIsafe drive 2 acknowledgement</p> <p>Acknowledgement of drive 2 with -S4.</p>
	
	<p>The drive internal safety functions are activated via the PROFIsafe control word.</p> <ul style="list-style-type: none"> • Bit 0 (STO) is connected to the digital input E0.0 (emergency OFF switch -S1). • Bit 4 (SLS) is connected to the digital input E0.2 (protective door -S3). • Bit 7 (ACK) is connected to the digital input E0.3 (acknowledgement button). <p>The bits for the unused safety functions require a failsafe high signal.</p>

4 Configuration

4.7 Activating the drive internal safety functions

No.	Action
5.	<div data-bbox="316 304 1209 376" style="border: 1px solid black; padding: 2px;"> Network: 16 PROFIsafe drive 2 SLS velocity step Bit 0 With safe VKE0, SLS velocity step Bit 0 is activate permanently. </div> <div data-bbox="331 394 734 542" style="margin-top: 10px;"> </div> <div data-bbox="316 613 1209 685" style="border: 1px solid black; padding: 2px; margin-top: 20px;"> Network: 17 PROFIsafe drive 2 SLS velocity step Bit 1 With safe VKE0, SLS velocity step Bit 1 is activate permanently. </div> <div data-bbox="331 703 734 851" style="margin-top: 10px;"> </div> <p data-bbox="316 887 1321 936">The speed level for the safety function SLS is actuated via these bits in the PROFIsafe control word.</p> <ul data-bbox="316 945 1321 1070" style="list-style-type: none"> • Bit 9 (SLS speed level bit 0) is connected to the failsafe zero signal. • Bit 10 (SLS speed level bit 1) is connected to the failsafe zero signal. <p data-bbox="316 1012 1321 1070">→ Speed level 1 is thus always selected (see the following figure showing the safety function SLS).</p> <div data-bbox="316 1111 1295 1550" style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> </div> <p data-bbox="316 1585 1340 1644">The remaining outputs for the PROFIsafe control word (S_STW1) are reserved and need not be connected.</p>
6.	<div data-bbox="316 1659 1219 1731" style="border: 1px solid black; padding: 2px;"> Network: 18 Activate lamp in switch -S4 Lamp in -S4 is switched on, if internal event on any drive is high. </div> <div data-bbox="395 1749 734 1830" style="margin-top: 10px;"> </div> <p data-bbox="316 1865 1283 1897">The signal lamp -S4 lights up when a safety fault occurs which needs to be acknowledged.</p>


No.	Action																																																																	
7.	<p>Network: 19 Reintegration of all F-Slaves</p> <p>This function block is used to reintegrate (acknowledge) all PROFIsafe-Slaves after an error.</p>  <p>Press the switch -S4 to depassivate all PROFIsafe slaves (F-Slaves, F-Devices).</p>																																																																	
8.	<p>Define the F-runtime group. Open the runtime group via <i>Options</i> → <i>Edit safety program</i> → <i>F-Runtime groups...</i></p> 																																																																	
9.	<p>Compile the safety program and load it into the controller.</p>  <table border="1" data-bbox="327 1489 1029 1803"> <thead> <tr> <th>F-runtime/F-block</th> <th>Symb. name</th> <th>Function in safety program</th> <th>Signature</th> <th>Know-how p</th> </tr> </thead> <tbody> <tr> <td colspan="5">Safety program</td> </tr> <tr> <td colspan="5">F-runtime group FC1</td> </tr> <tr> <td colspan="5">F I/O DBs</td> </tr> <tr> <td>DB1092</td> <td>F00000_FD12...</td> <td>F I/O DB</td> <td>1468</td> <td>☑</td> </tr> <tr> <td>DB1093</td> <td>F00010_FDO...</td> <td>F I/O DB</td> <td>9761</td> <td>☑</td> </tr> <tr> <td>DB1096</td> <td>F00021_PRO...</td> <td>F I/O DB</td> <td>3939</td> <td>☑</td> </tr> <tr> <td>DB1097</td> <td>F00015_PRO...</td> <td>F I/O DB</td> <td>7FEA</td> <td>☑</td> </tr> <tr> <td>FC1</td> <td></td> <td>F-CALL</td> <td>70EC</td> <td>☑</td> </tr> <tr> <td>FB1</td> <td></td> <td>F-program block</td> <td>FEC3</td> <td>☐</td> </tr> <tr> <td>FB219</td> <td>F_ACK_GL</td> <td>F application block</td> <td>8B12</td> <td>☑</td> </tr> <tr> <td>DB1</td> <td></td> <td>I-DB for F-program block</td> <td>F2DE</td> <td>☑</td> </tr> <tr> <td colspan="5">All Objects</td> </tr> </tbody> </table>	F-runtime/F-block	Symb. name	Function in safety program	Signature	Know-how p	Safety program					F-runtime group FC1					F I/O DBs					DB1092	F00000_FD12...	F I/O DB	1468	☑	DB1093	F00010_FDO...	F I/O DB	9761	☑	DB1096	F00021_PRO...	F I/O DB	3939	☑	DB1097	F00015_PRO...	F I/O DB	7FEA	☑	FC1		F-CALL	70EC	☑	FB1		F-program block	FEC3	☐	FB219	F_ACK_GL	F application block	8B12	☑	DB1		I-DB for F-program block	F2DE	☑	All Objects				
F-runtime/F-block	Symb. name	Function in safety program	Signature	Know-how p																																																														
Safety program																																																																		
F-runtime group FC1																																																																		
F I/O DBs																																																																		
DB1092	F00000_FD12...	F I/O DB	1468	☑																																																														
DB1093	F00010_FDO...	F I/O DB	9761	☑																																																														
DB1096	F00021_PRO...	F I/O DB	3939	☑																																																														
DB1097	F00015_PRO...	F I/O DB	7FEA	☑																																																														
FC1		F-CALL	70EC	☑																																																														
FB1		F-program block	FEC3	☐																																																														
FB219	F_ACK_GL	F application block	8B12	☑																																																														
DB1		I-DB for F-program block	F2DE	☑																																																														
All Objects																																																																		

4.8 Configuring the drive internal safety functions



It is assumed that the SINAMICS drive has been commissioned and the axes can be traversed via the control panel. The drive internal safety functions can be configured online or offline.

Table 4-9

No.	Action
1.	<p>Select “Extended functions” to activate the extended safety functions. If the safety functions are activated via PROFINET (or PROFIBUS), “via PROFIsafe” must be selected. → “Extended functions via PROFIsafe” In the sample project, all safety axes have an encoder. → “Safety with encoder and accel_monitoring(SAM) / delay time” Activate the safety functions → “Safety functions = Enable”</p>




4.8 Configuring the drive internal safety functions

No.	Action						
2.	<p>Perform the PROFIsafe configuration in the <i>Configuration</i> screen.</p>  <p>Select the axis type rotational axis.</p> <p>When activating the safety functions via PROFIsafe, the PROFIsafe address must correspond to the set <i>F_Dest_Add</i> (hex) in the HW Config (see Section 4.5, No. 5).</p>  <p>The following PROFIsafe addresses are used in the sample project.</p> <table border="1" data-bbox="316 1624 986 1747"> <thead> <tr> <th>Axis</th> <th>PROFIsafe address (<i>F_Dest_Add</i>)</th> </tr> </thead> <tbody> <tr> <td>SERVO_02 (red)</td> <td>C5_{hex}</td> </tr> <tr> <td>SERVO_03 (blue)</td> <td>C6_{hex}</td> </tr> </tbody> </table> <p>Note The functionality Test stop is not configured in the sample project.</p>	Axis	PROFIsafe address (<i>F_Dest_Add</i>)	SERVO_02 (red)	C5 _{hex}	SERVO_03 (blue)	C6 _{hex}
Axis	PROFIsafe address (<i>F_Dest_Add</i>)						
SERVO_02 (red)	C5 _{hex}						
SERVO_03 (blue)	C6 _{hex}						

4 Configuration

4.8 Configuring the drive internal safety functions

3. In the sample project, the safety function **SS1** is selected at the red axis (SERVO_02) by actuating the emergency OFF switch -S1. That means, this axis actively decelerates to the speed 0 rpm. Afterwards, the releases are canceled.




In the sample project, the standstill of the red axis (SERVO_02) is monitored (**SOS**) when the protective door -S2 is opened. Before, the Standard-CPU must specify a command speed of 0 rpm by setting the marker *M0.1 "boSafetyDoor"*. That means if the marker *M0.1 "boSafetyDoor"* is set, the blue axis must stop instead of rotating at ~187 rpm. When actuating the protective door -S2, no safety alarm may occur.

If the marker *M0.1 "boSafetyDoor"* is not set, the safety alarms "STOP B triggered" and "STOP A triggered" are output by the CU and the red axis (SERVO_02) by the Motor Module when actuating the switch -S2 and upon expiry of a parameterizable delay time.

The delay time "SOS → SOS active" can be parameterized according to the respective requirement.


After closing the protective door -S2 resp. setting the marker *M0.1 "boSafetyDoor"* (command speed = 0 rpm), the alarms can be acknowledged with the switch -S4. After acknowledging the alarms, the drives continue running if the marker *M0.0 "boMove"* is set in the Standard-CPU.






4.8 Configuring the drive internal safety functions

No.	Action
4.	<p>In the sample project, STO is selected at the blue axis (SERVO_03) when actuating the emergency OFF switch -S1, that means the axis coasts down. The releases are immediately canceled.</p> 

4 Configuration

4.8 Configuring the drive internal safety functions

No.	Action
5.	<p>In the sample project, the speed of the blue axis (SERVO_03) is monitored (SLS) when opening the protective door -S3. Before, the Standard-CPU must specify a command speed of less than 100 rpm by setting the marker <i>M0.1 "boSafetyDoor"</i>. That means if the marker <i>M0.1 "boSafetyDoor"</i> is set, a command speed of ~93 rpm is specified in the sample project. When actuating the protective door -S3, no safety alarm may be output.</p> <p>If the marker <i>M0.1 "boSafetyDoor"</i> is <u>not</u> set, the safety alarms "STOP B triggered" and "STOP A triggered" are output after actuating the switch -S3 and upon expiry of a parameterizable delay time.</p> <p>After closing the protective door -S3 resp. setting the marker <i>M0.1 "boSafetyDoor"</i> (command speed lower than 100 rpm), the alarms can be acknowledged with the switch -S4. After acknowledging the alarms, the drives continue running if the marker <i>M0.0 "boMove"</i> is set in the Standard-CPU.</p> <p>As in the sample project the bits 9 and 10 in the PROFIsafe control word (S_STW1) for the blue axis are connected to the failsafe zero signal, the speed level 1 is always selected for SLS. Thus, you only have to configure the speed level 1 in the sample project.</p>
	
	<pre> Network: 4 Transmit STW (Bit Master control by PLC) drive 2 (blue motor) U "boMove" SPEN S011 L W#16#47E // = 2#0100_0111_1110 T MW 1 L W#16#1FF // 511 = 6000 rpm * 511/16384 = 187,13 rpm U "boSafetyDoor" SPEN S014 L W#16#FF // = 93,38 rpm < 100 rpm for SLS S014: T AW 262 UN E 264.0 //restart inhibit U(L EW 260 L W#16#211 // = 2#0010_0001_0001 UW L W#16#211 ==I) SPEN S012 L W#16#47F // = 2#0100_0111_1111 T MW 1 S012: L MW 1 T AW 260 SPA S013 S011: L W#16#400 // = 2#0100_0000_0000 T AW 260 </pre>

No.	Action
6.	<p>If the configuration has been performed offline, checkmark "Copy Parameter", save the project and perform a download.</p> <p>If the configuration has been performed online, copy the parameters and activate them for both axes.</p>
7.	<p>Copy RAM to ROM.</p> 
8.	<p>Go offline.</p> 
9.	<p>Power OFF/ON</p>
10.	<p>Go online.</p> 
11.	<p>Load the drive configuration into the PG.</p> 
12.	<p>Save the project.</p>  <p>The offline and online configurations are now consistent.</p>

4.9 Configuring the distributed SIMATIC ET 200 Station

The following firmware versions of the SIMATIC ET 200 Station support the PROFINET functionality **Shared Device**.

Table 4-10: Necessary firmware versions for SIMATIC ET 200

Hardware	Version
ET 200M	As from V3.0
ET 200S (not High Speed version)	As from V7.0
ET 200S HS	As from V3.0
ET 200pro	As from V7.0


Table 4-11

No.	Action									
1.	<p>Drag the required SIMATIC ET 200 Station from the hardware catalog to the PROFINET IO system. In the detailed screen, you can insert the required electronic modules. The sample project uses an ET 200S HF V7.0, a power module and two digital output modules. Each digital output module is assigned to an IO-Controller. For this, you must insert the SIMATIC ET 200 Station as Shared Device at the second PROFINET IO-Controller.</p>									
2.	<p>In the sample project, the OB33 “Cyclic Interrupt“ is called up every 500 ms. In the OB33, the output byte 0 (Slot 2 → 4DO DC24V/2A ST) is incremented in each cycle by 1. That means the LEDs of the respective digital outputs graphically display incrementing as soon as the Standard-CPU is in the RUN state. This allows to show the Shared Device functionality by switching both CPUs alternately to STOP.</p> <p><u>Standard-CPU, OB33 (500 ms), network 1:</u></p> <table border="1"> <tbody> <tr> <td>L</td> <td>AB</td> <td>0</td> </tr> <tr> <td>INC</td> <td>1</td> <td></td> </tr> <tr> <td>T</td> <td>AB</td> <td>0</td> </tr> </tbody> </table>	L	AB	0	INC	1		T	AB	0
L	AB	0								
INC	1									
T	AB	0								

4.10 Configuring the SIMATIC ET 200 Station as Shared Device

Note Proceed as follows to connect a SIMATIC ET 200 Station as **Shared Device** to a SIMOTION controller.


Table 4-12

No.	Action																																
1.	<p>After configuring and successfully compiling the SIMATIC ET 200 Station it can be copied in the HW Config (right mouse button → <i>Copy</i>) and inserted as Shared Device at the second IO-Controller.</p>  <p>The screenshot shows the HW Config window for a SIMATIC ET 200 station. A context menu is open over the rack configuration, with the 'Copy' option highlighted in red. The rack configuration shows slot 0 containing an IM151-3 module, and slots 1-4 containing PM-E DC24V modules. A table at the bottom right shows the address and access rights for the modules.</p> <table border="1"> <thead> <tr> <th>Address</th> <th>Diagno...</th> <th>C...</th> <th>Access</th> </tr> </thead> <tbody> <tr> <td>2030*</td> <td></td> <td></td> <td>Full</td> </tr> <tr> <td>2029*</td> <td></td> <td></td> <td>Full</td> </tr> <tr> <td>2032*</td> <td></td> <td></td> <td>Full</td> </tr> <tr> <td>2031*</td> <td></td> <td></td> <td>Full</td> </tr> <tr> <td>2028*</td> <td></td> <td></td> <td>Full</td> </tr> <tr> <td>0.3</td> <td></td> <td></td> <td>Full</td> </tr> <tr> <td></td> <td></td> <td></td> <td>...</td> </tr> </tbody> </table>	Address	Diagno...	C...	Access	2030*			Full	2029*			Full	2032*			Full	2031*			Full	2028*			Full	0.3			Full				...
Address	Diagno...	C...	Access																														
2030*			Full																														
2029*			Full																														
2032*			Full																														
2031*			Full																														
2028*			Full																														
0.3			Full																														
			...																														

4 Configuration


4.10 Configuring the SIMATIC ET 200 Station as Shared Device

No.	Action
2.	<p>Insert the SIMATIC ET 200 Station as Shared Device in the HW Config of the second IO-Controller by marking the Ethernet subnet and clicking with the right mouse button → <i>Paste Shared</i>. For this, the HW Config of the first IO-Controller must have been successfully compiled. In the sample project, the SIMATIC ET 200S Station is inserted as Shared Device at the SIMATIC CPU 317F-2 PN/DP. Both controllers must be located in the same project.</p>



The screenshot shows the SIMATIC Manager HW Config interface. The main window is titled "HW Config - [F-CPU (Configuration) -- S_Dev]". The rack configuration shows a CPU 317F-2 PN/DP at slot 2. A context menu is open over the Ethernet subnet, with "Paste Shared" highlighted in red. Below the rack, a table lists the device details:

D...	IP address ...	Device Name	Order num
1	192.168.0.3	SINAMICS-S120-CBE20	6SL3 040-

No.	Action
3.	<p>To assign individual modules to a PROFINET IO-Controller, mark the respective module → Right mouse button → <i>Change Access</i> and select the requested function. The respective module access is automatically adjusted for the second IO-Controller.</p>  <p>The screenshot shows the HW Config software interface. A context menu is open over a module in the hardware rack. The 'Change Access' option is highlighted in red, and a sub-menu is open showing 'No Access' and 'Full Access' options. The hardware rack shows a CPU 317F-2 and several I/O modules. The context menu includes options like Copy, Paste, Replace Object..., Add Master System, Disconnect Master System, Master System Isochronous Mode, Insert PROFINET IO System, Disconnect PROFINET IO System, PROFINET IO Domain Management..., PROFINET IO Topology..., PROFINET IO Isochronous mode, Specify Module..., Delete, Go To, Filter Assigned Modules, Monitor/Modify, Edit Symbols..., Object Properties..., Clean Object With, Change Access, Assign Asset ID, Product Support Information, FAQs, Find Manual, and Start Device Tool.</p>
4.	<p>In the sample project, the OB33 “Cyclic Interrupt“ is called up every 500 ms. In the OB33, the output byte 4 (slot 3 → 4DO DC24V/2A ST) is incremented in each cycle by 1. That means the LEDs of the respective digital outputs graphically display incrementing as soon as the F-CPU is in the RUN state.</p> <p>This allows to show the Shared Device functionality by switching both CPUs alternately to STOP.</p> <p><u>F-CPU, OB33 (500 ms), network 1:</u></p> <pre> L AB 4 INC 1 T AB 4 </pre>

5 Startup of the application


5.1 Startup


5 Startup of the application

The following steps must be taken to startup the application.

5.1 Startup





Table 5-1

No.	Action
1.	All hardware components (see Table 2-1, Page 10) are provided and upgraded to the necessary firmware.
2.	All PROFINET components are interconnected and can be accessed via the engineering system.
3.	The Ethernet interface of the engineering system has been correctly configured. IP address: 192.168. 0 . 99 Subnetmask: 255.255.255. 0
4.	Start the STEP7 SIMATIC Manager engineering system.
5.	Dearchive the sample project "50207311_Example_Shared_Device_V2_0.zip".
6.	Open the S7 Project "S_Dev".
7.	Load the configuration of the Standard-CPU into the respective device.
8.	Load the configuration of the F-CPU into the respective device. The password for downloading / processing the safety program is "1".
9.	Open the HW Config to initiate the node.  <p>The screenshot shows the HW Config window for a Standard-CPU. The 'Ethernet' menu is open, and the 'Assign Device Name...' option is highlighted with a red box. The background shows a rack configuration with a CPU and various modules, and a list of modules on the right side.</p>
	Mark the PROFINET line and open the screen <i>Assign Device Name</i> .

No.	Action
10.	<p>Here, you can select the configured device name and assign it to the respective device (IO-Device).</p>  <p>Note Only IO-Devices are listed here. IO-Controllers are assigned the device name by downloading the HW Config.</p>
11.	<p>Alternatively, you can also use the Primary Setup Tool (PST) to initiate the node. The PST can be downloaded at the following link. http://support.automation.siemens.com/WW/view/en/19440762</p>

5 Startup of the application

5.1 Startup

No.	Action
12.	Start the STARTER engineering system.
13.	Go online. 
14.	Load the configuration of the SINAMICS drive into the respective device. The password for processing the safety functions is "1".
15.	Acknowledge the hardware replacement 
16.	Copy RAM to ROM. 
17.	Go offline. 
18.	Power OFF/ON
19.	The sample project can now be operated.

6 Operation of the application

6.1 Overview

On the one hand, the sample project is operated via the switch box of the safety training case, and on the other hand via the SIMATIC Manager used to modify markers.

The axis command speeds are permanently stored in the STEP7 standard program and can be selected via markers.

6.2 Distributed SIMATIC ET 200 Station as Shared Device

Testing the PROFINET Shared Device functionality

Each of the two output modules is assigned to another controller. As long as the assigned controller is in the RUN state, the LEDs of the respective output module show the incrementing of the corresponding output byte which is incremented by 1 in the OB33 (500 ms).

Table 6-1

No.	Action
1	Switch one of the two SIMATIC CPUs alternately to STOP and RUN. → In the STOP operating state, the LEDs of the corresponding output module are off.

6.3 Distributed SINAMICS drive as Shared Device

Testing the safety functions in the drive (Shared Device)


The standard functionality is assumed by the Standard-CPU, and the safety functions are activated by the F-CPU. The **Shared Device** functionality is used for this.

Table 6-2

No.	Action
1	Actuate the switch -S4 to depassivate all F-Devices.
2	Deselect all drive internal safety functions by unlocking the emergency OFF switch -S1 and closing both protective doors (-S2 and -S3).

6 Operation of the application

6.3 Distributed SINAMICS drive as Shared Device

No.	Action
3	<p>Open the OB1 in the Standard-CPU. Mark the <i>Modify</i> tab in the detailed screen and go online. Start both axes via the Standard-CPU with the marker <i>M0.0</i> "boMove" = TRUE. → Both axes must rotate at ~187 rpm, which corresponds to the command value $1FF_{hex} = 511$.</p>  <p>The command speeds for the red and blue axes are specified in the networks 1 and 2.</p>
5	<p>When actuating the emergency OFF switch, both axes must stop. Both axes are restarted when unlocking the emergency OFF switch and actuating the fault acknowledgement -S4.</p>
6	<p>If the marker <i>M0.1</i> "boSafetyDoor" is set, the protective doors 1 and 2 (-S2 and -S3) can be opened without triggering a safety fault. If the marker <i>M0.1</i> "boSafetyDoor" is not set, that means both drives rotate at ~187 rpm, a safety fault is triggered when opening the protective door 1 resp. 2 (-S2 resp. -S3).</p>

7 Contact

Siemens AG
Industry Sector
I DT MC PMA APC
Frauenauracher Straße 80
D - 91056 Erlangen
mailto: profinet.team.motioncontrol.i-dt@siemens.com

8 History

Table 8-1

Version	Date	Modifications
V1.1	07/2011	First version Configuring Shared Device via GSD file
V1.2	05/2012	Update
V2.0	05/2012	Configuring Shared Device via Object Manager