

Application Description • 12/2014

# Faceplates and Function Blocks for the Visualization of a SITOP UPS1600

WinCC flexible, WinCC (TIA Portal), WinCC

## Warranty and Liability

### Note

The Application Examples are not binding and do not claim to be complete with regard to configuration, equipment or any contingencies. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for the correct operation of the described products. These Application Examples do not relieve you of the responsibility of safely and professionally using, installing, operating and servicing equipment. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time and without prior notice. If there are any deviations between the recommendations provided in this Application Example and other Siemens publications – e.g. catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document.

Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this application example will be excluded. Such an exclusion will not apply in the case of mandatory liability, e.g. under the German Product Liability Act ("Produkthaftungsgesetz"), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract ("wesentliche Vertragspflichten"). The compensation for damages due to a breach of a fundamental contractual obligation is, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change in the burden of proof to your disadvantage.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of Siemens Industry Sector.

### Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit <http://www.siemens.com/industrialsecurity>.

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit <http://support.automation.siemens.com>.

# Table of Contents

<b>Warranty and Liability .....</b>	<b>2</b>
<b>1 Task .....</b>	<b>5</b>
<b>2 Structure .....</b>	<b>6</b>
2.1 Solution overview .....	6
2.2 Description of the core functionality .....	8
2.3 Hardware and software components used .....	9
<b>3 Function Blocks for the UPS1600 .....</b>	<b>11</b>
3.1 Function and task of the function block .....	11
3.1.1 Task description and application .....	11
3.1.2 Function description .....	11
3.2 Operating conditions .....	12
<b>4 Application of the Function Block under STEP 7 V5.5 .....</b>	<b>13</b>
4.1 Preconditions .....	13
4.2 Content of the library for STEP 7 V5.5 .....	13
4.3 Interfaces of the function block .....	16
4.4 Data block DB161 .....	17
4.5 Integrating the function block .....	19
<b>5 Application of the Function Block under STEP 7 V12 .....</b>	<b>29</b>
5.1 Preconditions .....	29
5.2 Content of the library for STEP 7 V12 .....	29
5.3 Interfaces of the function block FB160 .....	33
5.4 Data block DB161 .....	35
5.5 Integrating the function block .....	37
5.5.1 Procedure when using an S7-300/400 .....	37
5.5.2 Procedure when using an S7-1200/1500 .....	49
<b>6 Faceplates for the UPS1600 .....</b>	<b>60</b>
6.1 Faceplate "Faceplate_UPS1600_State" .....	60
6.2 Faceplate "Faceplate_UPS1600" .....	62
6.2.1 "State" tab .....	63
6.2.2 "Trends" tab .....	66
6.2.3 "Alarms" tab .....	67
<b>7 Application of the Faceplates in WinCC flexible .....</b>	<b>68</b>
7.1 Preconditions .....	68
7.2 Library for WinCC flexible .....	69
7.3 Integrating the faceplates .....	70
7.4 Interface description .....	77
<b>8 Application of the Faceplates in WinCC Comfort/Advanced V12 .....</b>	<b>82</b>
8.1 Preconditions .....	82
8.2 Library for WinCC Comfort/Advanced .....	83
8.3 Integrating the faceplates .....	84
8.4 Interface description .....	94
<b>9 Application of the Screen Windows in WinCC V7.2 .....</b>	<b>99</b>
9.1 Preconditions .....	99
9.2 Library for WinCC V7.2 .....	99
9.3 Integrating the screen windows .....	100
9.4 Interface description .....	110

## Table of Contents

---


<b>10</b>	<b>Application of the Faceplates in WinCC Professional V12.....</b>	<b>114</b>
10.1	Preconditions .....	114
10.2	Library for WinCC Professional .....	114
10.3	Integrating the screen windows .....	116
10.4	Interface description.....	128
	Internal tag .....	128
<b>11</b>	<b>Related Literature .....</b>	<b>131</b>
<b>12</b>	<b>History .....</b>	<b>131</b>

# 1 Task

## Overview of the automation task

The figure below provides an overview of the automation task.

Figure 1-1



## Description of the automation task

Your task is to equip your automation plant with uninterruptible power supply. In the event of a power failure, critical process participants are to be protected.

In the event of a power failure of the automation plant, process values are to be maintained and plant components be safeguarded against mechanical damage by means of a defined stop.

Uninterruptible power supply is to be communication-capable and integrated into the automation network via PROFINET.

The status and diagnostic information of the uninterruptible power supply is to be displayed in the individual HMI stations.


# 2 Structure

## 2.1 Solution overview

### Structure

The figure below shows a schematic overview of the most important components of the solution:

Figure 2-1



© Siemens AG 2014. All rights reserved

### Scope of this application example

This application example provides function blocks (FB160) for communication between the controller and SITOP UPS 1600.

Moreover, it provides faceplates and screen windows for monitoring and operation.

### Structure/function of the hardware components

Table 2-1

Name	Function
SITOP Power Supply	Central 24V power supply for all process devices
Non-critical process devices	Symbol for other uncritical process devices (which can, for example, be switched off such as a compressor if there is sufficient pressure)
SITOP UPS 1600 and SITOP UPS 1100	Uninterruptible power supply with buffer (e.g., battery module)
S7-1516	Automation controller
Comfort Panel TP1200	Control panel for process visualization

## 2 Structure

### 2.1 Solution overview

Name	Function
Other critical process devices	Symbol for other critical process devices
PROFINET	Central process bus of all automation devices

#### Advantages

This application offers the following advantages:

- Time and cost saving by means of provided function blocks (FB160) and HMI faceplates and screen windows.
- Easy and comprehensive introduction to the topic of integrating a SITOP UPS1600 within a PROFINET network.

#### Scope

This application does not include a description of

- the creation of program blocks in STEP7 V5 / STEP7 V12,
- the creation of screens and objects in WinCC flexible / WinCC TIA Portal / WinCC,
- the configuration of communication between the described terminal devices,
- the handling of all described SIMATIC terminal devices.

#### Assumed knowledge

The following knowledge is assumed:

- Knowledge of using STEP7 V5, STEP7 V12, WinCC flexible, WinCC, and WinCC TIA Portal.
- Knowledge of operating, handling, and configuring SIMATIC S7 controllers (S7-300/400; S7-1200/1500).
- Knowledge of operating, handling, and configuring HMI control panels (Multi Panels, Comfort Panels) and Runtime systems (WinCC flexible Runtime, WinCC Runtime Advanced, WinCC Runtime, WinCC Runtime Professional).
- Knowledge of handling and operating SITOP UPS1600.

## 2.2 Description of the core functionality

### Sequence of the core functionality


Communication between the UPS1600 and controller runs via PROFINET. The UPS1600 is connected with the controller as PROFINET IO node. Thus, the entire SITOP UPS1600 information (voltage, power, possible buffer time, battery state) is available in the controller.

In this application example, two scenarios are thus realized.

- Upon occurrence of a power failure, this is recognized by the PLC. Via the supplied program block FB160, this information is available in the control program and can be evaluated. This allows your process to respond and switch off your process devices in a defined manner.
- Via the supplied faceplates and screen windows, the relevant information and important parameters can be displayed on the HMI control panel.

### Overview and description of the user interface

Figure 2-2



The application example provides the following views in the faceplate:

- UPS state
  - General overview
  - Device information
- Voltage and power trend curves
- SITOP alarms
  - Currently pending alarms / alarm history



## 2.3 Hardware and software components used

The application was created with the following components:

### Hardware components

Table 2-2

Component	No.	Article number	Note
SITOP UPS1600 24V/10A (Ethernet/PROFINET)	1	6EP4134-3AB00-2AY0	
SITOP UPS1600 24V/20A (Ethernet/PROFINET)	or	6EP4136-3AB00-2AY0	
SITOP UPS1600 24V/40A (Ethernet/PROFINET)	or	6EP4137-3AB00-2AY0	
MP277 8" Touch	1	6AV6643-0CB01-1AX5	See <a href="#">Requirements</a>
Comfort Panel TP1200	1	6AV2124-0MC01-0AX0	See <a href="#">Requirements</a>
CPU 1516-3 PN/DP	1	6ES7516-3AN00-0AB0	Or other S7-1500 CPU
CPU 317-2 PN/DP	1	6ES7317-2EK14-0AB0	Or other S7-300 CPU

### Standard software components

Table 2-3

Component	No.	Article number	Note
WinCC flexible 2008 SP3 Advanced	1	6AV6613-0AA51-3CA5	Alternatively WinCC flexible 2008 SP3 Standard
WinCC Advanced V12	1	6AV2102-0AA02-0AA5	Alternatively WinCC Comfort V12
STEP7 Professional V5.5	1	6ES7810-4CC10-0YA5	-
STEP7 Professional V12	1	6ES7822-1AA02-0YA5	-
WinCC Professional V12	1	6AV2102-0AH02-0AA5	-
WinCC V7.2	1	6AV6381-2BS07-2AX0	-

### Sample files and projects

The following list includes all files and projects that are used in this example.

Table 2-4

Component	Note
78817848_UPS1600_lib_TIAP_V12_SP1.zip	This zip file contains the library for TIA Portal V12 and the master copies for STEP 7 V12 and WinCC V12.

## 2 Structure

### 2.3 Hardware and software components used

Component	Note
78817848_UPS1600_STEP7_V5_5.zip	This zip file contains the library of the function blocks for STEP 7 V5.5.
78817848_UPS1600_lib_WinCC_flexible_2008.zip	This zip file contains the library of the faceplates for WinCC flexible 2008 SP3.
78817848_UPS1600_lib_WinCC_V7_2.zip	This zip file contains the library of the screen windows for WinCC V7.2.
78817848_Faceplates_SITOP_DC_USV_de.pdf	This document.

## 3 Function Blocks for the UPS1600

This chapter informs about the options and functions provided by the supplied function block FB160. Moreover, this chapter describes the application and requirements of the function block FB160 and its integration into a STEP 7 project.

### 3.1 Function and task of the function block

#### 3.1.1 Task description and application

In the event of a plant power failure it is essential to safeguard certain machine components against damage and to back up process-relevant data in order to prevent data loss.

The application of the function block FB160 provides you with the option to bring your plant into a safe state and switch it off in a program-controlled manner while a SITOP UPS1600 buffers the voltage.

#### 3.1.2 Function description

The function block FB160 cyclically monitors the operating mode of the SITOP UPS1600. If the SITOP UPS1600 is in buffer mode, a 10s timer within the function block starts to run. This timer prevents a plant from being brought into a safe state in the event of just a short voltage dip/drop.


If after expiry of the timer the UPS is still in buffer mode, the parameter "UPS\_ready\_for\_reset" is set from "FALSE" to "TRUE".

In the further course of the program, this parameter can be used to bring plant components into a safe state (maintenance mode).

When the plant has been brought into a safe state, the parameter "UPS\_execute\_reset" must be set from "FALSE" to "TRUE". The function block then sends a command to the UPS1600, which then switches off autonomously.

The following figure displays the program sequence of the function block.

3.2 Operating conditions



© Siemens AG 2014. All rights reserved

**Notes regarding the function**

- If the SITOP UPS1600 returns to normal mode while the timer is running, the parameter "UPS\_ready\_for\_reset" is not set. The timer is then reset.
- After the parameter "UPS\_execute\_reset" has been set, the further program sequence must absolutely be executed until the UPS1600 is switched off via the function block.
- The buffer time of the SITOP UPS1600 must be set such that there is sufficient time to bring the plant into a safe state and switch off the UPS via the function block.

**3.2 Operating conditions**

The function block is approved for the following constellations:

- STEP 7 V5.5 and application of a CPU 300/400
- STEP 7 V12 and application of a CPU 300/400 or CPU 1200/1500

## 4 Application of the Function Block under STEP 7 V5.5

### 4.1 Preconditions

The following requirements must be met in order to use the function block in combination with a SITOP UPS1600 and STEP 7 V5.5.

- The GSD file of the SITOP UPS1600 is installed in the hardware configuration of STEP 7 V5.5 and the UPS is configured as PROFINET node in the HW configuration of the SIMATIC S7 controller.
- Already existing S7 communication between the SITOP UPS1600 and SIMATIC S7 controller.
- The library "UPS1600 STEP 7 V5\_5" is available on the computer.

#### Note regarding the installation of the GSD file

The required information about the installation of the GSD file of the SITOP UPS1600 in STEP 7 V5.5 is available in the [SITOP UPS1600 User Manual](#) in Chapter 3.4.1.

#### Note regarding the S7 communication

The required information about establishing communication between a SITOP UPS1600 and a SIMATIC S7 controller is available in the [SITOP UPS1600 User Manual](#) in Chapter 3.4.

### 4.2 Content of the library for STEP 7 V5.5

The library "UPS1600 STEP 7 V5\_5" comprises the following:

- Blocks (FB160, DB160, DB161)
- Symbol table "Symbols\_UPS1600"
- SCL source file of the code block FB160

The following table shows the blocks contained in the library.


Table 4-1

Block	Name	Description
FB160	UPS1600	Function block for program-controlled switch-off of the UPS1600
DB160	UPS1600_iDB	Instance data block of the FB160
DB161	UPS1600_Infos	The data block contains all parameters of the SITOP UPS1600 displayed within the HMI faceplate.

**Opening the library in STEP 7 V5.5**



Follow the instructions in the table below to open the library in a STEP 7 V5.5 project.

Table 4-2

No.	Procedure
1.	Start the SIMATIC Manager.
2.	<p>In the menu bar of the SIMATIC Manager, click on "File &gt; Open".</p>  <p>The "Open Project" dialog box opens.</p>

## 4 Application of the Function Block under STEP 7 V5.5


### 4.2 Content of the library for STEP 7 V5.5

No.	Procedure
3.	<p>Click on the "Libraries" tab.</p> 
4.	<p>Click the "Browse..." button. The "Browse" dialog box opens.</p>
5.	<p>Select the storage location of the library from the list in the dialog box and then click the "OK" button.</p>  <p>The library is opened and can be used.</p>

## 4.3 Interfaces of the function block

### Block diagram

The following figure shows the block diagram of the function block FB160 within a network.



### Interface description

Table 4-3

Parameter	Declaration	Data type	Description
PN_ADDRESS	Input	DWORD	PROFINET diagnostic address of the SITOP UPS1600 within the project. The diagnostic address must be specified in hexadecimal format.
UPS_execute_reset	Input	BOOL	Switch-off signal to the SITOP UPS1600
UPS_ready_for_reset	Output	BOOL	Signal for plant shut-down



## 4.4 Data block DB161

The data block contains all parameters of the SITOP UPS1600 displayed within the HMI faceplate.

The following table lists all parameters of the SITOP UPS1600 contained in DB161.

Table 4-4

Parameter	Data type	Offset	Remarks
Battery_capacity	Int	0.0	[0.1Ah]
End_of_charge_voltage	Int	2.0	[0.01V]
Charge_current	Int	4.0	[mA]
HW_revision	Int	6.0	-
SW_revision	Int	8.0	-
Max_output_current	Byte	10.0	[A]
Padding	Byte	11.0	-
Order_number	Array [0 .. 29] Of Char	12.0	[30 characters]
Serial_number	Array [0 .. 29] Of Char	42.0	[30 characters]
Device_name	Array [0 .. 29] Of Char	72.0	[30 characters]
Version_number	Array [0 .. 49] Of Char	102.0	[50 characters]
Input_voltage	Int	152.0	[0.01V]
Input_current	Int	154.0	[5mA]
Output_voltage	Int	156.0	[0.01V]
Load_current	Int	158.0	[5mA]
Measured_charge_current	Int	160.0	[mA]
Battery_voltage	Int	162.0	[0.01V]
Output_current	Int	164.0	[5mA]
Charge_voltage	Int	166.0	[0.01V]
Buffer_mode	Byte	168.0	(active=255 / inactive=0); undefined = 127
Ready_for_buffering	Byte	169.0	(yes or no – 255/0)
New_alarms_pending	Byte	170.0	(yes or no – 255/0)
Battery_charge_level	Byte	171.0	(0...100%); 255 – unknown battery)
Total_calculated_battery_capacity	Int	172.0	[0.1Ah]
Total_calculated_battery_health	Byte	174.0	[%]
Buffer_time	Int	176.0	[s]
Buffer_threshold	Int	178.0	[s]
Buffering_allowed	Byte	180.0	[0/255]
CommandID	Int	182.0	Remote reset=8195
Parameter	Byte	184.0	[s]
Padding_command	Byte	185.0	[s]

## 4 Application of the Function Block under STEP 7 V5.5

### 4.4 Data block DB161

Parameter	Data type	Offset	Remarks
Order_number_string	String [254]	186.0	char to string > Order_number
Serial_number_string	String [254]	442.0	char to string > Serial_number
Device_name_string	String [254]	698.0	char to string > Device_name
Version_number_string	String [254]	954.0	char to string > Version_number

**Note**

Further information about the system parameters is available in the [UPS1600 User Manual](#).

## 4.5 Integrating the function block

The following sections describe all steps required to integrate the function block FB160 into a STEP 7 V5.5 project.

Hardware used in this description:

- CPU 317-2 PN/DP
- SITOP UPS1600 24V/10A

The procedure for other SIMATIC S7 controllers is identical.


**Note**

Please make sure that all requirements for the integration of the function block are met. The requirements are described in [Chapter 4.1](#).

### Inserting blocks from the library into the program



The following table describes all steps for integrating the function block FB160 and the associated data blocks into a STEP 7 V5.5 project.

Table 4-5

No.	Procedure
1.	<p>Open the project into which you want to insert the function block.</p> 



## 4 Application of the Function Block under STEP 7 V5.5

### 4.5 Integrating the function block

No.	Procedure
2.	<p>Open the global library "UPS1600 STEP 7 V5_5".</p>  <p><b>Note</b> The procedure for opening a global library is described in <a href="#">Chapter 4.2</a>.</p>
3.	<p>Open the folder "UPS1600 STEP 7 V5_5 &gt; UPS1600 library &gt; Blocks" in the library.</p> 
4.	<p>Select all blocks in the "Blocks" folder.</p>



#### 4 Application of the Function Block under STEP 7 V5.5

##### 4.5 Integrating the function block

No.	Procedure																																			
5.	<p>Drag and drop all blocks into the "Blocks" folder in your target project folder.</p>  <p>The screenshot shows two windows in SIMATIC Manager. The top window, titled 'UPS1600_STEP7_V5_5', displays a tree view on the left with 'UPS1600 library' expanded to show 'Sources' and 'Blocks'. The right pane shows a table of objects:</p> <table border="1" data-bbox="708 495 1353 707"> <thead> <tr> <th>Object name</th> <th>Symbolic name</th> <th>Created in language</th> <th>Size in the work me...</th> <th>Type</th> </tr> </thead> <tbody> <tr> <td>FB160</td> <td>UPS1600</td> <td>SCL</td> <td>1734</td> <td>Function Bl</td> </tr> <tr> <td>DB160</td> <td>UPS1600_IDB</td> <td>DB</td> <td>376</td> <td>Instance da</td> </tr> <tr> <td>DB161</td> <td>UPS1600_Infos</td> <td>DB</td> <td>222</td> <td>Data Block</td> </tr> </tbody> </table> <p>The bottom window, titled 'Factory -- C:\Program Files\Siemens\Step7s7proj\Example', shows a similar tree view with 'Factory' expanded to show 'SIMATIC 300(1)', 'CPU 317-2 PN/DP', 'S7 Program(1)', 'Sources', and 'Blocks'. Its right pane shows:</p> <table border="1" data-bbox="708 741 1353 954"> <thead> <tr> <th>Object name</th> <th>Symbolic name</th> <th>Created in language</th> <th>Size in the work me...</th> <th>Type</th> </tr> </thead> <tbody> <tr> <td>System data</td> <td>---</td> <td>---</td> <td>---</td> <td>SDB</td> </tr> <tr> <td>OB1</td> <td>---</td> <td>---</td> <td>38</td> <td>Organizati</td> </tr> </tbody> </table>	Object name	Symbolic name	Created in language	Size in the work me...	Type	FB160	UPS1600	SCL	1734	Function Bl	DB160	UPS1600_IDB	DB	376	Instance da	DB161	UPS1600_Infos	DB	222	Data Block	Object name	Symbolic name	Created in language	Size in the work me...	Type	System data	---	---	---	SDB	OB1	---	---	38	Organizati
Object name	Symbolic name	Created in language	Size in the work me...	Type																																
FB160	UPS1600	SCL	1734	Function Bl																																
DB160	UPS1600_IDB	DB	376	Instance da																																
DB161	UPS1600_Infos	DB	222	Data Block																																
Object name	Symbolic name	Created in language	Size in the work me...	Type																																
System data	---	---	---	SDB																																
OB1	---	---	38	Organizati																																
6.	<p>Select the folder "UPS1600 STEP 7 V5_5 &gt; UPS1600 library" in the library.</p>  <p>The screenshot shows the same SIMATIC Manager interface. In the top window, the 'UPS1600 library' folder is now selected in the tree view. The right pane shows a table of objects:</p> <table border="1" data-bbox="708 1229 1353 1442"> <thead> <tr> <th>Object name</th> <th>Symbolic name</th> <th>Type</th> <th>Size</th> <th>Author</th> </tr> </thead> <tbody> <tr> <td>Sources</td> <td>---</td> <td>Source Folder</td> <td>---</td> <td>---</td> </tr> <tr> <td>Blocks</td> <td>---</td> <td>Block Folder Offline</td> <td>---</td> <td>---</td> </tr> <tr> <td>Symbols_UPS1600</td> <td>---</td> <td>Symbol table</td> <td>5313</td> <td>---</td> </tr> </tbody> </table> <p>The bottom window remains the same as in the previous screenshot.</p>	Object name	Symbolic name	Type	Size	Author	Sources	---	Source Folder	---	---	Blocks	---	Block Folder Offline	---	---	Symbols_UPS1600	---	Symbol table	5313	---															
Object name	Symbolic name	Type	Size	Author																																
Sources	---	Source Folder	---	---																																
Blocks	---	Block Folder Offline	---	---																																
Symbols_UPS1600	---	Symbol table	5313	---																																


## 4 Application of the Function Block under STEP 7 V5.5

### 4.5 Integrating the function block

No.	Procedure																																													
7.	<p>Open the symbol table "Symbols_UPS1600".</p>  <table border="1"> <thead> <tr> <th>Status</th> <th>Symbol /</th> <th>Address</th> <th>Data type</th> <th>Comment</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>UPS_Battery_charge_level</td> <td>PEB 262</td> <td>BYTE</td> <td>UPS1600 (Battery_charge_level)</td> </tr> <tr> <td>2</td> <td>UPS_Buffer_mode</td> <td>PEB 257</td> <td>BYTE</td> <td>UPS1600 (Buffer_mode)</td> </tr> <tr> <td>3</td> <td>UPS_New_alarms_pending</td> <td>PEB 261</td> <td>BYTE</td> <td>UPS1600 (New_alarms_pending)</td> </tr> <tr> <td>4</td> <td>UPS_Ready_for_buffering</td> <td>PEB 258</td> <td>BYTE</td> <td>UPS1600 (Ready_for_buffering)</td> </tr> <tr> <td>5</td> <td>UPS1600</td> <td>FB 160</td> <td>FB 160</td> <td>Function block SITOP UPS1600</td> </tr> <tr> <td>6</td> <td>UPS1600_IDB</td> <td>DB 160</td> <td>FB 160</td> <td>Instanz data block SITOP UPS1600</td> </tr> <tr> <td>7</td> <td>UPS1600_infos</td> <td>DB 161</td> <td>DB 161</td> <td>Data block SITOP UPS1600</td> </tr> <tr> <td>8</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Status	Symbol /	Address	Data type	Comment	1	UPS_Battery_charge_level	PEB 262	BYTE	UPS1600 (Battery_charge_level)	2	UPS_Buffer_mode	PEB 257	BYTE	UPS1600 (Buffer_mode)	3	UPS_New_alarms_pending	PEB 261	BYTE	UPS1600 (New_alarms_pending)	4	UPS_Ready_for_buffering	PEB 258	BYTE	UPS1600 (Ready_for_buffering)	5	UPS1600	FB 160	FB 160	Function block SITOP UPS1600	6	UPS1600_IDB	DB 160	FB 160	Instanz data block SITOP UPS1600	7	UPS1600_infos	DB 161	DB 161	Data block SITOP UPS1600	8				
Status	Symbol /	Address	Data type	Comment																																										
1	UPS_Battery_charge_level	PEB 262	BYTE	UPS1600 (Battery_charge_level)																																										
2	UPS_Buffer_mode	PEB 257	BYTE	UPS1600 (Buffer_mode)																																										
3	UPS_New_alarms_pending	PEB 261	BYTE	UPS1600 (New_alarms_pending)																																										
4	UPS_Ready_for_buffering	PEB 258	BYTE	UPS1600 (Ready_for_buffering)																																										
5	UPS1600	FB 160	FB 160	Function block SITOP UPS1600																																										
6	UPS1600_IDB	DB 160	FB 160	Instanz data block SITOP UPS1600																																										
7	UPS1600_infos	DB 161	DB 161	Data block SITOP UPS1600																																										
8																																														
8.	<p>Open the symbol table of your target project.</p>  <table border="1"> <thead> <tr> <th>Status</th> <th>Symbol /</th> <th>Address</th> <th>Data type</th> <th>Comment</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>UPS1600</td> <td>FB 160</td> <td>FB 160</td> <td>Function block SITOP UPS1600</td> </tr> <tr> <td>2</td> <td>UPS1600_IDB</td> <td>DB 160</td> <td>FB 160</td> <td>Instanz data block SITOP UPS1600</td> </tr> <tr> <td>3</td> <td>UPS1600_infos</td> <td>DB 161</td> <td>DB 161</td> <td>Data block SITOP UPS1600</td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Status	Symbol /	Address	Data type	Comment	1	UPS1600	FB 160	FB 160	Function block SITOP UPS1600	2	UPS1600_IDB	DB 160	FB 160	Instanz data block SITOP UPS1600	3	UPS1600_infos	DB 161	DB 161	Data block SITOP UPS1600	4																								
Status	Symbol /	Address	Data type	Comment																																										
1	UPS1600	FB 160	FB 160	Function block SITOP UPS1600																																										
2	UPS1600_IDB	DB 160	FB 160	Instanz data block SITOP UPS1600																																										
3	UPS1600_infos	DB 161	DB 161	Data block SITOP UPS1600																																										
4																																														

#### 4 Application of the Function Block under STEP 7 V5.5

##### 4.5 Integrating the function block

No.	Procedure																																													
9.	<p>Copy all entries of the symbol table "Symbols _UPS1600" to the symbol table of your target project.</p>  <p>The screenshot displays two windows from the Symbol Editor. The top window, titled 'UPS1600 library (Symbols_UPS1600) -- UPS1600_STEP7_V5_5', shows a table with the following data:</p> <table border="1"> <thead> <tr> <th>Status</th> <th>Symbol /</th> <th>Address</th> <th>Data type</th> <th>Comment</th> </tr> </thead> <tbody> <tr><td>1</td><td>UPS_Battery_charge_level</td><td>PEB 262</td><td>BYTE</td><td>UPS1600 (Battery_charge_level)</td></tr> <tr><td>2</td><td>UPS_Buffer_mode</td><td>PEB 257</td><td>BYTE</td><td>UPS1600 (Buffer_mode)</td></tr> <tr><td>3</td><td>UPS_New_alarms_pending</td><td>PEB 261</td><td>BYTE</td><td>UPS1600 (New_alarms_pending)</td></tr> <tr><td>4</td><td>UPS_Ready_for_buffering</td><td>PEB 258</td><td>BYTE</td><td>UPS1600 (Ready_for_buffering)</td></tr> <tr><td>5</td><td>UPS1600</td><td>FB 160</td><td>FB 160</td><td>Function block SITOP UPS1600</td></tr> <tr><td>6</td><td>UPS1600_IDB</td><td>DB 160</td><td>FB 160</td><td>Instanz data block SITOP UPS1600</td></tr> <tr><td>7</td><td>UPS1600_infos</td><td>DB 161</td><td>DB 161</td><td>Data block SITOP UPS1600</td></tr> <tr><td>8</td><td></td><td></td><td></td><td></td></tr> </tbody> </table> <p>The bottom window, titled 'S7 Program(1) (Symbols) -- Factory\SIMATIC 300(1)\CPU 317-2 PN/DP', shows an identical table with all entries highlighted in blue, indicating they have been copied to the target project.</p>	Status	Symbol /	Address	Data type	Comment	1	UPS_Battery_charge_level	PEB 262	BYTE	UPS1600 (Battery_charge_level)	2	UPS_Buffer_mode	PEB 257	BYTE	UPS1600 (Buffer_mode)	3	UPS_New_alarms_pending	PEB 261	BYTE	UPS1600 (New_alarms_pending)	4	UPS_Ready_for_buffering	PEB 258	BYTE	UPS1600 (Ready_for_buffering)	5	UPS1600	FB 160	FB 160	Function block SITOP UPS1600	6	UPS1600_IDB	DB 160	FB 160	Instanz data block SITOP UPS1600	7	UPS1600_infos	DB 161	DB 161	Data block SITOP UPS1600	8				
Status	Symbol /	Address	Data type	Comment																																										
1	UPS_Battery_charge_level	PEB 262	BYTE	UPS1600 (Battery_charge_level)																																										
2	UPS_Buffer_mode	PEB 257	BYTE	UPS1600 (Buffer_mode)																																										
3	UPS_New_alarms_pending	PEB 261	BYTE	UPS1600 (New_alarms_pending)																																										
4	UPS_Ready_for_buffering	PEB 258	BYTE	UPS1600 (Ready_for_buffering)																																										
5	UPS1600	FB 160	FB 160	Function block SITOP UPS1600																																										
6	UPS1600_IDB	DB 160	FB 160	Instanz data block SITOP UPS1600																																										
7	UPS1600_infos	DB 161	DB 161	Data block SITOP UPS1600																																										
8																																														

**Adapting the address ranges in the symbol table**

Within the program sequence of the function block FB160, the cyclic data of the address range of the SITOP UPS1600 are accessed. In this case, the required address ranges are transferred to the function block via four tags. It is therefore necessary to adapt the addresses of these tags in the symbol table dependent on the selected I/O address range of the SITOP UPS1600.

The following table shows the I/O address range (length: 7 bytes) of the SITOP UPS1600. The function block evaluates the parameters "buffer mode", "ready for buffering", "new alarms pending", and "battery charge level".

**Note**

The settings of the I/O address range of the SITOP UPS1600 are described in the HW configuration.




Table 4-6

Tag in the symbol table	Parameter of the UPS1600	Information	Address range in this example
-	Input voltage	-	PEB 256
UPS_Buffer_mode	buffer mode	Buffer mode / Normal mode	PEB 257
UPS_Ready_for_buffering	ready for buffering	Ready / Not ready for buffering	PEB 258




## 4 Application of the Function Block under STEP 7 V5.5

### 4.5 Integrating the function block

Tag in the symbol table	Parameter of the UPS1600	Information	Address range in this example
-	charge sufficient	-	PEB 259
-	battery change recommended	-	PEB 260
UPS_New_alarms_pending	new alarms pending	New / No new alarms pending	PEB 261
UPS_Battery_charge_level	battery charge level	Charge state of the battery	PEB 262

The following table describes the procedure for changing the address ranges of the symbol table contained in the library.

Table 4-7

No.	Procedure
1.	Open the symbol table in the program folder of your application program. 
2.	Change the address of the symbol "UPS_Battery_charge_level" dependent on the selected I/O address range for the parameter "ready for buffering" of the UPS1600.
3.	Change the address of the symbol "UPS_Buffer_mode" dependent on the selected I/O address range for the parameter "buffer mode" of the UPS1600.
4.	Change the address of the symbol "UPS_New_alarms_pending" dependent on the selected I/O address range for the parameter "New alarms pending" of the UPS1600.
5.	Change the address of the symbol "UPS_Battery_charge_level" dependent on the selected I/O address range for the parameter "battery charge level" of the UPS1600.



## 4 Application of the Function Block under STEP 7 V5.5

### 4.5 Integrating the function block

#### Calling the function block



This section describes the procedure for calling the function block within an organization block. In this description, the function block "FB160" is called within "OB1".

Table 4-8

No.	Procedure
1.	<p>In the "Blocks" folder of your application program, open the block "Main [OB1]" in the FBD view.</p> 
2.	<p>On the "Program elements" tab, open the "FB blocks" folder.</p>
3.	<p>Drag and drop the block "FB160 (UPS1600)" from the "FB blocks" folder to an empty network of the "Main [OB1]".</p> 



## 4 Application of the Function Block under STEP 7 V5.5

### 4.5 Integrating the function block

No.	Procedure
4.	<p>Interconnect the FB160 with the instance data block "DB160 (UPS1600_iDB)".</p>  <p>The screenshot shows the SIMATIC Manager interface. On the left, the 'Program elements' tree is expanded to 'SITOP / UPS1600'. The main workspace shows a ladder logic network with a function block call for 'FB160'. The 'PN_ADDRESS' parameter of the FB160 block is highlighted in blue and set to 'DB160'. A red box highlights the 'DB160' parameter value.</p>
5.	<p>At the block parameter "PN_ADDRESS" of the FB160, enter the PROFINET diagnostic address of the SITOP UPS1600 within your STEP 7 project. The PROFINET diagnostic address must be specified in hexadecimal format. In this example, the SITOP UPS1600 has the diagnostic address "DW#16#1FF7".</p>  <p>The screenshot shows the SIMATIC Manager interface. The main workspace shows a ladder logic network with a function block call for 'FB160'. The 'PN_ADDRESS' parameter of the FB160 block is highlighted in blue and set to 'DW#16#1FF7'. A red box highlights the 'DW#16#1FF7' parameter value.</p> <p><b>Note</b> Further information about the PROFINET diagnostic address is available in the STEP 7 V5.5 Online Help.</p>

## 4 Application of the Function Block under STEP 7 V5.5

### 4.5 Integrating the function block

No.	Procedure
6.	<p>Connect the block parameter "UPS_ready_for_reset" with the tag via which you bring your plant into a safe state. In this example, flag 0.0 is used.</p>  <p>The screenshot shows the SIMATIC Manager interface with the 'Function block' editor open. The 'UPS_ready_for_reset' parameter is connected to 'M0.0'. The 'UPS_execute_reset' parameter is also visible but not yet connected.</p> <p><b>Note</b> Further information about the block parameters is available in Chapter 3.2.3.</p>
7.	<p>Connect the block parameter "UPS_execute_reset" with a tag via which you switch off the UPS when your plant is in a condition in which it can be shut down. In this example, flag 0.1 is used.</p>  <p>The screenshot shows the SIMATIC Manager interface with the 'Function block' editor open. The 'UPS_execute_reset' parameter is now connected to 'M0.1'. The 'UPS_ready_for_reset' parameter remains connected to 'M0.0'.</p> <p><b>Note</b> Further information about the block parameters is available in <a href="#">Chapter 4.3</a>.</p>
8.	<p>Save the changes in the Main [OB1].</p>

The integration of the function block is thus completed.

## 5 Application of the Function Block under STEP 7 V12

### 5.1 Preconditions

The following requirements must be met in order to use the function block in combination with a SITOP UPS1600 and STEP 7 V12:

- The Hardware Support Package for the SITOP UPS1600 is installed in STEP 7 V12.
- Already existing S7 communication between the SITOP UPS1600 and SIMATIC S7 controller.
- The library with the function blocks is available.

#### Note regarding the installation of the Hardware Support Package

The required information about the installation of the Hardware Support Package of the SITOP UPS1600 in STEP 7 V12 is available in the [SITOP UPS1600 User Manual](#) in Chapter 3.3.1.

#### Notes regarding the S7 communication

The required information about establishing communication between a SITOP UPS1600 and a SIMATIC S7 controller is available in the [SITOP UPS1600 User Manual](#) in Chapter 3.3.

### 5.2 Content of the library for STEP 7 V12

The library "UPS1600 Function blocks (STEP7 V12)" contains the following library elements:

- STEP 7 Function blocks (S7-300/400)
- STEP 7 Function blocks (S7-1200/1500)
- STEP 7 Tag table
- PLC data types

The following sections describe in detail the library elements and how to open a library in STEP 7 V12.

#### Library element "STEP 7 Function blocks (S7-300/400)"

The following code blocks are contained in this library element:

Table 5-1

Code block	Name	Description
FB160	UPS1600	Function block for program-controlled switch-off of the SITOP UPS1600
DB160	UPS1600_iDB	Instance data block of the FB160
DB161	UPS1600_Data	The data block contains all parameters of the SITOP UPS1600 displayed within the HMI faceplate.

**Library element "STEP 7 Function blocks (S7-1200/1500)"**

The following code blocks are contained in this library element:

Table 5-2

Code block	Name	Description
FB160	UPS1600	Function block for program-controlled switch-off of the UPS1600
DB160	UPS1600_iDB	Instance data block of the FB160
DB161	UPS1600_Data	The data block contains all parameters of the SITOP UPS1600 displayed within the HMI faceplate.

**Library element "STEP 7 Tag table"**

This library element contains the tag folder "UPS1600 Tag table".

The tags within this folder are required for the transfer of the values of the I/O address range of the SITOP UPS1600 to the function block FB160.

**Library element „PLC data types“**


This library element contains the data types „tUPS1600 mixed“ und „tUPS1600 strings“.

Both data types are building the data block DB161. This DB is used for data exchange to the HMI faceplates.

**Opening the library in STEP 7 V12**



Follow the instructions in the table below to open the library in a STEP 7 V12 project.

Table 5-3

No.	Procedure
1.	<p>Open STEP 7 V12 in the Project view.</p>  <p>The screenshot shows the Siemens STEP 7 V12 software interface. The main window is titled 'Siemens - Factory'. The 'Project tree' on the left shows a hierarchy starting with 'Factory', containing 'Add new device', 'Devices &amp; networks', 'Common data', 'Documentation settings', 'Languages &amp; resources', 'Online access', and 'Card Reader/USB memory'. The 'Properties' window at the bottom center displays the message: 'No 'properties' available. No 'properties' can be shown at the moment. There is either no object selected or the selected object does not have any displayable properties.' The 'Tasks' and 'Options' panels are visible on the right side of the interface.</p>


## 5 Application of the Function Block under STEP 7 V12

### 5.2 Content of the library for STEP 7 V12

No.	Procedure
2.	<p>Open the "Libraries" task card.</p>  <p>The screenshot shows the Siemens Factory Portal interface. The 'Libraries' task card is highlighted with a red box on the right-hand side of the screen. The interface includes a menu bar at the top with options like 'Project', 'Edit', 'View', 'Insert', 'Online', 'Options', 'Tools', 'Window', and 'Help'. Below the menu bar is a toolbar with various icons. The main area is divided into several sections: 'Project tree' on the left, 'Libraries' on the right, and a 'Properties' pane at the bottom. The 'Libraries' section is expanded to show 'Project library' and 'Global libraries'. The 'Global libraries' section lists several categories: 'Buttons-and-Switches', 'Long Functions', 'Monitoring-and-control-objects', 'Documentation templates', and 'WinAC_MP'. The 'Properties' pane at the bottom displays the message: 'No 'properties' available. No 'properties' can be shown at the moment. There is either no object selected or the selected object does not have any displayable properties.'</p>
3.	<p>Under the "Global libraries" palette, click on the second icon from the left to open a global library.</p>  <p>The screenshot shows a close-up of the 'Libraries' task card. The 'Global libraries' section is expanded, and the second icon from the left (a green icon with a white document symbol) is highlighted with a red box. The 'Global libraries' section lists several categories: 'Buttons-and-Switches', 'Long Functions', 'Monitoring-and-control-objects', 'Documentation templates', and 'WinAC_MP'. Below the list is an 'Info (Global libraries)' button.</p> <p>The "Open global library" dialog box opens.</p>

## 5 Application of the Function Block under STEP 7 V12

### 5.2 Content of the library for STEP 7 V12

No.	Procedure
4.	In the "Look in:" drop-down list, select the storage location of the library on your computer.
5.	<p>Click the "Open" button.</p>  <p>The library is opened and displayed in the "Global libraries" palette.</p>




## 5.3 Interfaces of the function block FB160

### Function block FB160 for S7-300/400

#### Block diagram

The following figure shows the block diagram of the function block FB160 within a network.

Figure 5-1



#### Interface description

Table 5-4

Parameter	Declaration	Data type	Description
I_ADDRESS	Input	DWORD	PROFINET diagnostic address of the SITOP UPS1600 within the project The diagnostic address must be specified in hexadecimal format.
UPS_execute_reset	Input	BOOL	Switch-off signal to the SITOP UPS1600
UPS_ready_for_reset	Output	BOOL	Signal for plant shut-down
UPS_DataM	Input	tUPS1600 mixed	Data area of DB161 for data exchange to the HMI faceplate.
UPS_DataS	Input	tUPS1600 strings	Data area of DB161 for data exchange to the HMI faceplate.

**Function block FB160 for S7-1200/1500**

Block diagram

The following figure shows the block diagram of the function block FB160 within a network.




Figure 5-2

Interface description

Table 5-5

Parameter	Declaration	Data type	Description
HW_IO	Input	HW_IO	Hardware ID of the SITOP UPS1600 within the project
UPS_execute_reset	Input	BOOL	Switch-off signal to the SITOP UPS1600
UPS_ready_for_reset	Output	BOOL	Signal for plant shut-down
UPS_DataM	Input	tUPS1600 mixed	Data area of DB161 for data exchange to the HMI faceplate.
UPS_DataS	Input	tUPS1600 strings	Data area of DB161 for data exchange to the HMI faceplate.

**Note to the use of more as one UPS1600 devices**

Are more than one UPS1600 device used in one STEP 7 (TIA Portal) project, you have to use an individual instance data block and an separate data block for data exchange for each UPS1600 device.

So the function blocks are able to use in multiple instances. You can create data blocks with the PLC data types of the library.

## 5.4 Data block DB161

The data block contains all parameters of the SITOP UPS1600 displayed within the HMI faceplate.

The following table lists all parameters of the SITOP UPS1600 contained in DB161.

Table 5-6

Parameter	Data type	Offset	Remarks
UPS_DataS	tUPS1600 strings	0.0	-
Order_number_string	String [20]	0.0	Order number (String)
Serial_number_string	String [20]	22.0	Serial number (String)
Device_name_string	String [20]	44.0	Device name (String)
Version_number_string	String [30]	66.0	Version number (String)
UPS_DataM	tUPS1600 mixed	98.0	-
Battery_capacity	Int	0.0	[0.1Ah]
End_of_charge_voltage	Int	2.0	[0.01V]
Charge_current	Int	4.0	[mA]
HW_revision	Int	6.0	-
SW_revision	Int	8.0	-
Max_output_current	Byte	10.0	[A]
Padding	Byte	11.0	-
Order_number	Array [0 .. 29] Of Char	12.0	[30 characters]
Serial_number	Array [0 .. 29] Of Char	42.0	[30 characters]
Device_name	Array [0 .. 29] Of Char	72.0	[30 characters]
Version_number	Array [0 .. 49] Of Char	102.0	[50 characters]
Input_voltage	Int	152.0	[0.01V]
Input_current	Int	154.0	[5mA]
Output_voltage	Int	156.0	[0.01V]
Load_current	Int	158.0	[5mA]
Measured_charge_current	Int	160.0	[mA]
Battery_voltage	Int	162.0	[0.01V]
Output_current	Int	164.0	[5mA]
Charge_voltage	Int	166.0	[0.01V]
Buffer_mode	Byte	168.0	(active=255 / inactive=0); undefined = 127
Ready_for_buffering	Byte	169.0	(yes or no – 255/0)
New_alarms_pending	Byte	170.0	(yes or no – 255/0)
Battery_charge_level	Byte	171.0	(0...100%); 255 – unknown battery)
Total_calculated_battery_capacity	Int	172.0	[0.1Ah]

Parameter	Data type	Offset	Remarks
Total_calculated_battery_health	Byte	174.0	[%]
Buffer_time	Int	176.0	[s]
Buffer_threshold	Int	178.0	[s]
Buffering_allowed	Byte	180.0	[0/255]
CommandID	Int	182.0	Remote reset=8195
Parameter	Byte	184.0	[s]
Padding_command	Byte	185.0	[s]
Order_number_string	String [20]	0.0	Order number (String)
Serial_number_string	String [20]	22.0	Serial number (String)
Device_name_string	String [20]	44.0	Device name (String)
Version_number_string	String [30]	66.0	Version number (String)

#### Note to the use of more as one UPS1600 devices

Are more than one UPS1600 device used in one STEP 7 (TIA Portal) project, you have to use an individual instance data block and an separate data block for data exchange for each UPS1600 device.

The structure of the data blocks must be the same of the data block DB161.

The library contains the PLC data types „tUPS mixed“ and „tUPS strings“. With this you are able to build you own structures.

#### Note

Further information about the system parameters is available in the [UPS1600 User Manual](#).

## 5.5 Integrating the function block

The following sections describe all steps required to integrate the function block FB160 into a STEP 7 V12 project.

### 5.5.1 Procedure when using an S7-300/400

Hardware used in this description:

- CPU 317-2 PN/DP
- SITOP UPS1600 24V/10A


The procedure for other SIMATIC S7-300/400 controllers is identical.


**Note** Please make sure that all requirements for the integration of the function block are met. The requirements are described in [Chapter 5.1](#).

### Inserting blocks from the library into the program

The following table describes all steps for integrating the function block and the associated data blocks into a STEP 7 V12 project.



Table 5-7

No.	Procedure
1.	<p>Open the project into which you want to insert the function block in the Project view.</p>  <p>The screenshot shows the SIMATIC Manager interface. On the left, the 'Project tree' is expanded to show 'Factory' &gt; 'PLC_1 [CPU 317-2 PN/DP]'. The main workspace is dark blue. At the bottom, the 'Properties' window is open, displaying the message: 'No 'properties' available. No 'properties' can be shown at the moment. There is either no object selected or the selected object does not have any displayable properties.'</p>

No.	Procedure
2.	<p>Open the global library "UPS1600 library TIA Portal V12".</p>  <p>The screenshot shows the 'Libraries' window in TIA Portal. The 'Global libraries' section is expanded, and the folder 'UPS1600 library TIA Portal V12 SP1' is selected and highlighted with a red box. Below it, subfolders like 'Types', 'Master copies', and 'Common data' are visible.</p> <p><b>Note</b> The procedure for opening a global library is described in <a href="#">Chapter 5.2</a>.</p>
3.	<p>Open the folder "Master copies &gt; UPS1600 Function blocks (TIA V12)" in the library.</p>



## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
4.	<p>Select the folder "PLC data types" in the library.</p> 
5.	<p>Drag and drop the "PLC data types" folder to the "PLC data types" folder in the project folder of your existing controller.</p> 
6.	<p>Select the folder "STEP7 Function blocks (S7-300/400)".</p>

## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
7.	<p>Drag and drop the folder "STEP7 Function blocks (S7-300/400)" to the "Program blocks" folder in the project folder of your existing controller.</p>  <p>The screenshot shows the Siemens Factory Editor interface. On the left, the 'Project tree' shows a hierarchy for 'PLC_1 [CPU 317-2 PN/DP]' with 'Program blocks' highlighted. On the right, the 'Libraries' pane shows 'Global libraries' with 'STEP7 Function blocks (S7-300/400)' selected. A red arrow indicates the drag-and-drop action from the library to the project folder. The central workspace shows a 'General' tab with the message: 'No 'properties' available. No 'properties' can be shown at the moment. There is either no object selected or the selected object does not have any displayable properties.'</p>
8.	<p>Select the "STEP7 Tag table" folder.</p>
9.	<p>Drag and drop the "STEP7 Tag table" folder to the "PLC tags" folder in the project folder of your existing controller.</p>  <p>The screenshot shows the Siemens Factory Editor interface. On the left, the 'Project tree' shows 'PLC tags' highlighted. On the right, the 'Libraries' pane shows 'STEP7 Tag table' selected. A red arrow indicates the drag-and-drop action from the library to the project folder. The central workspace shows the same 'No 'properties' available' message.</p>



**Adapting address ranges**

Within the program sequence of the function block FB160, the cyclic data of the address range of the SITOP UPS1600 are accessed. In this case, the required address ranges are transferred to the function block FB160 via four tags. It is therefore necessary to adapt the addresses of these tags in the symbol table dependent on the selected I/O address range of the SITOP UPS1600.

The following table shows the I/O address range (length: 7 bytes) of the SITOP UPS1600. The function block evaluates the parameters "buffer mode", "ready for buffering", "new alarms pending", and "battery charge level".

**Note**

The setting of the I/O address range for the SITOP UPS1600 is specified in the device configuration of the SITOP UPS1600 you created in STEP 7 V12.




Table 5-8


Tag in the symbol table	Parameter of the UPS1600	Information	Address range in this example
-	Input voltage	-	%IB 256
UPS_Buffer_mode	buffer mode	Buffer mode / Normal mode	%IB 257
UPS_Ready_for_buffering	ready for buffering	Ready / Not ready for buffering	%IB 258
-	charge sufficient	-	%IB 259

5.5 Integrating the function block

Tag in the symbol table	Parameter of the UPS1600	Information	Address range in this example
-	battery change recommended	-	%IB 260
UPS_New_alarms_pending	new alarms pending	New / No new alarms pending	%IB 261

The following table describes the procedure for changing the address ranges of the symbol table contained in the library.


Table 5-9

No.	Procedure
1.	<p>Open the tag table "Tag table UPS1600" in the program folder "PLC tags &gt; UPS1600 Tag table" of your application program.</p> 
2.	Change the address of the symbol "UPS_Buffer_mode" dependent on the selected I/O address range for the parameter "buffer mode" of the UPS1600.
3.	Change the address of the symbol "UPS_Ready_for_buffering" dependent on the selected I/O address range for the parameter "ready for buffering" of the UPS1600.
4.	Change the address of the symbol "UPS_New_alarms_pending" dependent on the selected I/O address range for the parameter "new alarms pending" of the UPS1600.
5.	Change the address of the symbol "UPS_Battery_charge_level" dependent on the selected I/O address range for the parameter "battery charge level" of the UPS1600.

**Calling the function block**



This section describes the procedure for calling the function block within an organization block. In this description, the function block "FB160" is called within "OB1".

Table 5-10

No.	Procedure
1.	<p>In the "Program blocks" folder, open the block "Main [OB1]".</p>  <p>The screenshot shows the Siemens STEP 7 software interface. The 'Project tree' on the left is expanded to 'PLC_1 [CPU 317-2 PN/DP] &gt; Program blocks &gt; Main [OB1]'. The main workspace displays the 'Block interface' for 'Main Program Sweep (Cycle)*'. The interface includes a 'Block title' field, a 'Comment' field, and a 'Network 1' section with a 'Comment' field. The status bar at the bottom indicates 'Main (OB1)' and 'PROFINET IO-System: The network part ...'.</p>


## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
2.	<p>Drag and drop the block "UPS1600 [FB160]" from the folder "Program blocks &gt; UPS1600 blocks (S7-300/400)" to an empty network.</p>  <p>The screenshot shows the Siemens STEP 7 software interface. The Project tree on the left is expanded to 'Program blocks &gt; Main [OB1] &gt; UPS1600 blocks (S7-300/400)'. The 'UPS1600 [FB160]' block is selected. A red arrow points from this block to the 'Block interface' window on the right, which shows the 'Main Program Sweep (Cycle)' block with an empty network.</p>
	<p>This opens the call options of the function block.</p>
3.	<p>Open the "Name" drop-down list, select the entry "UPS1600_iDB" and then click the "OK" button.</p>  <p>The screenshot shows the 'Call options' dialog box for the 'UPS1600 [FB160]' block. The 'Name' field is set to 'UPS1600_iDB'. The 'Number' is set to '160'. The 'Manual' radio button is selected. The 'OK' button is highlighted with a red box.</p>
	<p><b>Note to the instance data block</b> It is not necessary to use the DB160 „UPS1600_iDB“ as an instance DB. Instead you can create and use a new one.</p>


## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
4.	<p>At the block parameter "I_ADDRESS", enter the PROFINET diagnostic address of the UPS1600 within your STEP 7 project in hexadecimal format.</p> <p>In this example, the UPS1600 has the PROFINET diagnostic address "2029", which corresponds to a hexadecimal value of "7ed".</p>  <p><b>Note</b> Further information about the PROFINET diagnostic address is available in the STEP 7 V12 Online Help.</p>

## 5 Application of the Function Block under STEP 7 V12



### 5.5 Integrating the function block

No.	Procedure
5.	<p>Connect the block parameter "UPS_ready_for_reset" with a tag of your project that you use to bring your plant into a condition in which it can be shut down.</p> <p>In this example, the tag "Tag_1_ready_for_reset (M0.0)" is used.</p>  <p>The screenshot displays the Siemens STEP 7 interface. The main window shows a ladder logic diagram for the 'UPS1600' function block. The 'UPS_ready_for_reset' parameter is connected to the 'M0.0' tag 'Tag_1_ready_for_reset'. The 'Properties' window is open, showing the block name 'Main' and type 'OB'. The 'General' tab is selected, and the 'Language' is set to 'LAD'.</p>

**Note**  
Further information about the block parameters is available in [Chapter 5.3](#).


## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
6.	<p>Connect the block parameter "UPS_execute_reset" with a tag of your project that you use to switch off the UPS when your plant is in a condition in which it can be shut down.</p> <p>In this example, the tag "Tag_2_execute_reset(M0.1)" is used.</p> 
7.	<p>Connect the block parameter "UPS_DataM" with the "UPS_DataM" tag from DB161 "UPS1600_Data".</p> 

## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block





### 5.5.2 Procedure when using an S7-1200/1500

Hardware used in this description:

- CPU 1516-3 PN/DP
- SITOP UPS1600 24V/10A

The procedure for other SIMATIC S7-1200/1500 controllers is identical.


**Note**


Please make sure that all requirements for the integration of the function block are met. The requirements are described in [Chapter 5.1](#).

#### Inserting blocks from the library into the program

The following table describes all steps for integrating the function block and the associated data blocks into a STEP 7 V12 project.



Table 5-11

No.	Procedure
1.	<p>Open the project into which you want to insert the function block in the Project view.</p> 

No.	Procedure
2.	<p>Open the global library "UPS1600 library TIA Portal V12".</p>  <p><b>Note</b> The procedure for opening a global library is described in <a href="#">Chapter 5.2</a>.</p>
3.	<p>Open the folder "Master copies &gt; UPS1600 Function blocks (TIA V12)" in the library.</p>



## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
4.	<p>Select the folder "PLC data types" in the library.</p> 
5.	<p>Drag and drop the "PLC data types" folder to the "PLC data types" folder in the project folder of your existing controller.</p> 
6.	<p>Select the folder "STEP7 Function blocks (S7-1200/1500)".</p>

## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
7.	<p>Drag and drop the folder "STEP7 Function blocks (S7-1200/1500)" to the "Program blocks" folder in the project folder of your existing controller.</p>  <p>The screenshot shows the Siemens Factory Editor interface. The Project tree on the left shows the 'Program blocks' folder selected. The Libraries pane on the right shows the 'STEP7 Function blocks (S7-1200/1500)' folder selected. A red arrow points from the selected folder in the Libraries pane to the 'Program blocks' folder in the Project tree. The Properties pane at the bottom shows 'No properties available'.</p>
8.	<p>Select the "STEP7 Tag table" folder in the library.</p>
9.	<p>Drag and drop the "STEP7 Tag table" folder to the "PLC tags" folder in the project folder of your existing controller.</p>  <p>The screenshot shows the Siemens Factory Editor interface. The Project tree on the left shows the 'PLC tags' folder selected. The Libraries pane on the right shows the 'STEP7 Tag table' folder selected. A red arrow points from the selected folder in the Libraries pane to the 'PLC tags' folder in the Project tree. The Properties pane at the bottom shows 'No properties available'.</p>

**Adapting address ranges**

Within the program sequence of the function block FB160, the cyclic data of the address range of the SITOP UPS1600 are accessed. In this case, the required address ranges are transferred to the function block FB160 via four tags. It is therefore necessary to adapt the addresses of these tags in the symbol table dependent on the selected I/O address range of the SITOP UPS1600.

The following table shows the I/O address range (length: 7 bytes) of the SITOP UPS1600. The function block evaluates the parameters "buffer mode", "ready for buffering", "new alarms pending", and "battery charge level".

**Note**

The setting of the I/O address range for the SITOP UPS1600 is specified in the device configuration of the SITOP UPS1600 you created in STEP 7 V12.




Table 5-12


Tag in the symbol table	Parameter of the UPS1600	Information	Address range in this example
-	Input voltage	-	%IB 256
UPS_Buffer_mode	buffer mode	Buffer mode / Normal mode	%IB 257
UPS_Ready_for_buffering	ready for buffering	Ready / Not ready for buffering	%IB 258
-	charge sufficient	-	%IB 259

5.5 Integrating the function block

Tag in the symbol table	Parameter of the UPS1600	Information	Address range in this example
-	battery change recommended	-	%IB 260
UPS_New_alarms_pending	new alarms pending	New / No new alarms pending	%IB 261

The following table describes the procedure for changing the address ranges of the symbol table contained in the library.


Table 5-13



No.	Procedure
1.	<p>Open the tag table "Tag table UPS1600" in the program folder "PLC tags &gt; UPS1600 Tag table" of your application program.</p> 
2.	Change the address of the symbol "UPS_Buffer_mode" dependent on the selected I/O address range for the parameter "buffer mode" of the UPS1600.
3.	Change the address of the symbol "UPS_Ready_for_buffering" dependent on the selected I/O address range for the parameter "ready for buffering" of the UPS1600.
4.	Change the address of the symbol "UPS_New_alarms_pending" dependent on the selected I/O address range for the parameter "new alarms pending" of the UPS1600.
5.	Change the address of the symbol "UPS_Battery_charge_level" dependent on the selected I/O address range for the parameter "battery charge level" of the UPS1600.

**Calling the function block**

This section describes the procedure for calling the function block within an organization block. In this description, the function block "FB160" is called within "OB1".

Table 5-14



No.	Procedure
1.	<p>In the "Program blocks" folder, open the block "Main [OB1]".</p> 

No.	Procedure
2.	<p>Drag and drop the block "UPS1600 [FB160]" from the folder "Program blocks &gt; UPS1600 blocks (S7-1200/1500)" to an empty network.</p>  <p>This opens the call options of the function block.</p>
3.	<p>Open the "Name" drop-down list, select the entry "UPS1600_iDB" and then click the "OK" button.</p>  <p><b>Note to the instance data block</b> It is not necessary to use the DB160 „UPS1600_iDB“ as an instance DB. Instead you can create and use a new one.</p>





## 5 Application of the Function Block under STEP 7 V12


### 5.5 Integrating the function block

No.	Procedure									
4.	<p>At the block parameter "HW_IO", enter the hardware ID of the UPS1600 within your STEP 7 project.</p> <p>In this example, the UPS1600 has the hardware ID "287".</p>  <p>The screenshot shows the Siemens STEP 7 software interface. The Project tree on the left shows the hierarchy: NBML_Testprojekt_SITOPUPS160040A_V12_V12_SP1_2... &gt; PLC_1 [CPU 1516-3 PN/DP] &gt; Program blocks &gt; Main [OB1]. The main window displays the 'Interface' table and the 'Network 1' ladder logic diagram. The 'Interface' table has the following data:</p> <table border="1"><thead><tr><th>Name</th><th>Data type</th><th>Comment</th></tr></thead><tbody><tr><td>Initial_Call</td><td>Bool</td><td>Initial call of this OB</td></tr><tr><td>Remanence</td><td>Bool</td><td>=True, if remanent data are available</td></tr></tbody></table> <p>The 'Network 1' diagram shows the 'UPS1600' function block with the following connections:</p> <ul style="list-style-type: none"><li>EN: 287</li><li>HW_IO: 287</li><li>UPS_execute: M0.1</li><li>Tag_2: reset</li><li>UPS_ready_for_reset: M0.0</li><li>Tag_1: Tag_1</li></ul> <p>The parameter '287' for HW_IO is highlighted with a red box.</p> <p><b>Note</b> Further information about the hardware ID is available in the STEP 7 V12 Online Help.</p>	Name	Data type	Comment	Initial_Call	Bool	Initial call of this OB	Remanence	Bool	=True, if remanent data are available
Name	Data type	Comment								
Initial_Call	Bool	Initial call of this OB								
Remanence	Bool	=True, if remanent data are available								
5.	<p>Connect the block parameter "UPS_ready_for_reset" with a tag of your project that you use to bring your plant into a condition in which it can be shut down.</p> <p>In this example, the tag "Tag_1 (M0.0)" is used.</p>  <p>The screenshot shows the Siemens STEP 7 software interface. The Project tree on the left shows the hierarchy: NBML_Testprojekt_SITOPUPS160040A_V12_V12_SP1_2... &gt; PLC_1 [CPU 1516-3 PN/DP] &gt; Program blocks &gt; Main [OB1]. The main window displays the 'Interface' table and the 'Network 1' ladder logic diagram. The 'Interface' table has the following data:</p> <table border="1"><thead><tr><th>Name</th><th>Data type</th><th>Comment</th></tr></thead><tbody><tr><td>Initial_Call</td><td>Bool</td><td>Initial call of this OB</td></tr><tr><td>Remanence</td><td>Bool</td><td>=True, if remanent data are available</td></tr></tbody></table> <p>The 'Network 1' diagram shows the 'UPS1600' function block with the following connections:</p> <ul style="list-style-type: none"><li>EN: 287</li><li>HW_IO: 287</li><li>UPS_execute: M0.1</li><li>Tag_2: reset</li><li>UPS_ready_for_reset: M0.0</li><li>Tag_1: Tag_1</li></ul> <p>The parameter 'M0.0' for UPS_ready_for_reset is highlighted with a red box.</p> <p><b>Note</b> Further information about the block parameters is available in <a href="#">Chapter 5.3</a>.</p>	Name	Data type	Comment	Initial_Call	Bool	Initial call of this OB	Remanence	Bool	=True, if remanent data are available
Name	Data type	Comment								
Initial_Call	Bool	Initial call of this OB								
Remanence	Bool	=True, if remanent data are available								

## 5 Application of the Function Block under STEP 7 V12

### 5.5 Integrating the function block

No.	Procedure
6.	<p>Connect the block parameter "UPS_execute_reset" with a tag of your project that you use to switch off the UPS when your plant is in a condition in which it can be shut down.</p> <p>In this example, the tag "Tag_2 (M0.1)" is used.</p> 
7.	<p>Connect the block parameter "UPS_DataM" with the "UPS_DataM" tag from DB161 "UPS1600_Data".</p> 



## 6 Faceplates for the UPS1600

The HMI faceplates' task is to display various actual values and states of the SITOP UPS1600 on an HMI control panel / runtime system.

### 6.1 Faceplate "Faceplate\_UPS1600\_State"

#### Description of the faceplate

The faceplate "Faceplate\_UPS1600\_State" provides the following functions:

- Activation of the visibility of the faceplate "Faceplate\_UPS1600"
- Status indication of the SITOP UPS1600

The functions are described in detail in the following sections.

#### Activation of the visibility of the faceplate "Faceplate\_UPS1600"

A click on the faceplate "Faceplate\_UPS1600\_State" activates the visibility of the faceplate "Faceplate\_UPS1600".

#### Note


The visibility of the faceplate "Faceplate\_UPS1600" can just be activated via the faceplate "Faceplate\_UPS1600\_State". Deactivation of the visibility is only possible in the faceplate "Faceplate\_UPS1600".

#### Status indication of the SITOP UPS1600

The faceplate "Faceplate\_UPS1600\_State" evaluates the following parameters of the SITOP UPS1600:

- New\_alarms\_pending  
(No new alarms pending / New alarms pending)
- Buffer\_mode  
(Normal mode / Buffer mode)
- Ready\_for\_buffering  
(Ready for buffering / Not ready for buffering)

The status indication is evaluated via a script.



The following table shows all parameter states with the corresponding color dynamization of the rectangle.

Table 6-1

Color of rectangle	Buffer_mode		New_alarms_pending		Ready_for_buffering	
	Normal mode	Buffer mode	No new alarms	New alarms	Ready for buffering	Not ready for buffering
Green	x		x		x	
Red	x		x			x
Red	x			x	x	

## 6 Faceplates for the UPS1600

### 6.1 Faceplate "Faceplate\_UPS1600\_State"

Color of rectangle	Buffer_mode		New_alarms_pending		Ready_for_buffering	
	Normal mode	Buffer mode	No new alarms	New alarms	Ready for buffering	Not ready for buffering
Red	x			x		x
Red		x	x		x	
Red		x	x			x
Red		x		x	x	
Red		x		x		x

#### Interface description

The following chapter describes the design of the dynamic interface of the faceplate.

#### Note

If you do not use the faceplates as master copy from the project library, the dynamic interface must be connected separately with the respective WinCC flexible tags.

The "Visibility" section of the dynamic interface contains all tags used to control the visibility of the faceplate.

Table 6-2


Dynamic interface faceplate	WinCC flexible tag
Faceplate_intern_button_alarms	Faceplate_intern_visibility_alarms
Connection	Internal tag
Data type	Integer
Faceplate_intern_button_headline	Faceplate_intern_visibility_headline
Connection	Internal tag
Data type	Integer
Faceplate_intern_button_state	Faceplate_intern_visibility_state
Connection	Internal tag
Data type	Integer
Faceplate_intern_button_trends	Faceplate_intern_visibility_trends
Connection	Internal tag
Data type	Integer
Faceplate_intern_visibility_main	Faceplate_intern_visibility_main
Connection	Internal tag
Data type	Integer
Faceplate_intern_visibility_min	Faceplate_intern_visibility_min
Connection	Internal tag
Data type	Integer

## 6.2 Faceplate "Faceplate\_UPS1600"

### Description of the faceplate

The faceplate "Faceplate\_UPS1600" visualizes parameters of the SITOP UPS1600 on an HMI control panel.

Figure 6-1



The parameters of the SITOP UPS1600 are distributed over three tabs, which can be opened in the faceplate by clicking on the relevant tab:

- Status
- Trends
- Alarms

The contents of the tabs and the parameters displayed there are described in detail in the following sections.

### Visibility of the faceplate "Faceplate\_UPS1600"


The visibility of the faceplate "Faceplate\_UPS1600" is activated via the faceplate "Faceplate\_UPS1600\_State".

#### Note

Further information on the faceplate "Faceplate\_UPS1600\_State" is available in [Chapter 6.1](#).

For deactivation of the visibility of the "Faceplate\_UPS1600", an "X" button is provided in the top right corner of the faceplate. By pressing this button the visibility is deactivated.

Figure 6-2




### 6.2.1 "State" tab

The "State" tab provides the menu items "Information > Overview" and "Device > Information".

#### Information > Overview

Under this menu item, information about the operating state and battery state of the SITOP UPS1600 is displayed.

Figure 6-3



The following parameters are displayed under this menu:

Table 6-3

Display name	Parameter of the UPS
Input voltage	Input_voltage
Output voltage	Output_voltage
Output current	Output_current

## 6 Faceplates for the UPS1600

### 6.2 Faceplate "Faceplate\_UPS1600"

Display name	Parameter of the UPS
Battery voltage	Battery_voltage
Battery charge	Battery_charge_level
End-of-charge voltage	End_of_charge_voltage
Charge current	Measured_charge_current
Normal mode / Buffer mode	Buffer_mode
Ready for buffering/ Not ready for buffering	Ready_for_buffering
No new alarms pending/ New alarms pending	New_alarms_pending

The values of the parameters "Buffer\_mode", "Ready\_for\_buffering", and "New\_alarms\_pending" are output via symbolic I/O fields. In addition to this output, a rectangle is displayed in front of each symbolic I/O field, which is subject to color dynamization dependent on the parameter value.

Figure 6-4

The screenshot shows the Siemens SITOP UPS1600 web interface. The 'State' tab is active, displaying 'UPS state information'. Three parameters are listed with green status indicators: 'Normal mode', 'Ready for buffering', and 'No new alarms pending'. Below this, 'Battery state information' is shown with values: 'Battery voltage: 25.18 V', 'End of charge voltage: 26.00 V', 'Battery charge: 99%', and 'Charge current: 0.09 A'.

The following table shows the possible parameter states with the corresponding color dynamization of the rectangle.

Table 6-4

Parameter	State / display name	Color of rectangle
Normal mode	Normal mode	Green
	Buffer mode	Yellow
Ready for buffering	Ready for buffering	Green
	Not ready for buffering	Red
No new alarms pending	No new alarms pending	Green
	New pending alarms	Yellow

#### Note

All I/O fields within the faceplate just output values. It is not possible to input values.



**Device > Information**

Under this menu, general information about the SITOP UPS1600 is displayed.

Figure 6-5

SIEMENS		SITOP UPS1600 <input type="button" value="x"/>
State	Trends	Alarms
		dc-ups-10a
Information	Device information	
Overview	Device name:	dc-ups-10a
Device	Order number:	6EP4134-3AB00-2AY0
Information	Serial number:	Q6D8AZMPFQX
	HW revision:	256
	SW revision:	268

The following table shows all parameters displayed under this menu:

Table 6-5


Display name	Parameter of the UPS
Device name	Device_name
Order number	Order_number
Serial number	Serial_number
HW revision	HW_revision
SW revision	SW_revision

### 6.2.2 "Trends" tab

On the "Trends" tab, the following parameters of the SITOP UPS1600 are displayed in a trend curve.

- Input voltage
- Output voltage
- Output current
- Battery voltage
- Charge current

Figure 6-6



The time range of the X axis of the trend curve is 200 seconds. The trend variables used have an acquisition cycle of 1 second and are refreshed cyclically.


Table 6-6

Display name	Parameter of the UPS	Color	Unit
Input voltage	Input_voltage	Green	Volt
Output voltage	Output_voltage	Black	Volt
Output current	Output_current	Red	Ampere
Battery voltage	Battery_voltage	Orange	Volt
Charge current	Measured_charge_current	Blue	Ampere

### 6.2.3 "Alarms" tab

On the "Alarms" tab, it is possible to display the PROFINET diagnostic messages of the SITOP UPS1600.

Figure 6-7



When clicking the "show pending alarms" and "show alarm history" buttons, two separate message windows are opened.

The message window for the "Pending alarms" allows for displaying all currently pending PROFINET diagnostic messages of the SITOP UPS1600. The message window for the "Alarm history" allows for displaying all PROFINET diagnostic messages of the SITOP UPS1600 stored in the internal message buffer of the used HMI control panel.

#### Prerequisites for displaying the PROFINET diagnostic messages

In order to display the PROFINET diagnostic messages of the SITOP UPS1600 within the faceplate, the respective WinCC flexible / WinCC TIA Portal project must already be configured for the display of PROFINET diagnostic messages.

A list of the PROFINET diagnostic messages of the SITOP UPS1600 is available in the [SITOP UPS1600 User Manual](#) in Chapter 3.2.1.

# 7 Application of the Faceplates in WinCC flexible

## 7.1 Preconditions

The following requirements must be met to use the faceplates in WinCC flexible 2008 SP3.

- The GSD file of the SITOP UPS1600 is installed in STEP 7 V5.5 and the UPS is configured as PROFINET node in the HW configuration of the CPU.
- Already configured S7 communication between the SITOP UPS1600 and CPU.
- All program blocks from the library "UPS1600 STEP 7 V5\_5" are integrated into the STEP 7 application program and executable.
- The library "UPS1600 library WinCC flexible 2008" for WinCC flexible 2008 SP3 is available.

### Supported control panels

The use of the faceplates is approved for the following control panels:

- TP270 10"
- OP270 10"
- MP270 10" Touch
- MP277 8" Touch / Key
- MP277 10" Touch / Key
- MP377 Touch / Key
- WinCC flexible Runtime 2008 SP3

### Supported languages

The faceplates support the following languages:

- English (USA)
- German (Germany)
- Chinese (PR China)

### Note regarding the application

The faceplates "Faceplate\_UPS1600" and "Faceplate\_UPS1600\_State" can only be used in combination. Using just one of the faceplates separately is not possible.

## 7.2 Library for WinCC flexible

The library "UPS1600 library WinCC flexible 2008" for WinCC flexible 2008 SP3 comprises the following objects:

Table 7-1

Name	Type	Description
HMI Faceplates (WinCC flexible 2008)	Faceplates	Comprises the two faceplates "Faceplate_UPS1600" and "Faceplate_UPS1600_State".
HMI VB-Script	VB script	-
HMI Tag table	Tag folder	Separate tag folder with all required tags
HMI Alarm views	Message window	Comprises two message windows for displaying the diagnostic messages of the UPS1600.

The contents of the objects are described in detail in the following sections.

### HMI Faceplates (WinCC flexible 2008)

This object comprises the two faceplates "Faceplate\_UPS1600" and "Faceplate\_UPS1600\_State". The two faceplates are combined to one master copy in the library. Therefore, subsequent connection of the symbolic interfaces of the faceplates is not necessary.

### HMI VB-Script

This object comprises the VB script "UPS1600\_Faceplate\_state\_min".

This script controls the status indication of the SITOP UPS1600 in the faceplate "Faceplate\_UPS1600\_State".

### HMI Tag table

This object in the library contains the tag folder "HMI Tag table". This folder comprises all tags required for the use of the faceplates.

The control tags in this folder are already equipped with a connection to the data block DB161. The default connection name is "Connection\_1".

After having integrated the tags from the library it might be necessary to adapt this connection name in your project.

### HMI Alarm views

This object comprises two message windows which can be used to display the PROFINET diagnostic messages of the SITOP UPS1600.

## 7.3 Integrating the faceplates

The following sections describe all steps required to integrate the faceplates into a WinCC flexible 2008 SP3 project.

Hardware used in this description:


- MP277 8" Touch

An overview of the supported HMI control panels is available in [Chapter 7.1](#).

### Opening the library


The following steps describe how to open a library in WinCC flexible 2008 SP3.

Table 7-2

No.	Procedure
1.	Open the WinCC flexible project into which you want to insert the faceplates.
2.	<p>Open the "Library" menu in the Tools window.</p>  <p>The screenshot shows the WinCC flexible Advanced - Factory - SIMATIC HMI-Station(1) interface. The main workspace displays a SIMATIC HMI screen with a cyan border. The Tools window on the right is open, and the 'Library' menu item is highlighted with a red rectangle. Below the Tools window, the 'Screen_1 (Screen)' settings panel is visible, showing fields for Name (Screen_1), Number (1), and a checked 'Use template' checkbox.</p>


## 7 Application of the Faceplates in WinCC flexible

### 7.3 Integrating the faceplates

No.	Procedure
3.	<p data-bbox="469 306 1230 336">In the toolbar of the Tools window, click the button for opening a library.</p>  <p data-bbox="469 1182 935 1211">The "Open global library" dialog box opens.</p>
4.	<p data-bbox="469 1225 1289 1281">Open the "Look in:" drop-down list and navigate to the storage location of the library "UPS1600 library WinCC flexible 2008" on your computer.</p>

## 7 Application of the Faceplates in WinCC flexible

### 7.3 Integrating the faceplates


No.	Procedure
5.	<p>Select the data "UPS1600 library WinCC flexible 2008.wif" and then click the "Open" button.</p>  <p>The library is now opened and can be used.</p>



**Inserting faceplates into a project**



The following table describes the procedure for integrating the faceplates from the library "UPS1600 library WinCC flexible 2008" into an existing WinCC flexible project.

Table 7-3

No.	Procedure
1.	Open the WinCC flexible project into which you want to insert the faceplates.
2.	Open the library "UPS1600 library WinCC flexible 2008" in your project.
3.	<p>In your project, open the screen into which you want to insert the faceplates.</p> 
4.	Select the folder "HMI Faceplates (WinCC flexible 2008)" of the library.



## 7 Application of the Faceplates in WinCC flexible

### 7.3 Integrating the faceplates

No.	Procedure
5.	<p>Drag and drop the folder "HMI Faceplates (WinCC flexible 2008)" to the open screen.</p>  <p>The faceplates are then inserted into the screen.</p> <p><b>Note</b> The tag folder "HMI Tag table" and the VB script "HMI VB-Script" are automatically integrated into the project, too.</p>
6.	In the Project window, open the screen template "Screens > Template".
7.	Select the folder "HMI Alarm views" of the library.
8.	<p>Drag and drop the folder "HMI Alarm views" to the template.</p>  <p>Two message windows are then inserted into the template.</p>
9.	In the Project window, open the folder "Communication > Tags > Faceplates_UPS1600_Tags".



## 7 Application of the Faceplates in WinCC flexible

### 7.3 Integrating the faceplates

No.	Procedure
10.	<p>Check the connection name entered for the control tags. The connection name must be identical with the name of the connection you created for the configured connection to your controller.</p>  <p><b>Note</b> Further information on this connection name is available in <a href="#">Chapter 7.2</a> under "HMI Tag table".</p>
11.	<p>Select the tag "Faceplate_intern_alarmview_buffer" and open the folder "Events &gt; Change value" in the properties window.</p>
12.	<p>Under the function "ShowAlarmWindow", open the drop-down list and select the entry "Vorlage_Meldefenster_UPS_2".</p> 
13.	<p>Select the tag "Faceplate_intern_alarmview_pending" and open the folder "Events &gt; Change value" in the properties window.</p>

## 7 Application of the Faceplates in WinCC flexible

### 7.3 Integrating the faceplates

No.	Procedure
14.	<p>Under the function "ShowAlarmWindow", open the drop-down list and select the entry "Vorlage_Meldefenster_UPS_1".</p> 
15.	In the Project window, open the folder "Communication > Connections".
16.	<p>Delete the created connection "Connection_1" if you are using a different connection.</p>  <p><b>Note</b> This connection "Connection_1" is created automatically when inserting the tags into the tag folder "Faceplates_UPS1600_Tags". If you have already created a different connection, the "Connection_1" must be deleted.</p>

The integration of the faceplates is thus completed.

### Displaying the PROFINET diagnostic messages

In order to display the PROFINET diagnostic messages of the SITOP UPS1600 within the faceplate, the respective WinCC flexible project must already be configured for the display of PROFINET diagnostic messages.

Information on the display and configuration of diagnostic messages in WinCC flexible is available under the entry ID: [22533916](#).

Further notes regarding the PROFINET diagnostic messages of the SITOP UPS1600 are available in the [SITOP UPS1600 User Manual](#) in Chapter 3.2.1.

## 7.4 Interface description


The following chapter describes the design of the dynamic interface of the faceplate. The interface is subdivided into the sections "Visibility" and "Values UPS1600".

**Note** If you do not use the faceplates as master copy from the project library, the dynamic interface must be connected separately with the respective WinCC flexible tags.

### Visibility

This section of the dynamic interface comprises all tags used to control the visibility of the faceplate.

Figure 7-1



## 7 Application of the Faceplates in WinCC flexible

### 7.4 Interface description

Table 7-4

<b>Dynamic interface faceplate</b>	<b>WinCC flexible tag</b>
Faceplate_intern_visibility_alarm	Faceplate_intern_visibility_alarm
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_headline	Faceplate_intern_visibility_headline
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_main	Faceplate_intern_visibility_main
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_state	Faceplate_intern_visibility_state
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_trends	Faceplate_intern_visibility_trends
Connection	Internal tag
Data type	Int
Faceplate_intern_alarmview_buffer	Faceplate_intern_alarmview_buffer
Connection	Internal tag
Data type	Int
Faceplate_intern_alarmview_pending	Faceplate_intern_alarmview_pending
Connection	Internal tag
Data type	Int

**Values UPS1600**

This section of the dynamic interface comprises all tags used to display the parameters of the SITOP UPS1600 within the faceplate.

Figure 7-2




Table 7-5

Dynamic interface faceplate	WinCC flexible tag
Battery_charge_level	UPS1600_Infos.Battery_charge_level
Data type	Byte
Address	DB 161 DBB 171
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use

## 7 Application of the Faceplates in WinCC flexible

### 7.4 Interface description

Dynamic interface faceplate	WinCC flexible tag
<b>Battery_voltage</b>	UPS1600_Infos.Battery_voltage
Data type	Int
Address	DB 161 DBW 162
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
<b>Buffer_mode</b>	UPS1600_Infos.Buffer_mode
Data type	Byte
Address	DB 161 DBB 168
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
<b>Device_name</b>	UPS1600_Infos.Device_name
Data type	StringChar
Address	DB 161 DBB 72
Length	30
Acquisition cycle	1s
Acquisition mode	Cyclic on use
<b>End_of_charge_voltage</b>	UPS1600_Infos.End_of_charge_voltage
Data type	Int
Address	DB 161 DBW 2
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
<b>HW_revision</b>	UPS1600_Infos.HW_revision
Data type	Int
Address	DB 161 DBW 2
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
<b>Input_voltage</b>	UPS1600_Infos.Input_voltage
Data type	Int
Address	DB 161 DBW 154
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
<b>Measured_charge_current</b>	UPS1600_Infos.Measured_charge_current
Data type	Int
Address	DB 161 DBW 160
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Linear scaling	10 : 1



## 7 Application of the Faceplates in WinCC flexible

### 7.4 Interface description

Dynamic interface faceplate	WinCC flexible tag
New_alarms_pending	UPS1600_Infos.New_alarms_pending
Data type	Byte
Address	DB 161 DBB 170
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Order_number	UPS1600_Infos.Order_number
Data type	StringChar
Address	DB 161 DBB 12
Length	30
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Output_current	UPS1600_Infos.Output_current
Data type	Int
Address	DB 161 DBW 164
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Linear scaling	10 : 5
Output_voltage	UPS1600_Infos.Output_voltage
Data type	Int
Address	DB 161 DBW 156
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Ready_for_buffering	UPS1600_Infos.Ready_for_buffering
Data type	Byte
Address	DB 161 DBB 169
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Serial_number	UPS1600_Infos.Serial_number
Data type	StringChar
Address	DB 161 DBB 42
Length	30
Acquisition cycle	1s
Acquisition mode	Cyclic on use
SW_revision	UPS1600_Infos.SW_revision
Data type	Int
Address	DB 161 DBW 8
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use

## 8 Application of the Faceplates in WinCC Comfort/Advanced V12

### 8.1 Preconditions

The following requirements must be met to use the faceplates in WinCC Comfort/Advanced V12 SP1.

- The Hardware Support Package for the SITOP UPS1600 is installed in STEP 7 V12.
- Already existing S7 communication between the SITOP UPS1600 and SIMATIC S7 controller.
- All program blocks for STEP 7 V12 from the library "UPS1600 library TIA Portal V12 SP1" are integrated into the application program and executable.
- The library "UPS1600 library TIA Portal V12 SP1" is available.

#### Supported control panels

The use of the faceplates is approved for the following control panels:

- TP700 Comfort / KP700 Comfort
- TP900 Comfort / KP900 Comfort
- TP1200 Comfort / KP1200 Comfort
- TP1500 Comfort / KP1500 Comfort
- TP1900 Comfort
- TP2200 Comfort
- MP277 8" Touch / MP277 8" Key
- MP277 10" Touch / MP277 10" Key
- MP377 Touch / Key
- WinCC RT Advanced V12

#### Supported languages

The faceplates support the following languages:

- English (USA)
- German (Germany)
- Chinese (PR China)

#### Note regarding the application

The faceplates can only be used in combination. Using just one of the faceplates separately is not possible.

## 8.2 Library for WinCC Comfort/Advanced

The following objects are part of the master copy "UPS1600 HMI Faceplates (WinCC Comfort/Advanced V12)" in the library "UPS1600 library TIA Portal V12".

Table 8-1

Name	Type	Description
HMI Faceplates (WinCC Comfort/Advanced V12)	Faceplates	Comprises the two faceplates "Faceplate_UPS1600" and "Faceplate_UPS1600_State".
HMI VB-Script	VB script	-
HMI Tag table	Tag folder	Separate tag folder with all required tags
HMI Alarm views	Message window	Comprises two message windows for displaying the diagnostic messages of the UPS1600.

The contents of the objects are described in detail in the following sections.

### HMI Faceplates (WinCC Comfort/Advanced V12)

This object comprises the two faceplates "Faceplate\_UPS1600" and "Faceplate\_UPS1600\_State". The two faceplates are combined to one master copy in the library. Therefore, subsequent connection of the symbolic interfaces of the faceplates is not necessary.

### HMI VB-Script

This object comprises the VB script "UPS1600\_Faceplate\_state\_min". This script controls the status indication of the SITOP UPS1600 in the faceplate "Faceplate\_UPS1600\_State".

### HMI Tag table

This object in the library contains the tag folder "HMI Tag table". This folder comprises all tags required for the use of the faceplates.

The control tags in this folder are already equipped with a connection to the data block DB161 and a controller connection. The default connection name is "Connection\_1".

After having integrated the tags from the library it might be necessary to adapt this connection name in your project.

### HMI Alarm views

This object comprises two message windows which can be used to display the PROFINET diagnostic messages of the SITOP UPS1600.

### 8.3 Integrating the faceplates

The following sections describe all steps required to integrate the faceplates into a WinCC Comfort/Advanced V12 project.

Hardware used in this description:


- TP1200 Comfort

An overview of the supported HMI control panels is available in [Chapter 8.1](#).



#### Opening the library in WinCC V12

The following steps describe how to open a library in WinCC Professional V12.


Table 8-2

No.	Procedure
1.	<p>Open WinCC V12 in the Project view.</p>  <p>The screenshot shows the Siemens WinCC V12 interface. The 'Project tree' on the left shows the 'Factory' folder expanded. The 'Properties' window is open, displaying the message: 'No properties available. No properties can be shown at the moment. There is either no object selected or the selected object does not have any displayable properties.' The 'Find and replace' dialog is also visible on the right side of the interface.</p>

8.3 Integrating the faceplates

No.	Procedure
2.	<p>Open the "Libraries" task card.</p> 
3.	<p>Under the "Global libraries" palette, click on the second icon from the left to open a global library.</p>  <p>The "Open global library" dialog box opens.</p>

8.3 Integrating the faceplates



No.	Procedure
4.	In the "Look in:" drop-down list, select the storage location of the library on your computer.
5.	<p>Click the "Open" button.</p>  <p>The library is opened and displayed in the "Global libraries" palette.</p>

**Inserting faceplates into a project**



The following table describes the procedure for integrating the faceplates from the master copy "UPS1600 HMI Faceplates (WinCC Comfort/Advanced V12)" of the library "UPS1600 library TIA Portal V12" into an existing WinCC V12 project.

8.3 Integrating the faceplates

Table 8-3

No.	Procedure
1.	<p>In the Project view, open the project into which you want to insert the faceplate.</p>  <p>The screenshot shows the Siemens TIA Portal interface. The 'Project tree' on the left is expanded to 'Factory'. The 'Properties' window is open, showing a message: 'No 'properties' available. No 'properties' can be shown at the moment. There is either no object selected or the selected object does not have any displayable properties.'</p>
2.	<p>Open the global library "UPS1600 library TIA Portal V12".</p>  <p>The screenshot shows the 'Libraries' pane in TIA Portal. Under 'Global libraries', the 'UPS1600 library TIA Portal V12 SP1' is selected and highlighted with a red box. Below it are sub-folders: 'Types', 'Master copies', and 'Common data'.</p>



8.3 Integrating the faceplates

No.	Procedure
3.	<p>Open the folder "Master copies &gt; UPS1600 HMI Faceplates (WinCC Comfort/Advanced V12)" in the library.</p> 
4.	<p>Select the folder "HMI Tag table" in the library.</p>
5.	<p>Drag and drop the folder "HMI Tag table" to the "HMI tags" folder in the project folder of your control panel.</p> 
6.	<p>Select the folder "HMI VB-Script" in the library.</p>





## 8 Application of the Faceplates in WinCC Comfort/Advanced V12


### 8.3 Integrating the faceplates


No.	Procedure
7.	<p>Drag and drop the folder "HMI VB-Script" to the folder "Scripts &gt; VB scripts" in the project folder of your control panel.</p> 
8.	<p>In the project folder, open the "Global screen" under "Screen management".</p>
9.	<p>Select the folder "HMI Alarm views" in the library.</p>
10.	<p>Drag and drop the folder "HMI Alarm views" to the Global screen.</p> 
11.	<p>In your project, open the screen into which you want to insert the faceplates.</p>
12.	<p>Select the folder "HMI Faceplates (WinCC Comfort/Advanced V12)" in the library.</p>

## 8 Application of the Faceplates in WinCC Comfort/Advanced V12

### 8.3 Integrating the faceplates

No.	Procedure																																																		
13.	<p>Drag and drop the folder "HMI Faceplates (WinCC Comfort/Advanced V12)" to the screen.</p>  <p>The screenshot shows the Siemens WinCC interface. The 'Libraries' pane on the right is expanded to 'UPS1600 HMI Faceplates (WinCC Co...'. A red arrow points from this folder to the 'Screen_1' workspace, indicating the drag-and-drop action.</p>																																																		
14.	<p>In the project folder, under "HMI tags &gt; UPS1600 HMI tag table", open the tag table "UPS1600 HMI tag table".</p>																																																		
15.	<p>Check the connection name entered for the control tags. The connection name must be identical with the name of the connection you created in your project for the configured connection to your controller.</p>  <p>The screenshot shows the 'UPS1600 HMI tag table' configuration window. A table lists various tags and their connections. The 'Connection' column shows 'HMI_Verbindung_1' for several tags. A dialog box for 'Connections' is open, showing 'HMI_connection_1' selected in the 'Name' field. The 'PLC tag' field is set to 'HMI_Verbindung_1'.</p> <table border="1" data-bbox="676 1263 1362 1599"> <thead> <tr> <th>Name</th> <th>Data type</th> <th>Connection</th> <th>PLC name</th> <th>PLC tag</th> </tr> </thead> <tbody> <tr> <td>Faceplate_intern_visibility_state</td> <td>Int</td> <td>&lt;internal tag&gt;</td> <td></td> <td>&lt;Und&gt;</td> </tr> <tr> <td>Faceplate_intern_visibility_trends</td> <td>Int</td> <td>&lt;internal tag&gt;</td> <td></td> <td>&lt;Und&gt;</td> </tr> <tr> <td>USV_Infos.Battery_charge_level</td> <td>Byte</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> <tr> <td>USV_Infos.Battery_voltage</td> <td>Int</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> <tr> <td>USV_Infos.Battery_voltage_Trend</td> <td>Int</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> <tr> <td>USV_Infos.Buffer_mode</td> <td>Byte</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> <tr> <td>USV_Infos.Device_name</td> <td>Array [0..29] of Char</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> <tr> <td>USV_Infos.End_of_charge_voltage</td> <td>Int</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> <tr> <td>USV_Infos.HW_revision</td> <td>Int</td> <td>HMI_Verbindung_1</td> <td></td> <td>UPS1</td> </tr> </tbody> </table>	Name	Data type	Connection	PLC name	PLC tag	Faceplate_intern_visibility_state	Int	<internal tag>		<Und>	Faceplate_intern_visibility_trends	Int	<internal tag>		<Und>	USV_Infos.Battery_charge_level	Byte	HMI_Verbindung_1		UPS1	USV_Infos.Battery_voltage	Int	HMI_Verbindung_1		UPS1	USV_Infos.Battery_voltage_Trend	Int	HMI_Verbindung_1		UPS1	USV_Infos.Buffer_mode	Byte	HMI_Verbindung_1		UPS1	USV_Infos.Device_name	Array [0..29] of Char	HMI_Verbindung_1		UPS1	USV_Infos.End_of_charge_voltage	Int	HMI_Verbindung_1		UPS1	USV_Infos.HW_revision	Int	HMI_Verbindung_1		UPS1
Name	Data type	Connection	PLC name	PLC tag																																															
Faceplate_intern_visibility_state	Int	<internal tag>		<Und>																																															
Faceplate_intern_visibility_trends	Int	<internal tag>		<Und>																																															
USV_Infos.Battery_charge_level	Byte	HMI_Verbindung_1		UPS1																																															
USV_Infos.Battery_voltage	Int	HMI_Verbindung_1		UPS1																																															
USV_Infos.Battery_voltage_Trend	Int	HMI_Verbindung_1		UPS1																																															
USV_Infos.Buffer_mode	Byte	HMI_Verbindung_1		UPS1																																															
USV_Infos.Device_name	Array [0..29] of Char	HMI_Verbindung_1		UPS1																																															
USV_Infos.End_of_charge_voltage	Int	HMI_Verbindung_1		UPS1																																															
USV_Infos.HW_revision	Int	HMI_Verbindung_1		UPS1																																															
<p><b>Note</b> Further information on this connection name is available in <a href="#">Chapter 8.2</a> under "HMI Tag table".</p>																																																			

No.	Procedure
16.	<p>The scaling of tags has been stored in the library.</p> <p>Enable the following tags for scaling:</p> <ul style="list-style-type: none"> <li>- UPS1600_Infos_Battery_voltage_trend</li> <li>- UPS1600_Infos_Input_voltage_trend</li> <li>- UPS1600_Infos_Measured_charge_current</li> <li>- UPS1600_Infos_Measured_charge_current_trend</li> <li>- UPS1600_Infos_Output_current</li> <li>- UPS1600_Infos_Output_current_trend</li> <li>- UPS1600_Infos_Output_voltage_trend</li> </ul> <ul style="list-style-type: none"> <li>• Click the "Properties" tab and then "Linear scaling".</li> <li>• Select the respective tag in the tag table.</li> <li>• Enable the checkbox left from the heading "Linear scaling".</li> <li>• Repeat the process until linear scaling is enabled for all tags mentioned above.</li> </ul> 

No.	Procedure
17.	<p>Right-click on the project folder and select the context menu item "Compile &gt; Software (rebuild all)".</p> 

The integration of the faceplates is thus completed.


**Displaying the PROFINET diagnostic messages**

In order to display the PROFINET diagnostic messages of the SITOP UPS1600 within the faceplate, the respective WinCC TIA Portal project must already be configured for the display of PROFINET diagnostic messages.

Information on the display and configuration of diagnostic messages in WinCC TIA Portal is available under the entry ID: [62121503](#).

**Note**

The activation of the PROFINET diagnostic messages of the SITOP UPS1600 can be found in the Device view of the UPS1600.



Further notes regarding the PROFINET diagnostic messages of the SITOP UPS1600 are available in the [SITOP UPS1600 User Manual](#) in Chapter 3.2.1.

## 8.4 Interface description

The following chapter describes the design of the dynamic interface of the faceplates.

### Note

If you do not use the faceplates as master copy from the project library, the dynamic interface must be connected separately with the respective WinCC (TIA Portal) tags.

### Faceplate "Faceplate\_UPS1600"

This section of the dynamic interface comprises all tags used to display the parameters of the SITOP UPS1600 within the faceplate.

Figure 8-1




Table 8-4

Dynamic interface faceplate	WinCC TIA Portal tag
Faceplate_intern_visibility_alarm	Faceplate_intern_visibility_alarm
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_headline	Faceplate_intern_visibility_headline
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_main	Faceplate_intern_visibility_main
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_state	Faceplate_intern_visibility_state
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_trends	Faceplate_intern_visibility_trends


8.4 Interface description

Dynamic interface faceplate	WinCC TIA Portal tag
Connection	Internal tag
Data type	Int

Faceplate "Faceplate\_UPS1600"

This section of the dynamic interface comprises all tags used to display the parameters of the SITOP UPS1600 within the faceplate.

Figure 8-2



## 8.4 Interface description

Table 8-5

Dynamic interface faceplate	WinCC TIA Portal tag
Battery_charge_level	UPS1600_Infos.Battery_charge_level
Data type	Byte
Address	DB 161 DBB 269
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Battery_voltage	UPS1600_Infos.Battery_voltage
Data type	Int
Address	DB 161 DBW 260
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Buffer_mode	UPS1600_Infos.Buffer_mode
Data type	Byte
Address	DB 161 DBB 266
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Device_name	UPS1600_Infos.Device_name
Data type	StringChar
Address	DB 161 DBB 170.0
Length	30
Acquisition cycle	1s
Acquisition mode	Cyclic on use
End_of_charge_voltage	UPS1600_Infos.End_of_charge_voltage
Data type	Int
Address	DB 161 DBW 100
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
HW_revision	UPS1600_Infos.HW_revision
Data type	Int
Address	DB 161 DBW 104
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use



## 8.4 Interface description

Dynamic interface faceplate	WinCC TIA Portal tag
Input_voltage	UPS1600_Infos.Input_voltage
Data type	Int
Address	DB 161 DBW 250
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Measured_charge_current	UPS1600_Infos.Measured_charge_current
Data type	Int
Address	DB 161 DBW 258
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Linear scaling	10 : 1
New_alarms_pending	UPS1600_Infos.New_alarms_pending
Data type	Byte
Address	DB 161 DBB 268
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Order_number	UPS1600_Infos.Order_number
Data type	StringChar
Address	DB 161 DBB 110.0
Length	30
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Output_current	UPS1600_Infos.Output_current
Data type	Int
Address	DB 161 DBW 262
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Linear scaling	10 : 5
Output_voltage	UPS1600_Infos.Output_voltage
Data type	Int
Address	DB 161 DBW 254
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use

## 8.4 Interface description

Dynamic interface faceplate	WinCC TIA Portal tag
Ready_for_buffering	UPS1600_Infos.Ready_for_buffering
Data type	Byte
Address	DB 161 DBB 267
Length	1
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Serial_number	UPS1600_Infos.Serial_number
Data type	StringChar
Address	DB 161 DBB 140.0
Length	30
Acquisition cycle	1s
Acquisition mode	Cyclic on use
SW_revision	UPS1600_Infos.SW_revision
Data type	Int
Address	DB 161 DBW 106
Length	2
Acquisition cycle	1s
Acquisition mode	Cyclic on use
Faceplate_intern_visibility_alarm	Faceplate_intern_visibility_alarm
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_headline	Faceplate_intern_visibility_headline
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_main	Faceplate_intern_visibility_main
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_state	Faceplate_intern_visibility_state
Connection	Internal tag
Data type	Int
Faceplate_intern_visibility_trends	Faceplate_intern_visibility_trends
Connection	Internal tag
Data type	Int
Faceplate_intern_alarmview_buffer	Faceplate_intern_alarmview_buffer
Connection	Internal tag
Data type	Int
Faceplate_intern_alarmview_pending	Faceplate_intern_alarmview_pending
Connection	Internal tag
Data type	Int

## 9 Application of the Screen Windows in WinCC V7.2

### 9.1 Preconditions

The following requirements must be met to use the screen windows in WinCC V7.2.

- The GSD file of the SITOP UPS1600 is installed in STEP 7 V5.5 and the UPS is configured as PROFINET node in the HW configuration of the CPU.
- Already configured S7 communication between the SITOP UPS1600 and CPU.
- All program blocks from the library "UPS1600 STEP 7 V5\_5" are integrated into the STEP 7 application program and executable.
- The library "UPS1600 library WinCC V7" for WinCC V7.2 is available.
- Existing WinCC OS (PC station) with already configured and active communication connection.

#### Supported control panels

The use of the screen windows is approved for the following control panels:

- WinCC V7.2 Runtime

#### Supported languages

The screen windows support the following languages:

- English (USA)
- German (Germany)
- Chinese (PR China)

### 9.2 Library for WinCC V7.2

The library "UPS1600 library WinCC V7" for WinCC V7.2 comprises the following file folders:

Table 9-1

Name	Type	Description
HMI Windows (WinCC V7.2)	Library (projectlibrary)	Comprises the screen windows "UPS1600" and "UPS1600_State".
HMI Tag table (WinCC V7.2)	Tags	Files for tag import
HMI Screens (WinCC V7.2)	Screens	Comprises the screens "UPS1600.pdl" and "UPS1600_State.pdl".

#### HMI Windows (WinCC V7.2)

This folder contains the WinCC V7.2 library "library.pxl".

This library comprises the screen windows "UPS1600" and "UPS1600\_State".

These screen windows display the screens "UPS1600.pdl" and "UPS1600\_State.pdl" in WinCC V7.2.

9.3 Integrating the screen windows

**HMI Tag table (WinCC V7.2)**

This folder contains the files "UPS1600\_Tags\_cex.csv", "UPS1600\_Tags\_dex.csv", and "UPS1600\_Tags\_vex.csv".

These files comprise all tags required for the functioning of the screen windows. They are imported into a WinCC V7.2 project using the smart tool "Tag Export Import".

**HMI Screens (WinCC V7.2)**

This folder contains the screens "UPS1600.pdl" and "UPS1600\_State.pdl". These screens are displayed in the screen windows "UPS1600" and "UPS1600\_State".

**9.3 Integrating the screen windows**

The following sections describe all steps required to integrate the screen windows into a WinCC V7.2 project.


Target system used in this description:

- WinCC V7.2 Runtime

**Inserting the project screens**


The following steps describe how to copy the screens "UPS1600.pdl" and "UPS1600\_State.pdl" from the library folder "HMI Screens (WinCC V7.2)" to the project directory GraCS of your WinCC project.

Table 9-2

No.	Procedure
1.	<p>Open the project folder "GraCS" in your project directory.                      In this description, the path to the project folder "GraCS" is:                      C:\Program Files\Siemens\Step7\S7Proj\Example\wincproj\OS(1)\GraCS</p> 

## 9 Application of the Screen Windows in WinCC V7.2


### 9.3 Integrating the screen windows

No.	Procedure
2.	<p>Insert the screens "UPS1600.pdl" and "UPS1600_State.pdl" from the library folder "HMI Screens (WinCC V7.2)" into the project folder "GraCS".</p>  <p>The screens are now included in the WinCC V7.2 project.</p>

### Configuring screen windows



The following steps describe how to copy the library "library.pxl" from the library folder "HMI Windows (WinCC V7.2)" to the project directory "Library" of your WinCC project.

Table 9-3

No.	Procedure
1.	<p>Open the project folder "Library" in your project directory. In this description, the path to the project folder "Library" is: C:\Program Files\Siemens\Step7\S7Proj\Example\wincproj\OS(1)\Library</p> 



## 9 Application of the Screen Windows in WinCC V7.2

### 9.3 Integrating the screen windows

No.	Procedure
2.	<p>Insert the library "library.pxl" from the library folder "HMI Windows (WinCC V7.2)" into the project folder "Library" and overwrite the existing "library.pxl" file.</p>  <p>The screen windows are now included in your WinCC project in the project library.</p>
3.	<p>Open the WinCC project.</p> 



## 9 Application of the Screen Windows in WinCC V7.2

### 9.3 Integrating the screen windows

No.	Procedure												
4.	<p>Open the screen in which you want to configure the screen windows. In this example, the screen name is "Startscreen.pdl".</p>  <p>The screenshot shows the WinCC Explorer interface. The left pane displays a tree view of the project structure under 'OS(1) Graphics Designer'. The right pane shows a table of files:</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Last Change</th> </tr> </thead> <tbody> <tr> <td>Startscreen.PDL</td> <td>Process picture (start pi...</td> <td>2/6/2014 2:16:12 PM</td> </tr> <tr> <td>UPS1600.Pdl</td> <td>Process picture</td> <td>2/5/2014 3:33:10 PM</td> </tr> <tr> <td>UPS1600_State.Pdl</td> <td>Process picture</td> <td>2/5/2014 3:33:08 PM</td> </tr> </tbody> </table> <p>The 'Startscreen.PDL' file is highlighted with a red rectangular box.</p>	Name	Type	Last Change	Startscreen.PDL	Process picture (start pi...	2/6/2014 2:16:12 PM	UPS1600.Pdl	Process picture	2/5/2014 3:33:10 PM	UPS1600_State.Pdl	Process picture	2/5/2014 3:33:08 PM
Name	Type	Last Change											
Startscreen.PDL	Process picture (start pi...	2/6/2014 2:16:12 PM											
UPS1600.Pdl	Process picture	2/5/2014 3:33:10 PM											
UPS1600_State.Pdl	Process picture	2/5/2014 3:33:08 PM											
5.	<p>In the "Library" detail window, open the project library "UPS1600 library WinCC V7.2".</p>  <p>The screenshot shows the Graphics Designer interface for 'Startscreen.PDL'. The 'Library' window is open at the bottom, displaying a list of libraries:</p> <table border="1"> <thead> <tr> <th>Name</th> <th>Size</th> <th>Last Change</th> </tr> </thead> <tbody> <tr> <td>UPS1600</td> <td>479</td> <td>05.02.14 14:56</td> </tr> <tr> <td>UPS1600_State</td> <td>511</td> <td>05.02.14 14:56</td> </tr> </tbody> </table> <p>The 'UPS1600 library WinCC V7.2' entry is highlighted with a red rectangular box. The main workspace shows a grid and various drawing tools on the right.</p>	Name	Size	Last Change	UPS1600	479	05.02.14 14:56	UPS1600_State	511	05.02.14 14:56			
Name	Size	Last Change											
UPS1600	479	05.02.14 14:56											
UPS1600_State	511	05.02.14 14:56											

## 9 Application of the Screen Windows in WinCC V7.2

### 9.3 Integrating the screen windows

No.	Procedure									
6.	<p>Select the entry "UPS1600" and drag and drop it to the screen.</p>  <p>The screenshot shows the WinCC Graphics Designer interface. The 'Library' pane at the bottom is open, displaying a table of objects. The 'UPS1600' entry is highlighted with a red box. A red arrow points from this entry to the 'UPS1600' object on the screen canvas. The 'Standard' pane on the right shows various object types like Line, Polygon, Polyline, etc.</p> <table border="1" data-bbox="746 846 1173 929"><thead><tr><th>Name</th><th>Size</th><th>Last Change</th></tr></thead><tbody><tr><td>UPS1600</td><td>479</td><td>05.02.14 14:56</td></tr><tr><td>UPS1600_State</td><td>511</td><td>05.02.14 14:56</td></tr></tbody></table>	Name	Size	Last Change	UPS1600	479	05.02.14 14:56	UPS1600_State	511	05.02.14 14:56
Name	Size	Last Change								
UPS1600	479	05.02.14 14:56								
UPS1600_State	511	05.02.14 14:56								
7.	<p>Select the entry "UPS1600_State" and drag and drop it to the screen.</p>  <p>The screenshot shows the WinCC Graphics Designer interface. The 'Library' pane at the bottom is open, displaying a table of objects. The 'UPS1600_State' entry is highlighted with a red box. A red arrow points from this entry to the 'UPS1600_State' object on the screen canvas. The 'Standard' pane on the right shows various object types like Line, Polygon, Polyline, etc.</p> <table border="1" data-bbox="746 1585 1173 1668"><thead><tr><th>Name</th><th>Size</th><th>Last Change</th></tr></thead><tbody><tr><td>UPS1600</td><td>479</td><td>05.02.14 14:56</td></tr><tr><td>UPS1600_State</td><td>511</td><td>05.02.14 14:56</td></tr></tbody></table> <p>The screen windows "UPS1600" and "UPS1600_State" are now included in your project and display the screens "UPS1600.pdl" and "UPS1600_State.pdl".</p>	Name	Size	Last Change	UPS1600	479	05.02.14 14:56	UPS1600_State	511	05.02.14 14:56
Name	Size	Last Change								
UPS1600	479	05.02.14 14:56								
UPS1600_State	511	05.02.14 14:56								







9.3 Integrating the screen windows



Importing tags



The following steps describe how to import the files from the library folder "HMI Tag table (WinCC V7.2)" into the WinCC project.



Table 9-4

No.	Procedure
1.	<p>Save the folder "HMI Tag table (WinCC V7.2)" from the library on your hard disk. In this description, the path to the folder "HMI Tag table (WinCC V7.2)" is: C:\Users\Admin\Downloads\HMI Tag table (WinCC V7.2)</p> 
2.	<p>Open the WinCC project.</p> 

No.	Procedure
3.	<p>Open the smarttool "TAG Export Import" under "Windows Start &gt; Siemens Automation &gt; SIMATIC &gt; WinCC &gt; Tools".</p>  <p>The screenshot shows a Windows Start menu with the following items: Produkt-Hinweise, ProSave, S7-PCT, SIMATIC NET, STEP 7, WinCC, Autostart, WinCC Explorer, WinCC Information System, Tools, Channel Diagnosis, Communication Configuratio, Cross Reference Assistant, Dynamic Wizard Editor, License Analysis, Project Duplicator, Project Migrator, TAG Export Import (highlighted with a red box), WinCC Documentation View, and WinCC TAG Simulator.</p>
4.	<p>Under "Path", just select the folder "HMI Tag Table (WinCC V7.2)" on your hard disk.</p>  <p>The screenshot shows the 'VARIABLE EXPORT / IMPORT' dialog box. The 'Path' field is highlighted with a red box and contains the text 'C:\Users\Admin\Downloads\HMI Tag table (WinCC V7.2)\'. The 'Filename' field contains 'OS(1)'. The 'Export' radio button is selected. The 'List separator' is set to a comma. The 'Execute' button is highlighted.</p>

No.	Procedure
5.	<p>Enter "UPS1600_Tags" under "Filename".</p>  <p>The screenshot shows the 'VARIABLE EXPORT / IMPORT' dialog box. The title bar reads 'VARIABLE EXPORT / IMPORT'. The main window contains the following elements:         <ul style="list-style-type: none"> <li>Project path: \\WIN-TE1TTAAD7P9\WinCC_Project_OS(1)_1\OS(1).mcp</li> <li>Instructions: 1. Select path and file, 2. Select export or import, 3. Press execute</li> <li>Path field: C:\Users\Admin\Downloads\HMI Tag table (WinCC V7.2)\</li> <li>Filename field: UPS1600_Tags (highlighted with a red rectangle)</li> <li>Radio buttons: Export (selected), Import, Import overwrite</li> <li>List separator: , (selected), Get from Regional Settings</li> <li>Show buttons: var, con, dex, diag, Help</li> <li>Bottom buttons: File selected, Execute, End</li> </ul> </p>
6.	<p>Click the "Import" radio button.</p>  <p>The screenshot shows the 'VARIABLE EXPORT / IMPORT' dialog box. The title bar reads 'VARIABLE EXPORT / IMPORT'. The main window contains the following elements:         <ul style="list-style-type: none"> <li>Project path: \\WIN-TE1TTAAD7P9\WinCC_Project_OS(1)_1\OS(1).mcp</li> <li>Instructions: 1. Select path and file, 2. Select export or import, 3. Press execute</li> <li>Path field: C:\Users\Admin\Downloads\HMI Tag table (WinCC V7.2)\</li> <li>Filename field: UPS1600_Tags</li> <li>Radio buttons: Export, Import (selected and highlighted with a red rectangle), Import overwrite</li> <li>List separator: , (selected), Get from Regional Settings</li> <li>Show buttons: var, con, dex, diag, Help</li> <li>Bottom buttons: File selected, Execute, End</li> </ul> </p>

No.	Procedure
7.	<p>Click the "Execute" button and confirm all subsequent prompts with "OK". All required tags are now imported into the project.</p>  <p>The screenshot shows the 'VARIABLE EXPORT / IMPORT' dialog box. The title bar reads 'VARIABLE EXPORT / IMPORT'. The main area contains instructions: '1. Select path and file', '2. Select export or import', and '3. Press execute'. The 'Path' field is set to 'C:\Users\Admin\Downloads\HMI Tag table (WinCC V7.2)\'. The 'Filename' field is 'UPS1600_Tags'. Under 'List separator', the 'Import' radio button is selected. At the bottom, the 'Execute' button is highlighted with a red rectangle.</p>
8.	<p>Click the "End" button.</p>  <p>The screenshot shows the same 'VARIABLE EXPORT / IMPORT' dialog box as in step 7. In this step, the 'End' button at the bottom right is highlighted with a red rectangle.</p>

No.	Procedure																																																																								
9.	<p>Navigate back to the WinCC project and open the "Tag Management".</p> 																																																																								
10.	<p>Check whether the structure "UPS1600 Tag table" has been created successfully.</p>  <table border="1" data-bbox="496 1115 1369 1608"> <thead> <tr> <th>Name</th> <th>Data Type</th> <th>Length</th> </tr> </thead> <tbody> <tr><td>1 UPS1600_1.UPS1600_Infos_Battery_charge_level</td><td>Unsigned 8-bit value</td><td>1</td></tr> <tr><td>2 UPS1600_1.UPS1600_Infos_Battery_voltage</td><td>Floating-point number 32-bit IEEE</td><td>4</td></tr> <tr><td>3 UPS1600_1.UPS1600_Infos_Buffer_mode</td><td>Unsigned 8-bit value</td><td>1</td></tr> <tr><td>4 UPS1600_1.UPS1600_Infos_Device_name_string</td><td>Text tag 8-bit character set</td><td>25</td></tr> <tr><td>5 UPS1600_1.UPS1600_Infos_End_of_charge_voltage</td><td>Floating-point number 32-bit IEEE</td><td>4</td></tr> <tr><td>6 UPS1600_1.UPS1600_Infos_HW_revision</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>7 UPS1600_1.UPS1600_Infos_Input_voltage</td><td>Floating-point number 32-bit IEEE</td><td>4</td></tr> <tr><td>8 UPS1600_1.UPS1600_Infos_Measured_charge_current</td><td>Floating-point number 32-bit IEEE</td><td>4</td></tr> <tr><td>9 UPS1600_1.UPS1600_Infos_New_alarms_pending</td><td>Unsigned 8-bit value</td><td>1</td></tr> <tr><td>10 UPS1600_1.UPS1600_Infos_Order_number_string</td><td>Text tag 8-bit character set</td><td>25</td></tr> <tr><td>11 UPS1600_1.UPS1600_Infos_Output_current</td><td>Floating-point number 32-bit IEEE</td><td>4</td></tr> <tr><td>12 UPS1600_1.UPS1600_Infos_Output_voltage</td><td>Floating-point number 32-bit IEEE</td><td>4</td></tr> <tr><td>13 UPS1600_1.UPS1600_Infos_Ready_for_buffering</td><td>Unsigned 8-bit value</td><td>1</td></tr> <tr><td>14 UPS1600_1.UPS1600_Infos_Serial_number_string</td><td>Text tag 8-bit character set</td><td>25</td></tr> <tr><td>15 UPS1600_1.UPS1600_Infos_SW_revision</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>16 UPS1600_1.UPS1600_intern_visibility_alarms</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>17 UPS1600_1.UPS1600_intern_visibility_headline</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>18 UPS1600_1.UPS1600_intern_visibility_main</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>19 UPS1600_1.UPS1600_intern_visibility_state</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>20 UPS1600_1.UPS1600_intern_visibility_trends</td><td>Unsigned 16-bit value</td><td>2</td></tr> <tr><td>21</td><td></td><td></td></tr> <tr><td>22</td><td></td><td></td></tr> <tr><td>23</td><td></td><td></td></tr> </tbody> </table> <p>The tags required to display the parameters of the UPS1600 in the screen windows are now included in the WinCC project.</p>	Name	Data Type	Length	1 UPS1600_1.UPS1600_Infos_Battery_charge_level	Unsigned 8-bit value	1	2 UPS1600_1.UPS1600_Infos_Battery_voltage	Floating-point number 32-bit IEEE	4	3 UPS1600_1.UPS1600_Infos_Buffer_mode	Unsigned 8-bit value	1	4 UPS1600_1.UPS1600_Infos_Device_name_string	Text tag 8-bit character set	25	5 UPS1600_1.UPS1600_Infos_End_of_charge_voltage	Floating-point number 32-bit IEEE	4	6 UPS1600_1.UPS1600_Infos_HW_revision	Unsigned 16-bit value	2	7 UPS1600_1.UPS1600_Infos_Input_voltage	Floating-point number 32-bit IEEE	4	8 UPS1600_1.UPS1600_Infos_Measured_charge_current	Floating-point number 32-bit IEEE	4	9 UPS1600_1.UPS1600_Infos_New_alarms_pending	Unsigned 8-bit value	1	10 UPS1600_1.UPS1600_Infos_Order_number_string	Text tag 8-bit character set	25	11 UPS1600_1.UPS1600_Infos_Output_current	Floating-point number 32-bit IEEE	4	12 UPS1600_1.UPS1600_Infos_Output_voltage	Floating-point number 32-bit IEEE	4	13 UPS1600_1.UPS1600_Infos_Ready_for_buffering	Unsigned 8-bit value	1	14 UPS1600_1.UPS1600_Infos_Serial_number_string	Text tag 8-bit character set	25	15 UPS1600_1.UPS1600_Infos_SW_revision	Unsigned 16-bit value	2	16 UPS1600_1.UPS1600_intern_visibility_alarms	Unsigned 16-bit value	2	17 UPS1600_1.UPS1600_intern_visibility_headline	Unsigned 16-bit value	2	18 UPS1600_1.UPS1600_intern_visibility_main	Unsigned 16-bit value	2	19 UPS1600_1.UPS1600_intern_visibility_state	Unsigned 16-bit value	2	20 UPS1600_1.UPS1600_intern_visibility_trends	Unsigned 16-bit value	2	21			22			23		
Name	Data Type	Length																																																																							
1 UPS1600_1.UPS1600_Infos_Battery_charge_level	Unsigned 8-bit value	1																																																																							
2 UPS1600_1.UPS1600_Infos_Battery_voltage	Floating-point number 32-bit IEEE	4																																																																							
3 UPS1600_1.UPS1600_Infos_Buffer_mode	Unsigned 8-bit value	1																																																																							
4 UPS1600_1.UPS1600_Infos_Device_name_string	Text tag 8-bit character set	25																																																																							
5 UPS1600_1.UPS1600_Infos_End_of_charge_voltage	Floating-point number 32-bit IEEE	4																																																																							
6 UPS1600_1.UPS1600_Infos_HW_revision	Unsigned 16-bit value	2																																																																							
7 UPS1600_1.UPS1600_Infos_Input_voltage	Floating-point number 32-bit IEEE	4																																																																							
8 UPS1600_1.UPS1600_Infos_Measured_charge_current	Floating-point number 32-bit IEEE	4																																																																							
9 UPS1600_1.UPS1600_Infos_New_alarms_pending	Unsigned 8-bit value	1																																																																							
10 UPS1600_1.UPS1600_Infos_Order_number_string	Text tag 8-bit character set	25																																																																							
11 UPS1600_1.UPS1600_Infos_Output_current	Floating-point number 32-bit IEEE	4																																																																							
12 UPS1600_1.UPS1600_Infos_Output_voltage	Floating-point number 32-bit IEEE	4																																																																							
13 UPS1600_1.UPS1600_Infos_Ready_for_buffering	Unsigned 8-bit value	1																																																																							
14 UPS1600_1.UPS1600_Infos_Serial_number_string	Text tag 8-bit character set	25																																																																							
15 UPS1600_1.UPS1600_Infos_SW_revision	Unsigned 16-bit value	2																																																																							
16 UPS1600_1.UPS1600_intern_visibility_alarms	Unsigned 16-bit value	2																																																																							
17 UPS1600_1.UPS1600_intern_visibility_headline	Unsigned 16-bit value	2																																																																							
18 UPS1600_1.UPS1600_intern_visibility_main	Unsigned 16-bit value	2																																																																							
19 UPS1600_1.UPS1600_intern_visibility_state	Unsigned 16-bit value	2																																																																							
20 UPS1600_1.UPS1600_intern_visibility_trends	Unsigned 16-bit value	2																																																																							
21																																																																									
22																																																																									
23																																																																									

The integration of the screen windows is thus completed.

**Displaying the PROFINET diagnostic messages**

In order to display the PROFINET diagnostic messages of the SITOP UPS1600 within the screen windows, the respective WinCC project must already be configured for the display of PROFINET diagnostic messages.

9.4 Interface description


Information on the display and configuration of diagnostic messages in WinCC is available under the entry ID: [245799373](#).

Further notes regarding the PROFINET diagnostic messages of the SITOP UPS1600 are available in the [SITOP UPS1600 User Manual](#) in Chapter 3.2.1.

## 9.4 Interface description

The following chapter describes all tags that are contained in the library object "HMI Tag table (WinCC V7.2)" and required for the functioning of the screen windows.

Figure 9-1



The following table provides the definition of the structure type "UPS1600 Tag table". The created structure tag has the tag prefix "UPS1600\_1".

Table 9-5

Structure element
UPS1600_Infos_Battery_charge_level
Data type: Unsigned 8-bit value
Length: 1
Format adaptation: ByteToUnsignedByte
Tag type: Control tag
Address: DB161,DBB171
UPS1600_Infos_Battery_voltage
Data type: Floating-point number 32-bit IEEE 754
Length: 4
Format adaptation: FloatToUnsignedWord
Tag type: Control tag
Address: DB161,DBW162
Linear scaling: AS (1000-0), OS (10-0)

## 9.4 Interface description

Structure element
<b>UPS1600_Infos_Buffer_mode</b>
Data type: Unsigned 8-bit value
Length: 1
Format adaptation: ByteToUnsignedByte
Tag type: Control tag
Address: DB161,DBB168
<b>UPS1600_Infos_Device_name_string</b>
Data type: Text tag 8-bit character set
Length: 25
Tag type: Control tag
Address: DB161,DBB242
<b>UPS1600_Infos_End_of_charge_voltage</b>
Data type: Floating-point number 32-bit IEEE 754
Length: 4
Format adaptation: FloatToUnsignedWord
Tag type: Control tag
Address: DB161,DBW2
Linear scaling: AS (1000-0), OS (10-0)
<b>UPS1600_Infos_HW_revision</b>
Data type: Unsigned 16-bit value
Length: 2
Format adaptation: WordToUnsignedWord
Tag type: Control tag
Address: DB161,DBW6
<b>UPS1600_Infos_Input_voltage</b>
Data type: Floating-point number 32-bit IEEE 754
Length: 4
Format adaptation: FloatToUnsignedWord
Tag type: Control tag
Address: DB161,DBW154
Linear scaling: AS (1000-0), OS (10-0)
<b>UPS1600_Infos_Measured_charge_current</b>
Data type: Floating-point number 32-bit IEEE 754
Length: 4
Format adaptation: FloatToUnsignedWord
Tag type: Control tag
Address: DB161,DBW160
Linear scaling: AS (1000-0), OS (1-0)

## 9.4 Interface description

Structure element
<b>UPS1600_Infos_New_alarms_pending</b>
Data type: Unsigned 8-bit value
Length: 1
Format adaptation: ByteToUnsignedByte
Tag type: Control tag
Address: DB161,DBB170
Linear scaling: AS (), OS ()
<b>UPS1600_Infos_Order_number_string</b>
Data type: Text tag 8-bit character set
Length: 25
Tag type: Control tag
Address: DB161,DBB186
<b>UPS1600_Infos_Output_current</b>
Data type: Floating-point number 32-bit IEEE 754
Length: 4
Format adaptation: FloatToUnsignedWord
Tag type: Control tag
Address: DB161,DBW164
Linear scaling: AS (1000-0), OS (5-0)
<b>UPS1600_Infos_Output_voltage</b>
Data type: Floating-point number 32-bit IEEE 754
Length: 4
Format adaptation: FloatToUnsignedWord
Tag type: Control tag
Address: DB161,DBW156
Linear scaling: (1000-0), OS (10-0)
<b>UPS1600_Infos_Ready_for_buffering</b>
Data type: Unsigned 8-bit value
Length: 1
Format adaptation: ByteToUnsignedByte
Tag type: Control tag
Address: DB161,DBB169
Linear scaling: AS (), OS ()
<b>UPS1600_Infos_Serial_number_string</b>
Data type: Text tag 8-bit character set
Length: 25
Tag type: Control tag
Address: DB161,DBB214
Linear scaling: AS (), OS ()



9.4 Interface description

Structure element
UPS1600_Infos_SW_revision
Data type: Unsigned 16-bit value
Length: 2
Format adaptation: WordToUnsignedWord
Tag type: Control tag
Address: DB161,DBW8
UPS1600_intern_visibility_alarms
Data type: Unsigned 16-bit value
Length: 1
Tag type: Internal tag
UPS1600_intern_visibility_headline
Data type: Unsigned 16-bit value
Length: 1
Tag type: Internal tag
UPS1600_intern_visibility_main
Data type: Unsigned 16-bit value
Length: 1
Tag type: Internal tag
UPS1600_intern_visibility_state
Data type: Unsigned 16-bit value
Length: 1
Tag type: Internal tag
UPS1600_intern_visibility_trends
Data type: Unsigned 16-bit value
Length: 1
Tag type: Internal tag

## 10 Application of the Faceplates in WinCC Professional V12

### 10.1 Preconditions

The following requirements must be met to use the screen windows in WinCC Professional V12 SP1.

- The Hardware Support Package for the SITOP UPS1600 is installed in STEP 7 V12.
- Already existing S7 communication between the SITOP UPS1600 and SIMATIC S7 controller.
- All program blocks for STEP 7 V12 from the library "UPS1600 library TIA Portal V12 SP1" are integrated into the application program and executable.
- The library "UPS1600 library TIA Portal V12 SP1" is available.

#### Supported control panels

The use of the screen windows is approved for the following control panels:

- WinCC RT Professional V12

#### Supported languages

The screen windows support the following languages:

- English (USA)
- German (Germany)
- Chinese (PR China)

#### Note regarding the application

The screen windows can only be used in combination. Using just one of the faceplates separately is not possible.

### 10.2 Library for WinCC Professional

The following objects are part of the master copy "UPS1600 HMI Faceplates (WinCC Professional V12)" in the library "UPS1600 library TIA Portal V12 SP1".

Table 10-1

Name	Type	Description
HMI Windows (WinCC Professional V12)	Screen window	Comprises the screen windows "UPS1600" and "UPS1600_State".
HMI Schedulerjob	Job (scheduler)	-
HMI Tag table	Tag folder	Separate tag folder with all required tags
HMI VB-Script	VB script	-

Name	Type	Description
HMI Screens (WinCC Professional V12)	Screens	Comprises the screens "UPS1600" and "UPS1600_State".

### HMI Windows (WinCC Professional V12)

This object comprises the screen windows "UPS1600" and "UPS1600\_State". In these screen windows, the screens "UPS1600" and "UPS1600\_State" will be displayed later.

The two screen windows are combined to one master copy in the library.

### HMI Scheduler job

This object contains the job "UPS1600\_state\_job" for the scheduler. This job cyclically executes the VB script "UPS1600\_Faceplate\_state\_min".

### HMI Tag table

This object in the library contains the tag folder "HMI Tag table".

This folder comprises all tags required for the use of the faceplates.

The control tags in this folder are already equipped with a connection to the data block DB161 and a controller connection. The default connection name is "Connection\_1".

After having integrated the tags from the library it might be necessary to adapt this connection name in your project.

### HMI VB-Script

This object comprises the VB script "UPS1600\_Faceplate\_state\_min".

This script controls the status indication of the SITOP UPS1600 in the screen window "UPS1600\_State".

### HMI Screens (WinCC Professional V12)

This object comprises the screens "UPS1600" and "UPS1600\_State". The two screens are combined to one master copy in the library.

## 10.3 Integrating the screen windows

The following sections describe all steps required to integrate the screen windows into a WinCC Professional V12 project.


Target system used in this description:



- WinCC RT Professional V12


### Opening the library in WinCC V12

The following steps describe how to open a library in WinCC Professional V12.

Table 10-2

No.	Procedure
1.	<p>Open WinCC V12 in the Project view.</p> 


No.	Procedure
2.	<p>Open the "Libraries" task card.</p> 
3.	<p>Under the "Global libraries" palette, click on the second icon from the left to open a global library.</p>  <p>The "Open global library" dialog box opens.</p>
4.	<p>In the "Look in:" drop-down list, select the storage location of the library on your computer.</p>


No.	Procedure
5.	<p>Click the "Open" button.</p>  <p>The library is opened and displayed in the "Global libraries" palette.</p>

**Inserting screen windows into a project**



The following table describes the procedure for integrating the screen windows from the master copy "UPS1600 HMI Faceplates (WinCC Professional V12)" of the library "UPS1600 library TIA Portal V12" into an existing WinCC V12 project.

Table 10-3

No.	Procedure
1.	<p>In the Project view, open the project into which you want to insert the screen windows.</p> 



No.	Procedure
2.	<p>Open the global library "UPS1600 library TIA Portal V12".</p>  <p>The screenshot shows the 'Libraries' window in TIA Portal. The 'Global libraries' section is expanded, and the library 'UPS1600 library TIA Portal V12 SP1' is selected and highlighted with a red box. Below it, sub-folders like 'Types', 'Master copies', and 'Common data' are visible. The 'Project library' section is also visible above the global libraries.</p>



No.	Procedure
3.	<p>Open the folder "Master copies &gt; UPS1600 HMI Faceplates (WinCC Professional V12)" in the library.</p> 
4.	<p>Select the folder "HMI Tag table" in the library.</p>
5.	<p>Drag and drop the folder "HMI Tag table" to the "HMI tags" folder in the project folder of your control panel.</p> 
6.	<p>Select the folder "HMI VB-Script" in the library.</p>



## 10 Application of the Faceplates in WinCC Professional V12


### 10.3 Integrating the screen windows


No.	Procedure
7.	<p>Drag and drop the folder "HMI VB-Script" to the folder "Scripts &gt; VB scripts" in the project folder of your control panel.</p>  <p>The screenshot shows the WinCC Professional V12 interface. The 'Project tree' on the left shows the project structure. The 'Libraries' pane on the right shows the 'Global libraries' section. A red arrow points from the 'HMI VB-Script' folder in the 'Global libraries' to the 'VB scripts' folder in the 'Scripts' folder of the project tree.</p>
8.	<p>Select the folder "HMI scheduler job" in the library.</p>
9.	<p>Drag and drop the folder "HMI scheduler job" to the folder "Scheduled tasks" in the project folder of your control panel.</p>  <p>The screenshot shows the WinCC Professional V12 interface. The 'Project tree' on the left shows the project structure. The 'Libraries' pane on the right shows the 'Global libraries' section. A red arrow points from the 'HMI scheduler job' folder in the 'Global libraries' to the 'Scheduled tasks' folder in the 'Scripts' folder of the project tree.</p>
10.	<p>Select the folder "HMI Screens (WinCC Professional V12)" in the library.</p>

## 10 Application of the Faceplates in WinCC Professional V12

### 10.3 Integrating the screen windows



No.	Procedure
11.	<p>Drag and drop the folder "HMI Screens (WinCC Professional V12)" to the folder "Screens" in the project folder of your control panel.</p> 
12.	<p>In your project, open the screen into which you want to insert the screen windows.</p>
13.	<p>Select the folder "HMI Windows (WinCC Professional V12)" in the library.</p>
14.	<p>Drag and drop the folder "HMI Windows (WinCC Professional V12)" to the screen.</p> 
15.	<p>In the project folder, under "HMI tags &gt; UPS1600 HMI tag table", open the tag table "UPS1600 HMI tag table".</p>

No.	Procedure
16.	<p>Check the connection name entered for the control tags. The connection name must be identical with the name of the connection you created in your project for the configured connection to your controller.</p>  <p><b>Note</b> Further information on this connection name is available in <a href="#">Chapter 10.2</a> under "HMI Tag table".</p>

No.	Procedure
17.	<p>The scaling of tags has been stored in the library.</p> <p>Enable the following tags for scaling:</p> <ul style="list-style-type: none"> <li>- UPS1600_Infos_Battery_voltage_trend</li> <li>- UPS1600_Infos_Input_voltage_trend</li> <li>- UPS1600_Infos_Measured_charge_current</li> <li>- UPS1600_Infos_Measured_charge_current_trend</li> <li>- UPS1600_Infos_Output_current</li> <li>- UPS1600_Infos_Output_current_trend</li> <li>- UPS1600_Infos_Output_voltage_trend</li> </ul> <ul style="list-style-type: none"> <li>• Click the "Properties" tab and then "Linear scaling".</li> <li>• Select the respective tag in the tag table.</li> <li>• Enable the checkbox left from the heading "Linear scaling".</li> <li>• Repeat the process until linear scaling is enabled for all tags mentioned above.</li> </ul> 

## 10 Application of the Faceplates in WinCC Professional V12

### 10.3 Integrating the screen windows

No.	Procedure
18.	<p>Stay in "Properties" and click "General".</p> <p>Under "Settings", click the arrow beside "HMI data type".</p> <p>Select "Real" from the drop-down list for the following tags:</p> <ul style="list-style-type: none"> <li>- UPS1600_Infos_Battery_voltage</li> <li>- UPS1600_Infos_End_of_charge_voltage</li> <li>- UPS1600_Infos_Input_voltage</li> <li>- UPS1600_Infos_Measured_charge_current</li> <li>- UPS1600_Infos_Output_current</li> <li>- UPS1600_Infos_Output_voltage_trend</li> </ul> 
19.	<p>Right-click on the project folder and select the context menu item "Compile &gt; Software (rebuild all)".</p> 

The integration of the screen windows is thus completed.


### Displaying the PROFINET diagnostic messages

In order to display the PROFINET diagnostic messages of the SITOP UPS1600 within the screen windows, the respective WinCC TIA Portal project must already be configured for the display of PROFINET diagnostic messages.

Information on the display and configuration of diagnostic messages in WinCC TIA Portal is available under the entry ID: [62121503](#).

#### Note

The activation of the PROFINET diagnostic messages of the SITOP UPS1600 can be found in the Device view of the UPS1600.



Further notes regarding the PROFINET diagnostic messages of the SITOP UPS1600 are available in the [SITOP UPS1600 User Manual](#) in Chapter 3.2.1.

## 10.4 Interface description

The following chapter describes all tags that are contained in the library object "HMI Tag table" and required for the functioning of the screen windows.

The following tables provide the definition of the tags.

### Internal tag

Table 10-4

WinCC TIA Portal tag
Faceplate_intern_visibility_alarm
Internal tag
Data type: Int
Faceplate_intern_visibility_headline
Internal tag
Data type: Int
Faceplate_intern_visibility_main
Internal tag
Data type: Int
Faceplate_intern_visibility_state
Internal tag
Data type: Int
Faceplate_intern_visibility_trends
Internal tag
Data type: Int

### Control tags

WinCC TIA Portal tag
UPS1600_Infos.Battery_charge_level
Data type: Byte
Address: DB 161 DBB 269
Length: 1
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
UPS1600_Infos.Battery_voltage / UPS1600_Infos.Battery_voltage_trend
Data type: Int
Address: DB 161 DBW 260
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
Linear scaling: 1000 : 10
UPS1600_Infos.Buffer_mode
Data type: Byte
Address: DB 161 DBB 266
Length: 1



## 10.4 Interface description

WinCC TIA Portal tag
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
UPS1600_Infos.Device_name_string
Data type: String
Address: DB 161 DBX 44.0
Length: 20
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
UPS1600_Infos.End_of_charge_voltage
Data type: Int
Address: DB 161 DBW 100
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
Linear scaling: 1000 : 10
UPS1600_Infos.HW_revision
Data type: Int
Address: DB 161 DBW 104
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
UPS1600_Infos.Input_voltage / UPS1600_Infos.Input_voltage_trend
Data type: Int
Address: DB 161 DBW 250
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
Linear scaling: 1000 : 10
UPS1600_Infos.Measured_charge_current
Data type: Int
Address: DB 161 DBW 258
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
Linear scaling: 1000 : 10
UPS1600_Infos.New_alarms_pending
Data type: Byte
Address: DB 161 DBB 268
Length: 1
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
UPS1600_Infos.Order_number_string
Data type: String

## 10.4 Interface description

<b>WinCC TIA Portal tag</b>
Address: DB 161 DBX 0.0
Length: 20
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
<b>UPS1600_Infos.Output_current/UPS1600_Infos.Output_current_trend</b>
Data type: Int
Address: DB 161 DBW 262
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
Linear scaling: 1000 : 5
<b>UPS1600_Infos.Output_voltage/UPS1600_Infos.Output_voltage_trend</b>
Data type: Int
Address: DB 161 DBW 254
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
Linear scaling: 1000 : 10
<b>UPS1600_Infos.Ready_for_buffering</b>
Data type: Byte
Address: DB 161 DBB 267
Length: 1
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
<b>UPS1600_Infos.Serial_number_string</b>
Data type: String
Address: DB 161 DBX 22.0
Length: 20
Acquisition cycle: 1s
Acquisition mode: Cyclic on use
<b>UPS1600_Infos.SW_revision</b>
Data type: Int
Address: DB 161 DBW 106
Length: 2
Acquisition cycle: 1s
Acquisition mode: Cyclic on use

# 11 Related Literature

## Internet link specifications

The following list is not complete and only represents a selection of relevant information.

Table 11-1

	Topic	Title
\1\	Link to this document	<a href="http://support.automation.siemens.com/WWW/view/en/78817848">http://support.automation.siemens.com/WWW/view/en/78817848</a>
\2\	Siemens Industry Online Support	<a href="http://support.automation.siemens.com">http://support.automation.siemens.com</a>
\3\	SITOP UPS1600 Manual	<a href="http://support.automation.siemens.com/WWW/view/en/84977415">http://support.automation.siemens.com/WWW/view/en/84977415</a>
\4\	STEP 7 Professional V12 System Manual	<a href="http://support.automation.siemens.com/WWW/view/en/77991795">http://support.automation.siemens.com/WWW/view/en/77991795</a>
\5\	WinCC Advanced V12.0 SP1 System Manual	<a href="http://support.automation.siemens.com/WWW/view/en/78318776">http://support.automation.siemens.com/WWW/view/en/78318776</a>
\6\	SIMATIC Programming with STEP 7 V5.5	<a href="http://support.automation.siemens.com/WWW/view/en/45531107">http://support.automation.siemens.com/WWW/view/en/45531107</a>
\7\	WinCC flexible 2008 System Manual	<a href="http://support.automation.siemens.com/WWW/view/en/18796010">http://support.automation.siemens.com/WWW/view/en/18796010</a>
\8\	WinCC System Manual	<a href="http://support.automation.siemens.com/WWW/view/en/73506085">http://support.automation.siemens.com/WWW/view/en/73506085</a>
\9\	GSD for SITOP UPS1600 for integration into STEP 7 V5	<a href="http://support.automation.siemens.com/WWW/view/en/75854605">http://support.automation.siemens.com/WWW/view/en/75854605</a>
\10\	HSP for SITOP UPS1600 for integration into STEP 7 V12 TIA	<a href="http://support.automation.siemens.com/WWW/view/en/75854606">http://support.automation.siemens.com/WWW/view/en/75854606</a>

# 12 History

Table 12-1

Version	Date	Modifications
V1.0	2/2014	First version
V1.1	12/2014	SITOP UPS1600, 2nd delivery stage