

SIEMENS

Ingenuity for life

24/7

Industry Online Support

Home

Support Packages for TIA Portal V16

December 2023

<https://support.industry.siemens.com/cs/ww/en/view/72341852>

Siemens
Industry
Online
Support



This entry is from the Siemens Industry Online Support. The general terms of use (http://www.siemens.com/terms_of_use) apply.

**Security
information**

Security information

In order to protect plants, systems, machines and networks against cyber threats, it is necessary to implement – and continuously maintain – a holistic, state-of-the-art industrial security concept. Siemens' products and solutions only form one element of such a concept. Customer is responsible to prevent unauthorized access to its plants, systems, machines and networks. Systems, machines and components should only be connected to the enterprise network or the internet if and to the extent necessary and with appropriate security measures (e.g. use of firewalls and network segmentation) in place. Additionally, Siemens' guidance on appropriate security measures should be taken into account. For more information about industrial security, please visit <http://www.siemens.com/industrialsecurity>. Siemens' products and solutions undergo continuous development to make them more secure. Siemens strongly recommends to apply product updates as soon as available and to always use the latest product versions. Use of product versions that are no longer supported, and failure to apply latest updates may increase customer's exposure to cyber threats. To stay informed about product updates, subscribe to the Siemens Industrial Security RSS Feed under <http://www.siemens.com/industrialsecurity>.

Table of contents

1	Support Packages for STEP 7	5
1.1	Support Packages for STEP 7 Basic or Professional V16.....	5
1.1.1	HSP 0063 V3.0 – STEP 7 V16 Update 4 is required	5
1.1.2	HSP 0134 V2.0.....	5
1.1.3	HSP 0184	5
1.1.4	HSP 0197	5
1.1.5	HSP 0198 V2.0 SP1 – STEP 7 V16 Update 2 is required	5
1.1.6	HSP 0205 – STEP 7 V16 Update 1 is required	6
1.1.7	HSP 0214	6
1.1.8	HSP 0238 V1.0.....	6
1.1.9	HSP 0238 V2.0.....	6
1.1.10	HSP 0299	6
1.1.11	HSP 0302	6
1.1.12	HSP 0305	6
1.1.13	HSP 0307	7
1.1.14	HSP 0310 V3.0 – STEP 7 V16 Update 4 is required	7
1.1.15	HSP 0311 V2.0.....	7
1.1.16	HSP 0311 V3.0 – STEP 7 V16 Update 2 is required	7
1.1.17	HSP 0311 V4.0 – STEP 7 V16 Update 2 is required	7
1.1.18	HSP 0311 V5.0 – STEP 7 V16 Update 4 is required	7
1.1.19	HSP 0311 V6.0 – STEP 7 V16 Update 5 is required	8
1.1.20	HSP 0312	8
1.1.21	HSP 0313	8
1.1.22	HSP 0318	8
1.1.23	HSP 0319	8
1.1.24	HSP 0321	8
1.1.25	HSP 0322 – STEP 7 V16 Update 2 is required	9
1.1.26	HSP 0323 – STEP 7 V16 Update 1 is required	9
1.1.27	HSP 0325 – STEP 7 V16 Update 2 is required	9
1.1.28	HSP 0326	9
1.1.29	HSP 0328 V2.0 – STEP 7 V16 Update 4 is required	9
1.1.30	HSP 0331 V2.0 – STEP 7 V16 Update 4 is required	9
1.1.31	HSP 0332	10
1.1.32	HSP 0334	10
1.1.33	HSP 0335 – STEP 7 V16 Update 4 is required	10
1.1.34	HSP 0336 – STEP 7 V16 Update 4 is required	10
1.1.35	HSP 0337 – STEP 7 V16 Update 4 is required	10
1.1.36	HSP 0338	10
1.1.37	HSP 0343 – STEP 7 V16 Update 4 is required	11
1.1.38	HSP 0346	11
1.1.39	HSP 0348	11
1.1.40	HSP 0356 – STEP 7 V16 Update 4 is required	11
1.1.41	HSP 0357	11
1.1.42	HSP 0373 – STEP 7 V16 Update 4 is required	11
1.1.43	HSP 0376 – STEP 7 V16 Update 5 is required	12
1.1.44	HSP 0377 – STEP 7 V16 Update 5 is required	12
1.1.45	New: HSP 0379.....	12
1.1.46	HSP 0381 – STEP 7 V16 Update 4 is required	12
1.2	Support Packages for STEP 7 Professional V16.....	13
1.2.1	HSP 0185	13
1.2.2	HSP 0287	13
1.2.3	HSP 0317 – STEP 7 V16 Update 2 is required	13

2	Support Packages for WinCC.....	14
2.1	Support Packages for WinCC V16.....	14
2.1.1	HSP 0306	14
2.1.2	HSP 0362 – WinCC V16 Update 4 is required.....	14
3	Support Packages for STEP 7 Safety	15
3.1	Support Packages for STEP 7 Safety Advanced V16	15
3.1.1	HSP 0308	15

1 Support Packages for STEP 7

1.1 Support Packages for STEP 7 Basic or Professional V16

You can use these HSP with STEP 7 Basic V16 and STEP 7 Professional V16.
At least STEP 7 Basic V16 or STEP 7 Professional V16 is required.

1.1.1 HSP 0063 V3.0 – STEP 7 V16 Update 4 is required

is necessary for these devices:

SITOP UPS1600 / UPS1100 / BAT1600 – FW V2.5

- 6EP4134-3AB00-2AY0; 6EP4136-3AB00-2AY0; 6EP4137-3AB00-2AY0
- 6EP4136-3AC00-2AY0;
- 6EP4131-0GB00-0AY0; 6EP4132-0GB00-0AY0; 6EP4133-0GB00-0AY0
- 6EP4133-0JB00-0AY0; 6EP4134-0GB00-0AY0; 6EP4135-0GB00-0AY0
- 6EP4134-0GL00-0AY0
- 6EP4130-0GJ00-0AY0; 6EP4132-0JA00-0AY0; 6EP4134-0JA00-0AY0
- 6EP4133-0GA00-0AY0; 6EP4135-0GE00-0AY0; 6EP4137-0GE00-0AY0
- 6EP4133-0GD00-0AY0; 6EP4135-0GL00-0AY0

1.1.2 HSP 0134 V2.0

is necessary for this device:

SIMATIC ET 200PRO Frequency converter FC-2 – FW Version 4.7.10

- 6SL3514-1KE13-5AE0

1.1.3 HSP 0184

is necessary for this module:

SIMATIC ET 200SP, TM Posinput 1

- 6ES7138-6BA01-0BA0

1.1.4 HSP 0197

is necessary for this device:

SIMATIC PN/CAN LINK

- 6BK1620-0AA00-0AA0

1.1.5 HSP 0198 V2.0 SP1 – STEP 7 V16 Update 2 is required

is necessary for these devices:

SIMATIC MICRO-DRIVE PDC(F) – FW-Version V2.0

- 6BK1630-1AA10-0AA0; 6BK1630-2AA10-0AA0
- 6BK1630-1AA60-0AA0; 6BK1630-2AA60-0AA0
- 6BK1630-1BA00-0AA0

1.1.6 HSP 0205 – STEP 7 V16 Update 1 is required

is necessary for this module:

SIMATIC ET 200SP IM155-6 PN Standard – FW-Version 4.2

- 6ES7155-6AU01-0BN0

1.1.7 HSP 0214

is necessary for this module:

SIMATIC PN/BACnet LINK

- 6BK1621-0AA00-0AA0

1.1.8 HSP 0238 V1.0

is necessary for these devices:

SIRIUS Soft Starter 3RW5

- 3RW50...-B..; 3RW55...-HA..; 3RW55...-HF..;
- 3RW5950-0CH00; 3RW5980-0CT00; 3RW5980-0HF00

1.1.9 HSP 0238 V2.0

is necessary for these devices:

SIRIUS Soft Starter 3RW5

- 3RW55...-HF..;
- 3RW5950-0CH00; 3RW5980-0CT00; 3RW5980-0HF00

1.1.10 HSP 0299

is necessary for these modules:

SIMATIC ET 200eco PN

- 6ES7141-6BG00-0BB0; 6ES7141-6BH00-0BB0
- 6ES7142-6BG00-0BB0; 6ES7142-6BR00-0BB0
- 6ES7143-6BH00-0BB0

1.1.11 HSP 0302

is necessary for this module:

SIMATIC Bus adapter BA 2xM12

- 6ES7193-6AM00-0AA0

1.1.12 HSP 0305

is necessary for this module:

SIMATIC ET200 SP CM DALI

- 6ES7137-6CA00-0BU0

1.1.13 HSP 0307

is necessary for this component:

PROFINET Driver for Controller – FW-Version 2.2

- 6ES7195-3AA00-0YA0

1.1.14 HSP 0310 V3.0 – STEP 7 V16 Update 4 is required

is necessary for this module:

SIMATIC ET 200SP CM CAN (FW-Version V1.0 / V1.1)

- 6ES7137-6EA00-0BA0

1.1.15 HSP 0311 V2.0

is necessary for this module:

SIMATIC ET 200SP F-TM ServoDrive

- 6BK1136-6AB00-0BU0

1.1.16 HSP 0311 V3.0 – STEP 7 V16 Update 2 is required

is necessary for these modules:

SIMATIC ET 200SP F-TM ServoDrive/StepDrive

- 6BK1136-6AB00-0BU0
- 6BK1136-6SB00-0BU0

1.1.17 HSP 0311 V4.0 – STEP 7 V16 Update 2 is required

is necessary for these modules:

SIMATIC ET 200SP F-TM ServoDrive/StepDrive

- 6BK1136-6AB00-0BU0
- 6BK1136-6AB00-0CU0
- 6BK1136-6SB00-0BU0

1.1.18 HSP 0311 V5.0 – STEP 7 V16 Update 4 is required

is necessary for these modules:

SIMATIC ET 200SP F-TM ServoDrive/StepDrive

- 6BK1136-6AB00-0BU0
- 6BK1136-6AB00-0CU0
- 6BK1136-6SB00-0BU0
- 6BK1136-6AB01-0BU0
- 6BK1136-6AB01-0CU0
- 6BK1136-6SB01-0BU0

1.1.19 HSP 0311 V6.0 – STEP 7 V16 Update 5 is required

is necessary for these modules:

SIMATIC ET 200SP F-TM ServoDrive/StepDrive

- 6BK1136-6AB00-0BU0
- 6BK1136-6AB00-0CU0
- 6BK1136-6SB00-0BU0
- 6BK1136-6AB01-0BU0
- 6BK1136-6AB01-0CU0
- 6BK1136-6SB01-0BU0

1.1.20 HSP 0312

is necessary for these modules:

SIMATIC S7-1500 / ET 200MP, Analog input modules, AI 16xU/I BA

- 6ES7531-7LH00-0AB0
- 6ES7531-7MH00-0AB0

1.1.21 HSP 0313

is necessary for this module:

SIMATIC ET 200AL, AI 4xRTD/TC

- 6ES7144-5KD50-0BA0

1.1.22 HSP 0318

is necessary for these devices:

SIMATIC S7-1500 Act. backplane/ 12 slot

- 6ES7590-0BL00-0AA0

SIMATIC ET 200MP. PROFINET IO-Device Interface-Modul IM 155-5 PN HF

- 6ES7155-5AA00-0AC0 (FW-Version V4.4)

1.1.23 HSP 0319

is necessary for these modules:

SIMATIC S7-1500 Digital modules 64 channels

- 6ES7521-1BP00-0AA0
- 6ES7522-1BP00-0AA0
- 6ES7522-1BP50-0AA0
- 6ES7523-1BP50-0AA0

1.1.24 HSP 0321

is necessary for this module:

SIMATIC ET 200SP RQ

- 6ES7132-6HC50-0BU0

1.1.25 HSP 0322 – STEP 7 V16 Update 2 is required

is necessary for these devices:

SCALANCE SC6xx-2C – FW-Version 2.1

- 6GK5 622-2GS00-2AC2
- 6GK5 632-2GS00-2AC2
- 6GK5 636-2GS00-2AC2
- 6GK5 642-2GS00-2AC2
- 6GK5 646-2GS00-2AC2

1.1.26 HSP 0323 – STEP 7 V16 Update 1 is required

is necessary for these devices:

SIMATIC RF 360R

- 6GT2801-5BA30

1.1.27 HSP 0325 – STEP 7 V16 Update 2 is required

is necessary for these devices:

SCALANCE X200/X300– FW-Version 4.2

- 6GK5204-..; 6GK5205-..; 6GK5206-..; 6GK5208-..
- 6GK5213-..; 6GK5216-..; 6GK5224-..
- 6GK5324-..; 6GK5326-..; 6GK5328-..

NOTE

Please note the important information in the file TIA_Portal_V16_Readmes.zip!

1.1.28 HSP 0326

is necessary for this module:

SIMATIC ET 200eco PN, CM 8x IO-Link + DI 4x 24V DC

- 6ES7148-6JG00-0BB0

1.1.29 HSP 0328 V2.0 – STEP 7 V16 Update 4 is required

is necessary for these modules:

SIMATIC RF18x CM – FW-Version 2.0

- 6GT2002-0JE.0

1.1.30 HSP 0331 V2.0 – STEP 7 V16 Update 4 is required

is necessary for this module:

SIMATIC ET 200SP, TM SITRANS FCT070 Coriolis flow transmitter

- 7ME4138-6AA00-0BB1

1.1.31 HSP 0332

is necessary for this module:

SIMATIC ET 200SP, TM Count 2 – FW-Version 2.0

- 6ES7550-1AA01-0AB0

1.1.32 HSP 0334

is necessary for this part:

SIMATIC S7-1500 / ET 200MP active backplane bus

- 6ES7590-0BH00-0AA0
- 6ES7590-0BD00-0AA0

1.1.33 HSP 0335 – STEP 7 V16 Update 4 is required

is necessary for these modules:

SIMATIC ET 200SP, AI Energy Meter – FW-Version 8.0

- 6ES7134-6PA01-0BU0; 6ES7134-6PA21-0BU0
- 6ES7134-6PA01-0CU0; 6ES7134-6PA21-0CU0

1.1.34 HSP 0336 – STEP 7 V16 Update 4 is required

is necessary for these devices:

SENTRON PAC4200 – FW-Version 2.3

- 7KM4211-1BA00-3AA0; 7KM4212-0BA00-2AA0; 7KM4212-0BA00-3AA0

SENTRON COM100/COM800 – FW-Version 4.4

- 3VA9977-0TA10; VA9977-0TA20; 3VA9987-0TA10; 3VA9987-0TA20

SENTRON molded case circuit breaker 3VA2/3VA6 – FW-Version 4.4

- 3VA2..
- 3VA6..

1.1.35 HSP 0337 – STEP 7 V16 Update 4 is required

is necessary for this device:

SIMATIC RF120C – FW-Version 2.0

- 6GT2002-0LA00

1.1.36 HSP 0338

is necessary for these devices:

SCALANCE X200 IRT– FW-Version 5.5

- 6GK5200-4AH00-2BA3; 6GK5200-4AH10-2BA3
- 6GK5201-3BH00-2BA3; 6GK5201-3BH10-2BA3; 6GK5201-3JR00-2BA6
- 6GK5201-3JR10-2BA6;
- 6GK5202-2BB00-2BA3; 6GK5202-2BB10-2BA3; 6GK5202-2BH00-2BA3
- 6GK5202-2BH10-2BA3; 6GK5202-2JR00-2BA6; 6GK5202-2JR10-2BA6
- 6GK5204-0BA00-2BA3; 6GK5204-0BA10-2BA3; 6GK5204-0JA00-2BA6

- 6GK5204-0JA10-2BA6; 6GK5204-0BA00-2BF2; 6GK5204-0BA10-2BF2
- 6GK5204-2AA00-2BD2

1.1.37 HSP 0343 – STEP 7 V16 Update 4 is required

is necessary for these modules:

SIMATIC S7-1500, DQ 230VAC ST (Triac)

- 6ES7522-5FF00-0AB0
- 6ES7522-5FH00-0AB0

1.1.38 HSP 0346

is necessary for these devices:

SCALANCE X200 IRT– FW-Version 5.4

- 6GK5200-4AH00-2BA3
- 6GK5201-3BH00-2BA3; 6GK5201-3JR00-2BA6
- 6GK5202-2BB00-2BA3; 6GK5202-2BH00-2BA3; 6GK5202-2JR00-2BA6
- 6GK5204-0BA00-2BA3; 6GK5204-0JA00-2BA6; 6GK5204-0BA00-2BF2
- 6GK5204-2AA00-2BD2

1.1.39 HSP 0348

is necessary for this module:

SIMATIC ET 200AL CM 4x IO-Link – FW-Version 1.2

- 6ES7147-5JD00-0BA0

1.1.40 HSP 0356 – STEP 7 V16 Update 4 is required

is necessary for this module:

SIMATIC ET 200SP TM SIWAREX WP341 HF

- 7MH4138-6CA00-0CU0

1.1.41 HSP 0357

is necessary for these modules:

SIMATIC ET 200SP AI RTD/TC HF – FW-Version 2.1

- 6ES7134-6JD00-0CA1
- 6ES7134-6JF00-0CA1

1.1.42 HSP 0373 – STEP 7 V16 Update 4 is required

is necessary for this device:

SIMATIC RF360R – FW-Version 2.0

- 6GT2801-5BA30

1.1.43 HSP 0376 – STEP 7 V16 Update 5 is required

is necessary for these devices:

SIMATIC RF600R – FW-Version 4.0

- 6GT2811-6AA10-0AA0; 6GT2811-6AA10-1AA0; 6GT2811-6AA10-2AA0
- 6GT2811-6AA10-2AA0; 6GT2811-6AA10-4AA0
- 6GT2811-6BC10-0AA0; 6GT2811-6BC10-1AA0; 6GT2811-6BC10-2AA0
- 6GT2811-6CA10-4AA0; 6GT2811-6CA10-0AA0; 6GT2811-6CA10-1AA0
- 6GT2811-6CC10-0AA0; 6GT2811-6CC10-1AA0; 6GT2811-6CC10-2AA0

1.1.44 HSP 0377 – STEP 7 V16 Update 5 is required

is necessary for this device:

SIMATIC RF166C – FW-Version 2.0

- 6GT2002-0EE20

1.1.45 New: HSP 0379

is necessary for this device:

SIMATIC S7-1500, TM NPU – FW-Version 2.0

- 6ES7556-1AA00-0AB0

1.1.46 HSP 0381 – STEP 7 V16 Update 4 is required

is necessary for these modules:

SIMATIC S7-1500, DI/DQ – FW-Version 2.0

- 6ES7521-1BH50-0AA0; 6ES7521-1FH00-0AA0
- 6ES7522-5FF00-0AB0; 6ES7522-5FH00-0AB0

1.2 Support Packages for STEP 7 Professional V16

You can use these HSP with STEP 7 Professional V16. **At least** STEP 7 Professional V16 is required.

1.2.1 HSP 0185

is necessary for these devices:

SINAMICS V90 PN (FW-version 1.04)

- 6SL3210-5FB10-1UF0; 6SL3210-5FB10-1UF2; 6SL3210-5FB10-2UF0;
- 6SL3210-5FB10-2UF2; 6SL3210-5FB10-4UF1; 6SL3210-5FB10-8UF0;
- 6SL3210-5FB11-0UF1; 6SL3210-5FB11-5UF0
- 6SL3210-5FB12-0UF0
- 6SL3210-5FE10-4UF0; 6SL3210-5FE10-8UF0;
- 6SL3210-5FE11-0UF0; 6SL3210-5FE11-5UF0;
- 6SL3210-5FE12-0UF0;
- 6SL3210-5FE13-5UF0
- 6SL3210-5FE15-0UF0;
- 6SL3210-5FE17-0UF0

1.2.2 HSP 0287

is necessary for these devices:

SIMATIC S7-1500 Software Controller CPU 150xS (FW-Version 21.8)

- 6ES7672-..C.1-0YA0

1.2.3 HSP 0317 – STEP 7 V16 Update 2 is required

is necessary for these modules:

SIMATIC ET 200SP HA – Ex-grade

- 6DL1155-6AU00-0PM0
- 6DL1131-6TD00-0HX1
- 6DL1132-6CB00-0HX1
- 6DL1132-6EB00-0HX1
- 6DL1134-6TB00-0HX1
- 6DL1134-6JD00-0HX1
- 6DL1135-6TB00-0HX1
- 6DL1133-6PX00-0HW0

2 Support Packages for WinCC

2.1 Support Packages for WinCC V16

2.1.1 HSP 0306

is necessary for this device:

SIMATIC HMI KTP700F Mobile Arctic:

- 6AV2145-6GB06-0AA0

2.1.2 HSP 0362 – WinCC V16 Update 4 is required

is necessary for these devices:

SIMATIC HMI connection box for Mobile Panels

- 6AV2125-2AE13-0AX0
- 6AV2125-2AE23-0AX0

3 Support Packages for STEP 7 Safety

3.1 Support Packages for STEP 7 Safety Advanced V16

3.1.1 HSP 0308

is necessary for this module:

SIMATIC ET 200SP, F-AI 4xU 0..10V HF

- 6ES7137-6CA00-0BU0