


# Connecting an external relay to a MASS6000 digital output

## Active output :


56 



58 

## Passive output :

56 



58 