

Which external storage locations are available on the various operator panels
(TIA Portal/WinCC flexible/ProTool) for archiving data?

Devicetype	Memory card-/ Interface								Storage data			
	Comfort Panels	Floppy-disk	PCMCIA-Card	CF-Card	PC-Card	MMC-Card	SD-Card	USB-Stick	Ethernet-interface	To archive recipes	Tags-/Archivmessage	Backup-/Restore
KP400 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
KTP400 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
KP700 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
TP700 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
KP900 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
TP900 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
KP1200 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X
TP1200 Comfort	--	--	--	--	--	X ¹⁰⁾	X ¹⁰⁾	X ⁹⁾	X	X	X	X

1) Slot A

2) Slot B

3) Folder path:"\Storage Card\Folder name"

4) Folder path:"\Storage Card2\Folder name"

6) NE2000 compatible plug-in board is required. Folder path:"\Computer name\Release name of the disk drive"

7) Folder path:"\Storage Card MMC\Folder name" Notes: It cannot be used a SIMATIC MEMORY CARD

8) Device dependent (with- / without Ethernet interface)

9) Folder path:"\Storage Card USB\Folder name"

10) Folder path:"\Storage Card SD\Folder name"

11) As of the version WinCC flexible 2008 SP1, as E-Stand 011

12) As of the version WinCC flexible 2008 SP1, at OP177B as E-Stand 014, at TP177B as E-Stand 016

13) As of the version WinCC flexible 2008 SP1, at OP277 as E-Stand 010, at TP277 as E-Stand 011

14) As of the version WinCC flexible 2008 SP1, at Mobile Panel 177 DP as E-Stand 009,at Mobile Panel 177 PN as E-Stand 006

15) As of the version WinCC flexible 2008 SP1

Which external storage locations are available on the various operator panels
(TIA Portal/WinCC flexible/ProTool) for archiving data?

Devicetype Panels	Memory card-/ Interface								Storage data		
	Floppy-disk	PCMCIA-Card	CF-Card	PC-Card	MMC-Card	SD-Card	USB-Stick	Ethernet-interface	To archive	Tags-/Archivme	Backup-/Restore
OP 73	--	--	--	--	--	--	--	--	--	--	--
OP 77A	--	--	--	--	--	--	--	--	--	--	--
OP 77B	--	--	--	--	X ⁷⁾	X ⁷⁾¹¹⁾	--	--	X	--	X
TP170A	--	--	--	--	--	--	--	--	--	--	--
TP177A	--	--	--	--	--	--	--	--	--	--	--
TP / OP170B	--	--	X ³⁾	--	--	--	--	--	X	--	X
TP / OP177B	--	--	--	--	X ⁷⁾	X ⁷⁾¹²⁾	--	X ⁸⁾	X	--	X
TP 177B 4" PN/DP COLOR	--	--	--	--	X	X ⁷⁾¹⁵⁾	X ⁹⁾	X	X	--	X
TP / OP270	--	--	X ⁴⁾	--	--	--	--	X ⁶⁾	X	X	X
TP / OP277	--	--	--	--	X ⁷⁾	X ⁷⁾¹³⁾	--	X	X	X	X
Mobile Panel 170	--	--	X ³⁾	--	--	--	--	--	X	--	X
Mobile Panel 177	--	--	--	--	X ⁷⁾	X ⁷⁾¹⁴⁾	--	X ⁸⁾	X	--	X
Mobile Panel 277	--	--	--	--	X ⁷⁾	X ⁷⁾	X ⁹⁾	X ⁸⁾	X	X	X
MP 177 6" TOUCH	--	--	--	--	X	X ⁷⁾	X ⁹⁾	X	X	--	X
MP270	--	--	X ⁴⁾	X ³⁾	--	--	--	X ⁶⁾	X	X	X
MP270B / Touch	--	--	X ⁴⁾	X ³⁾	--	--	--	X	X	X	X
MP277	--	--	--	--	X	X ⁷⁾	X ⁹⁾	X	X	X	X
MP370 / Touch	--	--	X ⁴⁾	X ³⁾	--	--	--	X	X	X	X
MP377 / Touch	--	--	X ³⁾	--	X	X ⁷⁾	X ⁹⁾	X	X	X	X

- 1) Slot A
- 2) Slot B
- 3) Folder path:"\Storage Card\Folder name"
- 4) Folder path:"\Storage Card2\Folder name"
- 6) NE2000 compatible plug-in board is required. Folder path:"\Computer name\Release name of the disk drive"
- 7) Folder path:"\Storage Card MMC\Folder name" Notes: It cannot be used a SIMATIC MEMORY CARD
- 8) Device dependent (with- / without Ethernet interface)
- 9) Folder path:"\Storage Card USB\Folder name"
- 10) Folder path:"\Storage Card SD\Folder name"
- 11) As of the version WinCC flexible 2008 SP1, as E-Stand 011
- 12) As of the version WinCC flexible 2008 SP1, at OP177B as E-Stand 014, at TP177B as E-Stand 016
- 13) As of the version WinCC flexible 2008 SP1, at OP277 as E-Stand 010, at TP277 as E-Stand 011
- 14) As of the version WinCC flexible 2008 SP1, at Mobile Panel 177 DP as E-Stand 009, at Mobile Panel 177 PN as E-Stand 006
- 15) As of the version WinCC flexible 2008 SP1

Which external storage locations are available on the various operator panels
(TIA Portal/WinCC flexible/ProTool) for archiving data?

Devicetype	Memory card-/ Interface								Storage data		
	Floppy-disk	PCMCIA-Card	CF-Card	PC-Card	MMC-Card	SD-Card	USB-Stick	Ethernet-interface	To archive recipes	Tags-/Archivme	Backup-/Restore
OP25	--	X	--	--	--	--	--	--	X	--	only over PCMCIA Card
OP27	--	X ¹⁾	--	--	--	--	--	--	X	--	only over PCMCIA Card
OP35	optional	X	--	--	--	--	--	--	X	--	only over PCMCIA Card
OP37	optional	X ²⁾	--	--	--	--	--	--	X	--	only over PCMCIA Card
OP37 Pro	X	X	--	--	--	--	--	--	X	X	X
TP27-6	--	X	--	--	--	--	--	--	X	--	X
TP27-10	--	X ²⁾	--	--	--	--	--	--	X	--	X
TP37	--	X ²⁾	--	--	--	--	--	--	X	--	X

- 1) Slot A
- 2) Slot B
- 3) Folder path:"\Storage Card\Folder name"
- 4) Folder path:"\Storage Card2\Folder name"
- 6) NE2000 compatible plug-in board is required. Folder path:"\\Computer name\Release name of the disk drive"
- 7) Folder path:"\Storage Card MMC\Folder name" Notes: It cannot be used a SIMATIC MEMORY CARD
- 8) Device dependent (with- / without Ethernet interface)
- 9) Folder path:"\Storage Card USB\Folder name"
- 10) Folder path:"\Storage Card SD\Folder name"
- 11) As of the version WinCC flexible 2008 SP1, as E-Stand 011
- 12) As of the version WinCC flexible 2008 SP1, at OP177B as E-Stand 014, at TP177B as E-Stand 016
- 13) As of the version WinCC flexible 2008 SP1, at OP277 as E-Stand 010, at TP277 as E-Stand 011
- 14) As of the version WinCC flexible 2008 SP1, at Mobile Panel 177 DP as E-Stand 009,at Mobile Panel 177 PN as E-Stand 006
- 15) As of the version WinCC flexible 2008 SP1

Which external storage locations are available on the various operator panels
(TIA Portal/WinCC flexible/ProTool) for archiving data?

Devicetype	Memory card-/ Interface								Storage data			
	Text-Based Display Panels	Floppy-disk	PCMCIA-Card	CF-Card	PC-Card	MMC-Card	SD-Card	USB-Stick	Ethernet-interface	To archive	Tags-/Archivme	Backup-/Restore
TD17	--	--	--	--	--	--	--	--	--	--	--	--
OP3	--	--	--	--	--	--	--	--	--	--	--	--
OP5	--	--	--	--	--	--	--	--	--	--	--	--
OP7	--	--	--	--	--	--	--	--	--	--	--	--
OP15A	--	--	--	--	--	--	--	--	--	--	--	--
OP15C	--	--	--	--	--	--	--	--	--	--	--	--
OP17	--	--	--	--	--	--	--	--	--	--	--	--

- 1) Slot A
- 2) Slot B
- 3) Folder path:"\Storage Card\Folder name"
- 4) Folder path:"\Storage Card2\Folder name"
- 6) NE2000 compatible plug-in board is required. Folder path:"\\Computer name\Release name of the disk drive"
- 7) Folder path:"\Storage Card MMC\Folder name" Notes: It cannot be used a SIMATIC MEMORY CARD
- 8) Device dependent (with- / without Ethernet interface)
- 9) Folder path:"\Storage Card USB\Folder name"
- 10) Folder path:"\Storage Card SD\Folder name"
- 11) As of the version WinCC flexible 2008 SP1, as E-Stand 011
- 12) As of the version WinCC flexible 2008 SP1, at OP177B as E-Stand 014, at TP177B as E-Stand 016
- 13) As of the version WinCC flexible 2008 SP1, at OP277 as E-Stand 010, at TP277 as E-Stand 011
- 14) As of the version WinCC flexible 2008 SP1, at Mobile Panel 177 DP as E-Stand 009,at Mobile Panel 177 PN as E-Stand 006
- 15) As of the version WinCC flexible 2008 SP1

Which external storage locations are available on the various operator panels
(TIA Portal/WinCC flexible/ProTool) for archiving data?

Devicetype	Memory card-/ Interface								Storage data			
	Micro Panels	Floppy-disk	PCMCIA-Card	CF-Card	PC-Card	MMC-Card	SD-Card	USB-Stick	Ethernet-interface	To archive	Tags-/Archivme	Backup-/Restore
TD 200	--	--	--	--	--	--	--	--	--	--	--	--
TD 200C	--	--	--	--	--	--	--	--	--	--	--	--
OP73micro	--	--	--	--	--	--	--	--	--	--	--	--
TP 070	--	--	--	--	--	--	--	--	--	--	--	--
TP 170micro	--	--	--	--	--	--	--	--	--	--	--	--
TP 177micro	--	--	--	--	--	--	--	--	--	--	--	--

- 1) Slot A
- 2) Slot B
- 3) Folder path:"\Storage Card\Folder name"
- 4) Folder path:"\Storage Card2\Folder name"
- 6) NE2000 compatible plug-in board is required. Folder path:"\Computer name\Release name of the disk drive"
- 7) Folder path:"\Storage Card MMC\Folder name" Notes: It cannot be used a SIMATIC MEMORY CARD
- 8) Device dependent (with- / without Ethernet interface)
- 9) Folder path:"\Storage Card USB\Folder name"
- 10) Folder path:"\Storage Card SD\Folder name"
- 11) As of the version WinCC flexible 2008 SP1, as E-Stand 011
- 12) As of the version WinCC flexible 2008 SP1, at OP177B as E-Stand 014, at TP177B as E-Stand 016
- 13) As of the version WinCC flexible 2008 SP1, at OP277 as E-Stand 010, at TP277 as E-Stand 011
- 14) As of the version WinCC flexible 2008 SP1, at Mobile Panel 177 DP as E-Stand 009,at Mobile Panel 177 PN as E-Stand 006
- 15) As of the version WinCC flexible 2008 SP1

Which external storage locations are available on the various operator panels
(TIA Portal/WinCC flexible/ProTool) for archiving data?

Devicetype C7-Device	Memory card-/ Interface								Storage data		
	Floppy-disk	PCMCIA-Card	CF-Card	PC-Card	MMC-Card	SD-Card	USB-Stick	Ethernet-interface	To archive	Tags-/Archivme	Backup-/Restore
C7-621	--	--	--	--	--	--	--	--	--	--	--
C7-623	--	--	--	--	--	--	--	--	--	--	--
C7-624	--	--	--	--	--	--	--	--	--	--	--
C7-626	--	--	--	--	--	--	--	--	--	--	--
C7-633	--	--	--	--	--	--	--	--	--	--	--
C7-634	--	--	--	--	--	--	--	--	--	--	--
C7-635 Key / Touch	--	X3)	--	--	--	--	--	--	--	--	X
C7-636	--	--	X4)	X3)	--	--	--	--	X	X	X

- 1) Slot A
- 2) Slot B
- 3) Folder path:"\Storage Card\Folder name"
- 4) Folder path:"\Storage Card2\Folder name"
- 6) NE2000 compatible plug-in board is required. Folder path:"\Computer name\Release name of the disk drive\"
- 7) Folder path:"\Storage Card MMC\Folder name" Notes: It cannot be used a SIMATIC MEMORY CARD
- 8) Device dependent (with- / without Ethernet interface)
- 9) Folder path:"\Storage Card USB\Folder name"
- 10) Folder path:"\Storage Card SD\Folder name"
- 11) As of the version WinCC flexible 2008 SP1, as E-Stand 011
- 12) As of the version WinCC flexible 2008 SP1, at OP177B as E-Stand 014, at TP177B as E-Stand 016
- 13) As of the version WinCC flexible 2008 SP1, at OP277 as E-Stand 010, at TP277 as E-Stand 011
- 14) As of the version WinCC flexible 2008 SP1, at Mobile Panel 177 DP as E-Stand 009,at Mobile Panel 177 PN as E-Stand 006
- 15) As of the version WinCC flexible 2008 SP1