

SIEMENS

Ingenuity for life

Industry Online Support

Home

Generating the Parameters for the Modbus/TCP Communication

SIMATIC Modbus/TCP Wizard

<https://support.industry.siemens.com/cs/ww/en/view/60735352>

Siemens
Industry
Online
Support



Warranty and liability

Note

The Application Examples are not binding and do not claim to be complete regarding the circuits shown, equipping and any eventuality. The Application Examples do not represent customer-specific solutions. They are only intended to provide support for typical applications. You are responsible for ensuring that the described products are used correctly. These application examples do not relieve you of the responsibility to use safe practices in application, installation, operation and maintenance. When using these Application Examples, you recognize that we cannot be made liable for any damage/claims beyond the liability clause described. We reserve the right to make changes to these Application Examples at any time without prior notice.

If there are any deviations between the recommendations provided in these application examples and other Siemens publications – e.g. Catalogs – the contents of the other documents have priority.

We do not accept any liability for the information contained in this document.

Any claims against us – based on whatever legal reason – resulting from the use of the examples, information, programs, engineering and performance data etc., described in this Application Example shall be excluded. Such an exclusion shall not apply in the case of mandatory liability, e.g. under the German Product Liability Act (“Produkthaftungsgesetz”), in case of intent, gross negligence, or injury of life, body or health, guarantee for the quality of a product, fraudulent concealment of a deficiency or breach of a condition which goes to the root of the contract (“wesentliche Vertragspflichten”). The damages for a breach of a substantial contractual obligation are, however, limited to the foreseeable damage, typical for the type of contract, except in the event of intent or gross negligence or injury to life, body or health. The above provisions do not imply a change of the burden of proof to your detriment.

Any form of duplication or distribution of these Application Examples or excerpts hereof is prohibited without the expressed consent of Siemens Industry Sector.

Security information

Siemens provides products and solutions with industrial security functions that support the secure operation of plants, solutions, machines, equipment and/or networks. They are important components in a holistic industrial security concept. With this in mind, Siemens' products and solutions undergo continuous development. Siemens recommends strongly that you regularly check for product updates.

For the secure operation of Siemens products and solutions, it is necessary to take suitable preventive action (e.g. cell protection concept) and integrate each component into a holistic, state-of-the-art industrial security concept. Third-party products that may be in use should also be considered. For more information about industrial security, visit <http://www.siemens.com/industrialsecurity>.

To stay informed about product updates as they occur, sign up for a product-specific newsletter. For more information, visit <http://support.automation.siemens.com>.

Table of contents

	Warranty and liability	2
1	Task	4
2	Solution	5
	2.1 Solution overview	5
	2.2 Required Hardware and Software Components	5
3	Function mechanisms of this application	6
4	Installation	7
5	Operation of the application	8
	5.1 Functions of the SIMATIC Modbus/TCP Wizard as an overview.....	8
	5.2 General information on the dialog masks.....	9
	5.2.1 SIMATIC Modbus/TCP CP	9
	5.2.2 SIMATIC Modbus/TCP CP Red	15
	5.2.3 SIMATIC Modbus/TCP PN	21
	5.2.4 SIMATIC Modbus/TCP PN Red	27
	5.3 Step by step instruction: Create new connection	33
	5.4 Step by step instruction: Change connection	36
	5.5 Step by step instruction: Copy connection / use as template	39
	5.6 Step by step instruction: Licensing.....	43
6	Related literature	45
7	History	45

1 Task

Introduction

The configuration of the Modbus/TCP communication is possible using the Modbus/TCP function blocks.

The connection and Modbus parameter must be specified for each connection.

2 Solution

2.1 Solution overview

Solution

Using the “SIMATIC Modbus/TCP Wizard” tool enables simple and clear specification of the connection and Modbus parameters. The tool then exports a DB with all parameters into your STEP 7 project.

Advantages

The SIMATIC Modbus/TCP Wizard provides the following advantages:

- simplified parameterization of the Modbus/TCP connection
- reduced susceptibility to errors
- reduces the parameter input to actually required parameters
- existing connections can be uploaded and represented
- an existing connection can be used as template for a new connection (copy)
- an existing connection can be changed (change)
- support for licensing

2.2 Required Hardware and Software Components

The application was generated with the following components:

Standard software components

Table 2-1

Component	No.	Order number	Note
SIMATIC STEP 7 V5.4	1	6ES7810-4CC08-0YA5	Or higher

Additional software components

Operating the Simatic Modbus/TCP Wizard requires the installation of .NET Framework on your PG/PC. After Installation of STEP 7 at your PC this .NET Framework is already installed. Therefore it is not necessary to install .Net Framework manually.

Sample files and projects

The following list includes all files and projects that are used in this example.


Table 2-2

Component	Note
60735352_Modbus_TCP_Wizard_PROJ_V22.zip	Installation program for the Tool – SIMATIC Modbus/TCP Wizard
60735352_Modbus_TCP_Wizard_DOC_en.pdf	This document

3 Function mechanisms of this application

General overview

Figure 3-1



Copyright © Siemens AG 2016-2018. All rights reserved

4 Installation

Software Preconditions

The SIMATIC Modbus/TCP Wizard is running under:

- MS Windows XP Professional SP2 or SP3
- MS Windows Server 2003 R2 SP2 standard edition as workstation
- MS Windows 7 32-Bit Ultimate, Professional and Enterprise (Standard installation), with or w/o SP1. However, the Windows XP mode under Windows 7 is not released.
- MS Windows 7 64-Bit Ultimate, Professional and Enterprise with or w/o SP1
- MS Windows Server 2008 R2 (64 Bit), with or w/o SP1
- MS Windows 10 Pro and Enterprise (64-bit)
- MS Windows Server 2012 R2 (64-bit) (Standard Edition as work station computer)
- MS Windows Server 2016 (64-bit) (Standard Edition as work station computer)

Installing the Wizard

Retrieve the zip-file “60735352_Modbus_TCP_Wizard_CODE.zip” and go through the setup process.

The tool is available after installation at “Start > SIMATIC” or “Start > Siemens Automation > SIMATIC”.

NOTE

The SIMATIC Modbus/TCP Wizard works with STEP 7 projects. For this reason, STEP 7 must have been installed on the PC. If STEP 7 has not been installed, the installation of the SIMATIC Modbus/TCP Wizard will be aborted.

5 Operation of the application

5.1 Functions of the SIMATIC Modbus/TCP Wizard as an overview

All functions of the SIMATIC Modbus/TCP Wizard are described here. The “step by step” instructions are given in the course of this document.

Generating a new Modbus/TCP connection

The Modbus/TCP connection data is stored directly in your project in a DB.

Uploading the connections from a STEP 7 project

SIMATIC Modbus/TCP Wizard can read out the existing Modbus/TCP connections from the STEP 7 project. In STEP 7 the SIMATIC Modbus/TCP Wizard searches the blocks (DB) of a station for structures, which contain the connection data. The loaded data can be used for further processing.

Change an existing connection

Uploaded Modbus/TCP connections can be changed with the tool. Subsequently, the data are stored at the same location in the STEP 7 project.

Generate new connection by means of the copying function

New Modbus/TCP connections can be generated by copying and changing an uploaded connection. This facilitates the data input in case of many identical parameters.

License the function block

The SIMATIC Modbus/TCP Wizard can read out the IDENT_CODE from the online instance data block and show it as a data matrix code.

With the “Industry Support” app it is possible to scan this data matrix and the data matrix code on the software Modbus package to generate a service request for licensing the function block.

Afterwards the sent REG_KEY can be written into a data block and downloaded into the PLC.


5.2 General information on the dialog masks

Subsequently dialogs of the SIMATIC Modbus/TCP Wizard are described from a general point of view. This description serves as a supplementation of the step-by-step instruction, which you find in the further course of the document.

5.2.1 SIMATIC Modbus/TCP CP

Dialog mask: Welcome


Figure 5-1



The SIMATIC Modbus/TCP Wizard starts with this dialog. Further information on the Modbus/TCP communication is available on the internet.

Dialog mask: Product selection


Figure 5-2



In this dialog you need to select your product.

Dialog mask: Selection

Figure 5-3




In this dialog you can select if you want to create a parameter data block or to license the function block.

The license dialog mask you find here: [Dialog mask: Licensing](#).

Dialog mask: STEP7 project

Figure 5-4




The STEP 7 project selected in this dialog as well as the block folder can be considered as a source station. From this station connection data are uploaded. This station is at the same time used as target station.

The tool determines IP addresses of the selected station. These IP addresses can be considered as local IP addresses. The Modbus/TCP communication generally only uses TCP/IP as connection type. For this reason, only the IP address of the used CP is suitable as local IP address.

After using the “Next” button the upload of the specified project starts automatically.

Dialog mask: Upload connections

Figure 5-5




In this dialog the uploaded connections in the overview are represented. The upload starts automatically. This gives you an overview of the connections of the selected station.

The functions “Change” and “Copy” assume the selection of an uploaded connection in the overview.

Dialog mask: General parameters

Figure 5-6



Here you can enter general parameters for Modbus/TCP communication. Choose the CP for the communication. The ID must be the ID in NetPro.

The option “Single write” is only available when the option “Client” has been selected.

5 Operation of the application

5.2 General information on the dialog masks

Dialog mask: Modbus TCP address reference

Figure 5-7

The screenshot shows the 'Modbus TCP address reference' dialog mask. It features a table with 8 rows for data areas. The first row is pre-filled with 'Holding Register', start and end address '1', and DB number '1'. The other rows are labeled 'unused'. There are checkboxes for 'CFC data collector' and 'OR' between 'DB number' and 'CFC data collector'. Navigation buttons 'Back' and 'Next' are at the bottom.

Data area	Data type	Start and end address	DB number	OR	CFC data collector
1	Holding Register	1	1		<input type="checkbox"/>
2	unused				<input type="checkbox"/>
3	unused				<input type="checkbox"/>
4	unused				<input type="checkbox"/>
5	unused				<input type="checkbox"/>
6	unused				<input type="checkbox"/>
7	unused				<input type="checkbox"/>
8	unused				<input type="checkbox"/>

In this dialog you enter the Modbus/TCP address reference. The first data range is always used. A seamless continuation is not required.

The used data areas must not overlap. The values in the grayed fields are not considered in this check.

The data blocks are defined, in which the defined MODBUS registers are to be mapped. With the optional data collector blocks the values can be interconnected directly in CFC - without usage of global data blocks. In this case there is no entering of the data block number.

Dialog mask: Choose destination block

Figure 5-8

The screenshot shows the 'Choose the parameter datablock' dialog mask. It includes a text field for 'STEP 7 project' with the path 'C:\Program Files (x86)\SIEMENS\STEP7\EXAMPLES\MB_TCP_CP'. Under 'Parameter DB:', there is a 'DB Number' field with 'DB4' and a note '(absolute or symbolic, eg. DBxxx or DB-MODBUS)'. The 'Block folder' field contains 'MODBUS_TCP_CP_EXAMPLE\SIMATIC 400(Client)\CPU 414-2 DP'. Navigation buttons 'Back' and 'Next' are at the bottom.


In the dialog assign any DB number or a symbolic name. When using a symbolic name ensure that the symbolic name is defined in your S7 program.

The wizard checks whether the specified block already exists in your S7 program. If the block does not yet exist in your S7 program, it will be generated. An existing data block is overwritten by the wizard after confirmation.

If a connection is changed (function "Change") details in this dialog cannot be changed. The connection data are filed in the same data block.

Dialog mask: Overview


Figure 5-9



To check the performed changes the connection is again represented as an overview in this dialog.

Dialog mask: Compilation report

Figure 5-10



In this dialog the results of the compilation are displayed. If no errors are displayed in the report, the changes in the STEP 7 project are made successfully. In case of an error no changes are made.


If an error message is displayed in the report, you check whether the used data block has not been opened otherwise.

NOTE

The AWL file displayed in the compilation report is created temporarily, compiled and subsequently deleted.

Dialog mask: Licensing

Figure 5-11



In this dialog you can read the IDENT_CODE from the online instance data block or write the REG_KEY into a license data block and download it into the PLC.


First choose your project and your block folder. After that you can select to read the IDENT_CODE or write the REG_KEY into a data block.

To read the IDENT_CODE or download the license data block your PLC must be reachable.

5.2.2 SIMATIC Modbus/TCP CP Red

Dialog mask: Welcome


Figure 5-12



The SIMATIC Modbus/TCP Wizard starts with this dialog. Further information on the Modbus/TCP communication is available on the internet.

Dialog mask: Product selection


Figure 5-13



In this dialog you need to select your product.

Dialog mask: Selection

Figure 5-14




In this dialog you can select if you want to create a parameter data block or to license the function block.

The license dialog mask you find here: [Dialog mask: Licensing](#).

Dialog mask: STEP7 project

Figure 5-15




The STEP 7 project selected in this dialog as well as the block folder can be considered as a source station. From this station connection data are uploaded. This station is at the same time used as target station.

The tool determines IP addresses of the selected station. These IP addresses can be considered as local IP addresses. The Modbus/TCP communication generally only uses TCP/IP as connection type. For this reason, only the IP address of the used CP is suitable as local IP address.

After using the “Next” button the upload of the specified project starts automatically.

Dialog mask: Upload connections

Figure 5-16




In this dialog the uploaded connections in the overview are represented.

The upload starts automatically. This gives you an overview of the connections of the selected station.

The functions “Change” and “Copy” assume the selection of an uploaded connection in the overview.

Dialog mask: General parameters

Figure 5-17




Here you can enter general parameters for Modbus/TCP communication.

The option “Single write” is only available when the option “Client” has been selected.

Dialog mask: Communication Partner

Figure 5-18




Here you enter connection parameters. Make sure to select the used CPs.

Each redundant connection consists of 2 connections (single-sided redundancy) or 4 connections (double-sided redundancy).

You must select a CP and an ID for each connection. The ID must be the ID in NetPro.

Dialog mask: Modbus TCP address reference

Figure 5-19



In this dialog you enter the Modbus/TCP address reference. The first data range is always used. A seamless continuation is not required.

The used data areas must not overlap. The values in the grayed fields are not considered in this check.


The data blocks are defined, in which the defined MODBUS registers are to be mapped. With the optional data collector blocks the values can be interconnected directly in CFC - without usage of global data blocks. In this case there is no entering of the data block number.

5 Operation of the application

5.2 General information on the dialog masks

Dialog mask: Choose the parameter datablock

Figure 5-20




In the dialog assign any DB number or a symbolic name. When using a symbolic name ensure that the symbolic name is defined in your S7 program.

The wizard checks whether the specified block already exists in your S7 program. If the block does not yet exist in your S7 program, it will be generated. An existing data block is overwritten by the wizard after confirmation.

If a connection is changed (function "Change") details in this dialog cannot be changed. The connection data are filed in the same data block.

Dialog mask: Overview


Figure 5-21



To check the performed changes the connections are again represented as an overview in this dialog.

Dialog mask: Compilation report

Figure 5-22




In this dialog the results of the compilation are displayed. If no errors are displayed in the report, the changes in the STEP 7 project are made successfully. In case of an error no changes are made.

If an error message is displayed in the report, you check whether the used data block has not been opened otherwise.

NOTE The AWL file displayed in the compilation report is created temporarily, compiled and subsequently deleted.

Dialog mask: Licensing

Figure 5-23



In this dialog you can read the IDENT_CODE from the online instance data block or write the REG_KEY into a license data block and download it into the PLC.


First choose your project and your block folder. After that you can select to read the IDENT_CODE or write the REG_KEY into a data block.

To read the IDENT_CODE or download the license data block your PLC must be reachable.

5.2.3 SIMATIC Modbus/TCP PN

Dialog mask: Welcome


Figure 5-24



The SIMATIC Modbus/TCP Wizard starts with this dialog. Further information on the Modbus/TCP communication is available on the internet.

Dialog mask: Product selection


Figure 5-25



In this dialog you need to select your product.

Dialog mask: Selection

Figure 5-26




In this dialog you can select if you want to create a parameter data block or to license the function block.

The license dialog mask you find here: [Dialog mask: Licensing](#).

Dialog mask: STEP7 project

Figure 5-27




The STEP 7 project selected in this dialog as well as the block folder can be considered as a source station. From this station connection data are uploaded. This station is at the same time used as target station.

The tool determines IP addresses of the selected station. These IP addresses can be considered as local IP addresses. The Modbus/TCP communication generally only uses TCP/IP as connection type. For this reason, only the IP address of the used CPU is suitable as local IP address.

After using the “Next” button the upload of the specified project starts automatically.

Dialog mask: Upload connections

Figure 5-28




In this dialog the uploaded connections in the overview are represented. The upload starts automatically. This gives you an overview of the connections of the selected station.

The functions “Change” and “Copy” assume the selection of an uploaded connection in the overview.

Dialog mask: General parameters

Figure 5-29



Here you can enter general parameters for the Modbus/TCP communication.

The option “Single write” is only available when the option “Client” has been selected.

You must enter an ID and a connection name. The connection name is filled in the comment.

If S7 acts as client, the IP address and the port number for the connection must be entered. The Modbus communication usually runs via server port 502.

If S7 acts as server, the local port number must be entered. Please note that not all CPU types can use port 502.

5 Operation of the application

5.2 General information on the dialog masks

Dialog mask: Modbus TCP address reference

Figure 5-30

The screenshot shows the 'Modbus TCP address reference' dialog mask. It features a table with 8 rows for data areas. Each row includes a 'Data area' number, a 'Data type' dropdown menu, a 'Start and end address' field, a 'DB number' field, and a 'CFC data collector' checkbox. The first row is pre-filled with 'Holding Register', '0 - 499', '11', and the checkbox is checked. The second row is 'Holding Register', '720 - 900', '12', and the checkbox is checked. The third row is 'Input Register', '720 - 1000', '13', and the checkbox is checked. The fourth row is 'unused', '--', and the checkbox is unchecked. The fifth row is 'Coils', '640 - 1250', '14', and the checkbox is checked. The sixth row is 'Inputs', '1700 - 2300', '15', and the checkbox is checked. The seventh row is 'Coils', '1700 - 2300', '16', and the checkbox is checked. The eighth row is 'unused', '--', and the checkbox is unchecked. At the bottom, there are buttons for 'Abort', 'Help', '< Back', and 'Next >'.

Data area	Data type	Start and end address	DB number	OR	CFC data collector
1	Holding Register	0 - 499	11		<input checked="" type="checkbox"/>
2	Holding Register	720 - 900	12		<input checked="" type="checkbox"/>
3	Input Register	720 - 1000	13		<input checked="" type="checkbox"/>
4	unused	--			<input type="checkbox"/>
5	Coils	640 - 1250	14		<input checked="" type="checkbox"/>
6	Inputs	1700 - 2300	15		<input checked="" type="checkbox"/>
7	Coils	1700 - 2300	16		<input checked="" type="checkbox"/>
8	unused	--			<input type="checkbox"/>

In this dialog you enter the Modbus/TCP address reference. The first data range is always used. A seamless continuation is not required.

The used data areas must not overlap. The values in the grayed fields are not considered in this check.

The data blocks are defined, in which the defined MODBUS registers are to be mapped. With the optional data collector blocks the values can be interconnected directly in CFC - without usage of global data blocks. In this case there is no entering of the data block number.

Dialog mask: Choose parameter datablock

Figure 5-31

The screenshot shows the 'Choose the parameter datablock' dialog mask. It has a title bar 'SIMATIC Modbus/TCP PN CPU Wizard' and a subtitle 'Choose the parameter datablock'. Below the subtitle is the instruction 'Insert data block number'. A text field shows 'STEP 7 project: C:\Program Files (x86)\SIEMENS\STEP7\EXAMPLES\MB_PN_CPU'. Under the heading 'Parameter DB:', there are two fields: 'DB Number: DB4 (absolute or symbolic, eg. DBxxx or DB-MODBUS)' and 'Block folder: MODBUS_PN_CPU_EXAMPLE\SIMATIC 400(Client)\CPU 414-3 PN'. At the bottom, there are buttons for 'Abort', 'Help', '< Back', and 'Next >'.


In the dialog assign any DB number or a symbolic name. When using a symbolic name ensure that the symbolic name is defined in your S7 program.

The wizard checks whether the specified block already exists in your S7 program. If the block does not yet exist in your S7 program, it will be generated. An existing data block is overwritten by the wizard after confirmation.

If a connection is changed (function "Change") details in this dialog cannot be changed. The connection data are filled in the same data block.

Dialog mask: Overview


Figure 5-32



To check the performed changes the connections are again represented as an overview in this dialog.

Dialog mask: Compilation report

Figure 5-33



In this dialog the results of the compilation are displayed. If no errors are displayed in the report, the changes in the STEP 7 project are made successfully. In case of an error no changes are made.


If an error message is displayed in the report, you check whether the used data block has not been opened otherwise.

NOTE

The AWL file displayed in the compilation report is created temporarily, compiled and subsequently deleted.

Dialog mask: Licensing

Figure 5-34



In this dialog you can read the IDENT_CODE from the online instance data block or write the REG_KEY into a license data block and download it into the PLC.


First choose your project and your block folder. After that you can select to read the IDENT_CODE or write the REG_KEY into a data block.

To read the IDENT_CODE or download the license data block your PLC must be reachable.

5.2.4 SIMATIC Modbus/TCP PN Red

Dialog mask: Welcome


Figure 5-35



The SIMATIC Modbus/TCP Wizard starts with this dialog. Further information on the Modbus/TCP communication is available on the internet.

Dialog mask: Product selection


Figure 5-36



In this dialog you need to select your product.

Dialog mask: Selection

Figure 5-37




In this dialog you can select if you want to create a parameter data block or to license the function block.

The license dialog mask you find here: [Dialog mask: Licensing](#).

Dialog mask: STEP7 project

Figure 5-38




The STEP 7 project selected in this dialog as well as the block folder can be considered as a source station. From this station connection data are uploaded. This station is at the same time used as target station.

The tool determines IP addresses of the selected station. These IP addresses can be considered as local IP addresses. The Modbus/TCP communication generally only uses TCP/IP as connection type. For this reason, only the IP address of the used CPU is suitable as local IP address.

After using the “Next” button the upload of the specified project starts automatically.

Dialog mask: Upload connections

Figure 5-39




In this dialog the uploaded connections in the overview are represented. Here you can switch between functions of the SIMATIC Modbus/TCP Wizard.

The upload starts automatically. This gives you an overview of the connections of the selected station.

The functions “Change” and “Copy” assume the selection of an uploaded connection in the overview.

Dialog mask: General parameters

Figure 5-40



Here you can enter general parameters for Modbus/TCP communication.


The option “Single write” is only available when the option “Client” has been selected.

5 Operation of the application

5.2 General information on the dialog masks

Dialog mask: Communication partner

Figure 5-41



Here you enter connection parameters. Please ensure that the correct interface has been selected.

Each redundant connection consists of 2 connections (single-sided redundancy) or 4 connections (double-sided redundancy).


You must enter an ID and a connection name for each connection. The connection name is filled in the comment.

If S7 acts as client, the IP addresses and the port numbers for the connections must be entered. The Modbus communication usually runs via server port 502.

If S7 acts as server, the local port numbers must be entered. Please note that not all CPU types can use port 502.

Dialog mask: Modbus TCP address reference

Figure 5-42




In this dialog you enter the Modbus/TCP address reference. The first data range is always used. A seamless continuation is not required.

The used data areas must not overlap. The values in the grayed fields are not considered in this check.

The data blocks are defined, in which the defined MODBUS registers are to be mapped. With the optional data collector blocks the values can be interconnected directly in CFC - without usage of global data blocks. In this case there is no entering of the data block number.

Dialog mask: Choose destination block

Figure 5-43




In the dialog assign any DB number or a symbolic name. When using a symbolic name ensure that the symbolic name is defined in your S7 program.

The wizard checks whether the specified block already exists in your S7 program. If the block does not yet exist in your S7 program, it will be generated. An existing data block is overwritten by the wizard after confirmation.

If a connection is changed (function "Change") details in this dialog cannot be changed. The connection data are filed in the same data block.

Dialog mask: Overview


Figure 5-44



To check the performed changes the connections are again represented as an overview in this dialog.

Dialog mask: Compilation report

Figure 5-45




In this dialog the results of the compilation are displayed. If no errors are displayed in the report, the changes in the STEP 7 project are made successfully. In case of an error no changes are made.

If an error message is displayed in the report, you check whether the used data block has not been opened otherwise.

NOTE The AWL file displayed in the compilation report is created temporarily, compiled and subsequently deleted.

Dialog mask: Licensing

Figure 5-46



In this dialog you can read the IDENT_CODE from the online instance data block or write the REG_KEY into a license data block and download it into the PLC.

First choose your project and your block folder. After that you can select to read the IDENT_CODE or write the REG_KEY into a data block.




To read the IDENT_CODE or download the license data block your PLC must be reachable.

5.3 Step by step instruction: Create new connection

In this chapter we show you step by step the procedure for generating a new Modbus/TCP connection.




NOTE If already configured Modbus/TCP connections exist in your project, you can also create new connections via the “Copy” option. See: ([Step by step instruction: Copy connection / use as template](#)).

Table 5-1

No.	Description	Wizard
1.	Click the “Next” button in this dialog. Further information on this dialog is available in chapter “Dialog mask: Welcome mask” .	
2.	Select “SIMATIC Modbus/TCP CP” and click the “Next” button in this dialog. Further information on this dialog is available in chapter “Dialog mask: Product selection” or by calling the online help with the “Help” button.	
3.	Select “Create parameter data block” and click the “Next” button in this dialog. Further information on this dialog is available in chapter “Dialog mask: Selection” or by calling the online help with the “Help” button.	




5 Operation of the application

5.3 Step by step instruction: Create new connection

No.	Description	Wizard																																																						
4.	<p>In this dialog you select a STEP 7 project and a block folder.</p> <p>Further information on this dialog is available in chapter “Dialog mask: STEP 7 project” or by calling the online help with the “Help” button.</p>																																																							
5.	<p>In this dialog the option “New” has been selected as a standard. Click the “Next” button to get into the next dialog.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Upload connections” or by calling the online help with the “Help” button.</p>																																																							
6.	<p>In these dialogs you enter the parameters for the Modbus/TCP communication.</p> <p>Further information on this dialog is available in following chapters:</p> <ul style="list-style-type: none"> • “Dialog mask: General parameters” • “Dialog mask: Modbus TCP address reference” <p>Or by calling the online help with the “Help” button.</p>	 <table border="1" data-bbox="866 1646 1353 1915"> <thead> <tr> <th>Data area</th> <th>Data type</th> <th>Start and end address</th> <th>DB number</th> <th>OR</th> <th>CFC data collector</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Holding Register</td> <td>1 - 500</td> <td>11</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>2</td> <td>Holding Register</td> <td>720 - 900</td> <td>12</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>3</td> <td>Input Register</td> <td>720 - 1000</td> <td>13</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>4</td> <td>unused</td> <td>-</td> <td></td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>5</td> <td>Coils</td> <td>640 - 1250</td> <td>14</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>6</td> <td>Inputs</td> <td>1700 - 2300</td> <td>15</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>7</td> <td>Coils</td> <td>1700 - 2300</td> <td>16</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>8</td> <td>unused</td> <td>-</td> <td></td> <td></td> <td><input type="checkbox"/></td> </tr> </tbody> </table>	Data area	Data type	Start and end address	DB number	OR	CFC data collector	1	Holding Register	1 - 500	11		<input type="checkbox"/>	2	Holding Register	720 - 900	12		<input type="checkbox"/>	3	Input Register	720 - 1000	13		<input type="checkbox"/>	4	unused	-			<input type="checkbox"/>	5	Coils	640 - 1250	14		<input type="checkbox"/>	6	Inputs	1700 - 2300	15		<input type="checkbox"/>	7	Coils	1700 - 2300	16		<input type="checkbox"/>	8	unused	-			<input type="checkbox"/>
Data area	Data type	Start and end address	DB number	OR	CFC data collector																																																			
1	Holding Register	1 - 500	11		<input type="checkbox"/>																																																			
2	Holding Register	720 - 900	12		<input type="checkbox"/>																																																			
3	Input Register	720 - 1000	13		<input type="checkbox"/>																																																			
4	unused	-			<input type="checkbox"/>																																																			
5	Coils	640 - 1250	14		<input type="checkbox"/>																																																			
6	Inputs	1700 - 2300	15		<input type="checkbox"/>																																																			
7	Coils	1700 - 2300	16		<input type="checkbox"/>																																																			
8	unused	-			<input type="checkbox"/>																																																			

5 Operation of the application




5.3 Step by step instruction: Create new connection

No.	Description	Wizard
7.	<p>In this dialog you enter a DB number or a name.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Choose destination block” or by calling the online help with the “Help” button.</p>	
8.	<p>In this dialog you check your details and click the “Next” button. Further information on this dialog is available in chapter “Dialog mask: Overview” or by calling the online help with the “Help” button</p>	
9.	<p>A new connection was configured. Click the “Finish” button.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Compilation report” or by calling the online help with the “Help” button.</p>	

5.4 Step by step instruction: Change connection




In this chapter we show you step by step the procedure for changing an existing Modbus/TCP connection.

Table 5-2

No.	Description	Wizard
1.	<p>Click the “Next” button in this dialog. Further information on this dialog is available in chapter “Dialog mask: Welcome mask”.</p>	
2.	<p>Select “SIMATIC Modbus/TCP PN CPU” and click the “Next” button in this dialog. Further information on this dialog is available in chapter “Dialog mask: Product selection” or by calling the online help with the “Help” button.</p>	
3.	<p>Select “Create parameter data block” and click the “Next” button in this dialog. Further information on this dialog is available in chapter “Dialog mask: Selection” or by calling the online help with the “Help” button.</p>	




5 Operation of the application

5.4 Step by step instruction: Change connection

No.	Description	Wizard																																																																
4.	<p>In this dialog you select a STEP 7 project and a block folder.</p> <p>Further information on this dialog is available in chapter “Dialog mask: STEP 7 project” or by calling the online help with the “Help” button.</p>	 <table border="1" data-bbox="884 517 1316 658"> <thead> <tr> <th>CPU</th> <th>IP address</th> <th>MLFB</th> </tr> </thead> <tbody> <tr> <td>CPU 414-3 PN/DP</td> <td>10.0.0.1</td> <td>6ES7 414-3EM05-0AB0</td> </tr> </tbody> </table>	CPU	IP address	MLFB	CPU 414-3 PN/DP	10.0.0.1	6ES7 414-3EM05-0AB0																																																										
CPU	IP address	MLFB																																																																
CPU 414-3 PN/DP	10.0.0.1	6ES7 414-3EM05-0AB0																																																																
5.	<p>In this dialog you select an uploaded connection in the overview. Activate the “Change” option and click the “Next” button.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Upload connections” or by calling the online help with the “Help” button.</p>	 <table border="1" data-bbox="884 831 1316 1048"> <thead> <tr> <th>DB</th> <th>ID (16#...)</th> <th>Connection Name</th> <th>remote IP</th> <th>remote port</th> <th>loc</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>1</td> <td>Verbindung_0001</td> <td>10.0.0.4</td> <td>502</td> <td>0</td> </tr> </tbody> </table>	DB	ID (16#...)	Connection Name	remote IP	remote port	loc	2	1	Verbindung_0001	10.0.0.4	502	0																																																				
DB	ID (16#...)	Connection Name	remote IP	remote port	loc																																																													
2	1	Verbindung_0001	10.0.0.4	502	0																																																													
6.	<p>In these dialogs you can change the parameters for the Modbus/TCP communication.</p> <p>Further information on this dialog is available in following chapters:</p> <ul style="list-style-type: none"> • “Dialog mask: General parameters” • “Dialog mask: Modbus TCP address reference”. <p>Or by calling the online help with the “Help” button.</p>	 <table border="1" data-bbox="884 1435 1316 1480"> <thead> <tr> <th>ID (16#...)</th> <th>Connection Name</th> <th>Remote IP</th> <th>Remote port</th> <th>Local port</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Verbindung_0001</td> <td>10.0.0.4</td> <td>502</td> <td>0</td> </tr> </tbody> </table> <table border="1" data-bbox="874 1637 1326 1899"> <thead> <tr> <th>Data area</th> <th>Data type</th> <th>Start and end address</th> <th>Modbus values are filled in DB number</th> <th>OR</th> <th>CFC data collector</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Holding Register</td> <td>0 - 499</td> <td>11</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>2</td> <td>Holding Register</td> <td>720 - 900</td> <td>12</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>3</td> <td>Input Register</td> <td>720 - 1000</td> <td>13</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>4</td> <td>unused</td> <td>-</td> <td></td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>5</td> <td>Coils</td> <td>640 - 1250</td> <td>14</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>6</td> <td>Inputs</td> <td>1700 - 2300</td> <td>15</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>7</td> <td>Coils</td> <td>1700 - 2300</td> <td>16</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>8</td> <td>unused</td> <td>-</td> <td></td> <td></td> <td><input type="checkbox"/></td> </tr> </tbody> </table>	ID (16#...)	Connection Name	Remote IP	Remote port	Local port	1	Verbindung_0001	10.0.0.4	502	0	Data area	Data type	Start and end address	Modbus values are filled in DB number	OR	CFC data collector	1	Holding Register	0 - 499	11		<input type="checkbox"/>	2	Holding Register	720 - 900	12		<input type="checkbox"/>	3	Input Register	720 - 1000	13		<input type="checkbox"/>	4	unused	-			<input type="checkbox"/>	5	Coils	640 - 1250	14		<input type="checkbox"/>	6	Inputs	1700 - 2300	15		<input type="checkbox"/>	7	Coils	1700 - 2300	16		<input type="checkbox"/>	8	unused	-			<input type="checkbox"/>
ID (16#...)	Connection Name	Remote IP	Remote port	Local port																																																														
1	Verbindung_0001	10.0.0.4	502	0																																																														
Data area	Data type	Start and end address	Modbus values are filled in DB number	OR	CFC data collector																																																													
1	Holding Register	0 - 499	11		<input type="checkbox"/>																																																													
2	Holding Register	720 - 900	12		<input type="checkbox"/>																																																													
3	Input Register	720 - 1000	13		<input type="checkbox"/>																																																													
4	unused	-			<input type="checkbox"/>																																																													
5	Coils	640 - 1250	14		<input type="checkbox"/>																																																													
6	Inputs	1700 - 2300	15		<input type="checkbox"/>																																																													
7	Coils	1700 - 2300	16		<input type="checkbox"/>																																																													
8	unused	-			<input type="checkbox"/>																																																													

5 Operation of the application




5.4 Step by step instruction: Change connection

No.	Description	Wizard
7.	<p>Click the “Next” button in this dialog.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Choose destination block” or by calling the online help with the “Help” button.</p>	
8.	<p>In this dialog you check your details and click the “Next” button. Further information on this dialog is available in chapter “Dialog mask: Overview” or by calling the online help with the “Help” button</p>	
9.	<p>The selected connection was changed. Click the “Finish” button.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Compilation report” or by calling the online help with the “Help” button.</p>	

5.5 Step by step instruction: Copy connection / use as template



In this chapter we show you step by step the procedure for copying or using an existing Modbus/TCP connection as template for creating a new connection.

Table 5-3

No.	Description	Wizard
1.	Click the "Next" button in this dialog. Further information on this dialog is available in chapter " Dialog mask: Welcome mask ".	
2.	Select "SIMATIC Modbus/TCP PN Red" and click the "Next" button in this dialog. Further information on this dialog is available in chapter " Dialog mask: Product selection " or by calling the online help with the "Help" button.	
3.	Select "Create parameter data block" and click the "Next" button in this dialog. Further information on this dialog is available in chapter " Dialog mask: Selection " or by calling the online help with the "Help" button.	



5 Operation of the application

5.5 Step by step instruction: Copy connection / use as template

No.	Description	Wizard
4.	<p>In this dialog you select a STEP 7 project and a block folder.</p> <p>Further information on this dialog is available in chapter “Dialog mask: STEP7 project” or by calling the online help with the “Help” button.</p>	 <p>The screenshot shows the 'STEP 7 project' dialog box. It has a title bar 'SIMATIC Modbus/TCP PN Red Wizard'. Below the title bar, it says 'STEP 7 project' and 'Choose a project and a block folder.'. There are two text boxes: 'STEP 7 project:' with the path 'C:\Program Files (x86)\SIEMENS\STEP7\EXAMPLES\MB_PN_CPU' and 'Block folder:' with the path 'MODBUS_PN_CPU_EXAMPLE\SIEMATIC 400(Client)\CPU 414-3 PN/'. Below these is a table titled 'IP addresses found in station:' with columns 'CPU', 'IP address', and 'MLFB'. The table contains one row: 'CPU 414-3 PN/DP', '10.0.0.1', and '6ES7 414-3EM05-0AB0'. At the bottom are buttons for 'Abort', 'Help', '< Back', and 'Next >'.</p>
5.	<p>In this dialog you select an uploaded connection in the overview. Activate the “Copy” option and click the “Next” button.</p> <p>Further information on this dialog is available in chapter “Dialog mask: Upload connections” or by calling the online help with the “Help” button.</p>	 <p>The screenshot shows the 'Upload connections' dialog box. It has a title bar 'SIMATIC Modbus/TCP PN Red Wizard'. Below the title bar, it says 'Upload connections' and 'List of connections'. There is a table with columns: 'Connection Type', 'DB', 'ID (16#...', 'Connection Name', and 're'. The table contains three rows: 'Modbus/TCP PN Red Single s...' with DB 4, ID 5, 'Verbindung_1', and '1'; 'Modbus/TCP PN Red Single s...' with DB 6, ID 6, 'Verbindung_2', and '1'; and 'Modbus/TCP PN Red Single s...' with DB 99, ID 3, 'Verbindung_1', and '1'. Below the table are radio buttons for 'New', 'Change', and 'Copy' (which is selected). At the bottom are buttons for 'Abort', 'Help', '< Back', and 'Next >'.</p>



5 Operation of the application

5.5 Step by step instruction: Copy connection / use as template

No.	Description	Wizard																																																																																				
6.	<p>In these dialogs you can change the parameters for Modbus/TCP communication. Further information on this dialog is available in following chapters:</p> <ul style="list-style-type: none"> • “Dialog mask: General parameters” • “Dialog mask: Communication partner” • “Dialog mask: Modbus TCP address reference” <p>Or by calling the online help with the “Help” button.</p>	 <p>The wizard consists of three main dialog boxes:</p> <ul style="list-style-type: none"> Modbus general parameters: Shows a diagram of a PLC and a laptop connected. Options include 'Client' (selected) or 'Server', 'Single write', and 'Connect at startup'. Communication partner: Shows redundancy options (S7 is redundant, Device is redundant, S7 and device are redundant) with diagrams. It also shows a table of connection parameters: <table border="1" data-bbox="869 985 1316 1075"> <thead> <tr> <th>Connection</th> <th>ID(16#...)</th> <th>Connection name</th> <th>Remote IP</th> <th>Remote port</th> <th>Local port</th> </tr> </thead> <tbody> <tr> <td>0A</td> <td>7</td> <td>Verbindung_1</td> <td>10.0.0.10</td> <td>502</td> <td></td> </tr> <tr> <td>1A</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>0B</td> <td>8</td> <td>Verbindung_2</td> <td>10.0.0.11</td> <td>502</td> <td></td> </tr> <tr> <td>1B</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table> Modbus TCP address reference: Shows a table of data areas: <table border="1" data-bbox="869 1220 1316 1489"> <thead> <tr> <th>Data area</th> <th>Data type</th> <th>Start and end address</th> <th>DB number</th> <th>OR</th> <th>CFC data collector</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Holding Register</td> <td>0 - 499</td> <td>11</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>2</td> <td>Holding Register</td> <td>720 - 900</td> <td>12</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>3</td> <td>Input Register</td> <td>720 - 1000</td> <td>13</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>4</td> <td>unused</td> <td>-</td> <td></td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>5</td> <td>Coils</td> <td>640 - 1250</td> <td>14</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>6</td> <td>Inputs</td> <td>1700 - 2300</td> <td>15</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>7</td> <td>Coils</td> <td>1700 - 2300</td> <td>16</td> <td></td> <td><input type="checkbox"/></td> </tr> <tr> <td>8</td> <td>unused</td> <td>-</td> <td></td> <td></td> <td><input type="checkbox"/></td> </tr> </tbody> </table> 	Connection	ID(16#...)	Connection name	Remote IP	Remote port	Local port	0A	7	Verbindung_1	10.0.0.10	502		1A						0B	8	Verbindung_2	10.0.0.11	502		1B						Data area	Data type	Start and end address	DB number	OR	CFC data collector	1	Holding Register	0 - 499	11		<input type="checkbox"/>	2	Holding Register	720 - 900	12		<input type="checkbox"/>	3	Input Register	720 - 1000	13		<input type="checkbox"/>	4	unused	-			<input type="checkbox"/>	5	Coils	640 - 1250	14		<input type="checkbox"/>	6	Inputs	1700 - 2300	15		<input type="checkbox"/>	7	Coils	1700 - 2300	16		<input type="checkbox"/>	8	unused	-			<input type="checkbox"/>
Connection	ID(16#...)	Connection name	Remote IP	Remote port	Local port																																																																																	
0A	7	Verbindung_1	10.0.0.10	502																																																																																		
1A																																																																																						
0B	8	Verbindung_2	10.0.0.11	502																																																																																		
1B																																																																																						
Data area	Data type	Start and end address	DB number	OR	CFC data collector																																																																																	
1	Holding Register	0 - 499	11		<input type="checkbox"/>																																																																																	
2	Holding Register	720 - 900	12		<input type="checkbox"/>																																																																																	
3	Input Register	720 - 1000	13		<input type="checkbox"/>																																																																																	
4	unused	-			<input type="checkbox"/>																																																																																	
5	Coils	640 - 1250	14		<input type="checkbox"/>																																																																																	
6	Inputs	1700 - 2300	15		<input type="checkbox"/>																																																																																	
7	Coils	1700 - 2300	16		<input type="checkbox"/>																																																																																	
8	unused	-			<input type="checkbox"/>																																																																																	
7.	<p>In this dialog you enter a DB number or a name. Further information on this dialog is available in chapter “Dialog mask: Choose destination block” or by calling the online help with the “Help” button.</p>	 <p>The dialog box 'Choose the parameter datablock' shows the project path: C:\Program Files (x86)\SIEMENS\STEP7\EXAMPLES\MB_PN_CPU. The parameter DB is set to DB199. The block folder is MODBUS_PN_CPU_EXAMPLE\SIMATIC 400(Client)\CPU 414-3 PN.</p>																																																																																				

5 Operation of the application




5.5 Step by step instruction: Copy connection / use as template

No.	Description	Wizard
8.	<p>In this dialog you check your details and click the “Next” button. Further information on this dialog is available in chapter “Dialog mask: Overview” or by calling the online help with the “Help” button.</p>	
9.	<p>A new connection was configured from the template. Click the “Finish” button. Further information on this dialog is available in chapter “Dialog mask: Compilation report” or by calling the online help with the “Help” button.</p>	

5.6 Step by step instruction: Licensing




In this chapter we show you step by step the procedure for reading the IDENT_CODE from an online instance data block or write the REG_KEY into a license data block.

Tabelle 5-4

Nr.	Beschreibung	Wizard
1.	Click the “Next” button in this dialog. Further information on this dialog is available in chapter “ Dialog mask: Welcome mask ”.	
2.	Select “SIMATIC Modbus/TCP CP Red” and click the “Next” button in this dialog. Further information on this dialog is available in chapter “ Dialog mask: Product selection ” or by calling the online help with the “Help” button.	
3.	Select “License the Modbus block” and click the “Next” button in this dialog. Further information on this dialog is available in chapter “ Dialog mask: Selection ” or by calling the online help with the “Help” button.	

5 Operation of the application

5.6 Step by step instruction: Licensing

Nr.	Beschreibung	Wizard
4.	<p>In this dialog you select a STEP 7 project and a block folder.</p> <p>Further information on this dialog is available in chapter "Dialog mask: Licensing" or by calling the online help with the "Help" button.</p>	
5.	<p>Afterwards you can choose to read the IDENT_CODE from the online instance data block or write a REG_KEY into a license data block.</p>	
6.	<p>Select „Read IDENT_CODE from instance data block (online)”, insert the modbus instance data block number and click on “Read out”.</p> <p>The wizard will display the IDENT_CODE in text form and as a data matrix code.</p>	
7.	<p>Using the “Industry Support”-App you can scan this data matrix code and the data matrix code from the Modbus package to request the REG_KEY.</p>	
8.	<p>Select „Write REG_KEY into license data block” to save the received REG_KEY in the db.</p> <p>Insert the REG_KEY and the license db number into the text fields.</p> <p>Write the REG_KEY with “Write into offline DB” into the data block.</p> <p>With the “Download to PLC”-button you can download the block into the PLC.</p>	

6 Related literature

This list is not complete and only represents a selection of relevant information.

Table 6-1

	Subject	Title
\1\	Customized Automation - Software Portfolio	http://www.siemens.com/s7modbus
\2\	Download page of this entry	https://support.industry.siemens.com/cs/ww/en/view/60735352
\3\	Siemens Industry Online Support	http://support.automation.siemens.com

7 History

Table 7-1

Version	Date	Modifications
V1.0	28.06.2016	First version
V1.1	01.03.2017	Extended version
V1.2	03.04.2018	Update Software Preconditions