

SIEMENS

SIMATIC

Industrie PC SIMATIC IPC627C

Getting Started

<u>Introduction</u>	1
<u>Description</u>	2
<u>Application planning</u>	3
<u>Mounting</u>	4
<u>Connecting</u>	5
<u>Commissioning</u>	6
<u>Troubleshooting</u>	7
<u>Dimensional drawings</u>	8
<u>Appendix</u>	A

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

⚠ DANGER
indicates that death or severe personal injury will result if proper precautions are not taken.
⚠ WARNING
indicates that death or severe personal injury may result if proper precautions are not taken.
⚠ CAUTION
with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.
CAUTION
without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.
NOTICE
indicates that an unintended result or situation can occur if the relevant information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

⚠ WARNING
Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction	5
2	Description	7
2.1	Exterior design	7
2.2	Operator Controls	9
2.3	Connection elements	11
2.4	Status displays	15
3	Application planning	17
3.1	Transport.....	17
3.2	Unpacking and checking the delivery unit	17
3.3	Device identification data	18
3.4	Ambient and environmental conditions.....	19
3.5	Permitted mounting positions.....	20
4	Mounting	23
4.1	Installing the device	23
4.2	Installing the device with mounting brackets	24
4.3	Installing the device with the vertical mounting kit.....	24
4.4	Installing the device with the vertical mounting kit for PC port access from the front.....	27
5	Connecting	29
5.1	Connecting peripherals	29
5.2	Connecting the 100 - 240 V AC Power Supply.....	30
5.3	Connecting the (24 V) DC power supply	33
5.4	Connecting equipotential bonding.....	35
6	Commissioning	37
6.1	Requirements for commissioning.....	37
6.2	Basic commissioning - initial startup.....	38
6.3	Reinstalling the software.....	38
6.3.1	General installation procedure.....	38
7	Troubleshooting	39
7.1	General problems	39
8	Dimensional drawings	41
8.1	Dimensional drawings of the device	41

A	Appendix.....	45
	A.1 Guidelines and declarations.....	45
	A.2 Certificates and approvals.....	46
	A.3 Service and support	49
	Index.....	51

Introduction

Purpose of this document

This Getting Started documentation contains all the information you need for commissioning and using the SIMATIC IPC627C.

Scope of validity of this document

This documentation is valid for all supplied versions of the SIMATIC IPC627C.

SIMATIC IPC627C, Operating Instructions

The operating instructions are available on the supplied "Documentation and Drivers" CD. To view and print the operating instructions, run **Start** and follow the instructions on the screen.


The operating instructions provide useful information on many topics such as the hardware expansion options, modification of the system configuration and technical data.


Conventions

The term "Box PC" or "device" is sometimes used to refer to the SIMATIC IPC627C product in this documentation. The abbreviation "CP" stands for CP 1616 onboard.

Description


2.1 Exterior design



Front view	
	① DVI/VGA port
	② On/off button
	③ 2 slots for expansion modules
	④ Cover for Compact Flash Card slot
	⑤ COM interface
	⑥ 4 USB ports
	⑦ 2 RJ 45 Ethernet connections
	⑧ IEC connector for AC power supply or connection for DC power supply
	⑨ On / Off switch
	⑩ PROFIBUS or PROFINET ports
	⑪ Power supply fan

Rear view	
	① Battery compartment
	② Device fan
	③ Rating label with serial number
	④ Steel cover plate for the operator panel interfaces
	⑤ Status display: Two part 7 segment display and two LEDs for POST code (optional)

Description


2.1 Exterior design

Side view (drive side)	
	<p>① Mounting for WinAC backup battery (please use the supplied battery mount without cover for WinAC module)</p>
	<p>② Input data of the power supply</p>
	<p>③ Drive bay module for hard disks and DVD burner</p>

Bottom	
	<p>① Connection for equipotential bonding</p> 

2.2 Operator Controls

On/Off switch

On/Off switch	Description
	<p>Switch the device on using the on/off switch. This requires that the BIOS Setup entry "After Power Failure" is set to "Power On".</p>


WARNING

The on/off switch does not isolate the device from the mains! When the switch is in 0 position (Off), the device is still supplied with mains voltage in order to generate the internal auxiliary voltage for the power supply.

NOTICE

Terminate the operating system before shutting down the device with the on/off switch, otherwise data may be lost.

On/off button

On/off button	Description
	<p>The on/off button has three functions:</p> <ul style="list-style-type: none">- Switch on the PC (press briefly 1x)- Shut down the operating system and PC (press briefly 1x)- Switch off the PC without shutting down the operating system (press and hold more than 4 seconds) = hardware reset.



CAUTION
Data may be lost when the PC performs a hardware reset.

⚠ WARNING
The on/off button does not isolate the device from the mains!

Note
By default, the BIOS Setup entry "After Power Failure" is set to "Power On". This means the device is switched on with the on/off switch and you do not have to operate the on/off button.

2.3 Connection elements

Interfaces

Arrangement of the interfaces on the front of the device			
Item	Description	Description	
	①	DVI/VGA	DVI/VGA connection for CRT or LCD monitor with DVI interface, VGA via DVI/VGA adapter
	②	Compact Flash card	Slot for Compact Flash card
	③	COM	Serial V.24 port
	④	USB 2.0	4 ports for USB devices (only 2 ports can be simultaneously used as high current)
	⑤	ETHERNET	2x RJ 45 Ethernet connection for 10/100/1000 Mbps
	⑥	PROFIBUS/MPI	MPI interface (RS485, electrically isolated), optional 9-pin D-sub socket (optional product model)
	⑦	PROFINET	CP 1616 onboard interface, three RJ45 sockets (optional product models)


2.3 Connection elements

The interfaces available on the device can be uniquely identified based on their numbering. This numbering may deviate, however, from the numbering performed by the operating system.

Interfaces for connecting operator panels / displays

Arrangement of the interfaces		
	①	LVDS display interface for TFT displays up to 1024 x 768 pixels
	②	Access to 2nd LVDS display interface for TFT displays up to 1280 x 1024
	③	USB 2.0 for front
	④	Retaining screw for the steel cover plate that covers the interfaces described below.
	⑤	I/O interface for connecting front panel components


AC power supply

Position of the IEC power connector	Description
 The image shows the rear panel of a SIMATIC IPC627C industrial computer. A red rectangular box highlights the IEC power connector, which is a three-pronged AC power inlet. To the left of the connector are various ports including PROFINET (LAN) X1, X2, X3, P1, P2, P3, P4, P5, P6, P7, P8, P9, P10, P11, P12, P13, P14, P15, P16, P17, P18, P19, P20, P21, P22, P23, P24, P25, P26, P27, P28, P29, P30, P31, P32, P33, P34, P35, P36, P37, P38, P39, P40, P41, P42, P43, P44, P45, P46, P47, P48, P49, P50, P51, P52, P53, P54, P55, P56, P57, P58, P59, P60, P61, P62, P63, P64, P65, P66, P67, P68, P69, P70, P71, P72, P73, P74, P75, P76, P77, P78, P79, P80, P81, P82, P83, P84, P85, P86, P87, P88, P89, P90, P91, P92, P93, P94, P95, P96, P97, P98, P99, P100. To the right of the connector are several other ports including a DVI/VGA X70 port, a CompactFlash X50 port, a COM1 X30 port, a USB X60 port, and a PROFIBUS DP X4 port. The panel also features a power button and a cooling fan.	IEC power connector to AC power supply of the device. The maximum permitted power range is 100 VAC to 240 VAC.

Description


2.3 Connection elements

DC power supply

Position of the DC power connector	Description
 The image shows the rear panel of a SIMATIC IPC627C. A DC power connector is located in the center-right area. Three lines point to the terminals of the connector, labeled 1, 2, and 3. Terminal 1 is the top terminal, terminal 2 is the middle terminal, and terminal 3 is the bottom terminal. Other ports visible on the panel include Ethernet ports (X1-X4), USB ports (X6), and a CompactFlash slot (X50). <p data-bbox="341 439 871 1124">① ② ③</p>	Plug connector for DC power supply of the device
	① + (24 V DC)
	② - (ground)
③ PE (ground terminal)	

2.4 Status displays


PROFINET status display

PROFINET status display			
			
Display	Meaning	LED	Description
SF PROFINET (optional)	Status display for CP 1616 onboard	OFF	<ul style="list-style-type: none"> CP not available CP disabled No error, communication established Download in progress
		Slow flashing	<ul style="list-style-type: none"> Link status error IO controller: IO device cannot be addressed IO controller: Duplicate IP address
		Fast flashing	Exception error: Diagnostics via Web or SNMP no longer possible
		AN	<ul style="list-style-type: none"> Diagnostic information available No communication established.

Virtual status displays			
The two "virtual" CP 1616 LEDs can only be seen in the SIMATIC software and can be scanned via SNMP.			
PROFINET	Virtual LEDs	RUN	CP is active
		STOP	CP is in the stop state
		Flashes	There are no "slow flashing" or "fast flashing" states.

Status display

The status display consists of two 7-segment displays and two three-color LEDs.



	7 segment display	LED H1	LED H2
Power On (= status display test)	88h	Orange	Orange
BIOS self-test	xxh (see BIOS post code)	Off	Off
BIOS self-test completed	00h	Off	Off
Operating system running or controlled by application	00h	Off	Off
Operating system shutting down	Off	Off	Off

Application planning

3.1 Transport

Despite the device's rugged design, its internal components are sensitive to severe vibrations or shock. You must therefore protect the PC from severe mechanical stress when transporting it.

You should always use the **original packaging** for shipping and transporting the device.

CAUTION
Risk of damage to the device!
When transporting the PC in cold weather, it may be submitted to extreme variations in temperature. In this situation, ensure that no moisture (condensation) develops on or inside the device.
If condensation has developed on the device wait at least 12 hours before you switch it on.

3.2 Unpacking and checking the delivery unit

Note the following when unpacking the device:

- Check the delivery unit for any visible transport damage.
- Verify that the shipment contains the complete unit and your separately ordered accessories. Please inform your local dealer of any disagreements or transport damage.
- It is advisable not to dispose of the original packing material. Keep it in case you have to transport the unit.
- Keep the enclosed documentation in a safe place. It is required for initial commissioning and is part of the device.


3.3 Device identification data

The device can be clearly identified with the help of this identification data in case of repairs or theft.

Enter the following data in the table below:


- Serial number: The serial number (S VP...) is found on the rating plate.

Rating plate



- Order number of the device
- Ethernet addresses: The Ethernet addresses of the device are printed on the device and are stored in the BIOS Setup (F2 key) under "Advanced > Peripheral Configuration".
- Microsoft Windows "Product Key" on the "Certificate of Authenticity" (COA). The COA label is bonded to the device. The Product Key is always required to reinstall the operating system.

COA label



Serial number:	S VP ...
Order No.	6ES7647-6C...
Microsoft Windows Product Key	
Ethernet address 1	
Ethernet address 2	
CP 1616 onboard layer 2	

3.4 Ambient and environmental conditions

When you plan your project, take note of the following points:


- Observe the climatic and mechanical environmental conditions specified in the technical specifications of your operating instructions.
- This device was designed for use in a normal industrial environment. Without additional protective measures (such as the provision of clean air), SIMATIC Box PCs may not be operated in harsh environments that are subject to caustic vapors or gases.
- At least 100 mm space should be left free around the ventilation slots, in order that the PC receives sufficient ventilation.
- Do not cover the vent slots of the device.
- The device together with its AC power supply fulfils the requirements for fire protected enclosures according to EN 60950-1. Therefore it can be installed without any additional fire protective covering.
- The device with DC power supply does not fulfill the requirements according to EN 60950-1 in the power supply unit area. The device must therefore be installed in such a way as is part of an operating area with restricted access (e.g. a locked switchgear cabinet, control panel or server room).
- Always observe the mounting positions permitted for this device.
- The connected or built-in peripherals should not introduce negative field voltage in excess of 0.5 V into the device.

 WARNING
Failure to adhere to these conditions when mounting the system voids the approvals based on UL 60950-1, UL 508 and EN 60950-1!

3.5 Permitted mounting positions


PC mounting positions according to UL60950-1/UL508/EN60950-1/CSA22.2 No. 60950-1

An inclination of $\pm 20^\circ$ is permitted for all approved mounting positions.



Additional PC mounting positions according to UL508/CSA 22.2 No. 142

An inclination of $\pm 15^\circ$ is allowed in this mounting position.

**Note**

CD/DVD and floppy drives cannot be operated in this position. The CD drawer opens upward or downward which can lead to mechanical damages in the drawer mechanism.

NOTICE

When using the device in the area of Industrial Control Equipment (UL 508), ensure that it is classified as "Open Type". A mandatory requirement for approval or operation according to UL 508 is therefore installation of the device in an enclosure certified for UL 508.

NOTICE

Mounting positions 4 and 5 are also permitted for the Information Technology Equipment area when the device is mounted in an enclosure that fulfills the requirements stipulated by sections 4.6 and 4.7.3 of IEC/UL/EN/DIN EN 60950-2.

Mounting

4.1 Installing the device

The device is particularly suitable for installation in consoles, switch cabinets and switchboards.

 **WARNING**

Function test while installing the device in machines or execute systems


Following the results of a risk analysis, additional protection equipment on the machine or the system is necessary to avoid endangering persons. With this, especially the programming, configuration and wiring of the inserted I/O modules have to be executed, in accordance with the necessary risk analysis identified safety performance (SIL, PL or Cat.). The intended use of the device has to be secured.

The correct use of the device has to be verified with a function test on the system. This test can detect programming, configuration and wiring errors. The test results have to be documented and if necessary inserted into the relevant inputs.

4.2 Installing the device with mounting brackets

Screw-mounting the brackets

Two angle brackets are included in the product package. You can attach these to the PC enclosure using six M3 x 6 mm screws.



Instructions for wall mounting


Mounting examples		
Material	Hole diameter	Mounting
Concrete	8 mm diameter, 60 mm depth	Dowel: 8 mm, 50 mm screws 4 mm, 50 mm
Plasterboard (min. 13 mm thick)	14 mm diameter	Tilting dowel diameter 4 mm min. length 50 mm
Metal (min. 2 mm thick)	5 mm diameter	Metal screws diameter 4 mm min. length 15 mm

⚠ WARNING
Ensure that the wall is capable of bearing four times the total weight of the device (including the brackets and expansion modules). The total weight is approx. 7 kg.

4.3 Installing the device with the vertical mounting kit

The optional vertical mounting kit allows space-saving installation of the device.

Securing the vertical mounting plate to the device



4.3 Installing the device with the vertical mounting kit

1.	Remove the equipotential bonding screw ① from the device and attach it with the vertical mounting plate ②.
2.	Attach the vertical mounting plate with four M4 screws and three M3 screws to the device


Note

Please note the information in the following section Permitted mounting positions (Page 20).

4.4 Installing the device with the vertical mounting kit for PC port access from the front

The optional vertical mounting kit allows space-saving installation of the device.

Securing the vertical mounting plate to the device



Mounting

4.4 Installing the device with the vertical mounting kit for PC port access from the front

1.	Secure the vertical mounting plate ① on the device using five M4 screws: two screws on top ② and three (not shown in figure) on the bottom of the device.
----	---

Note

Please note the information in the following section Permitted mounting positions (Page 20).

Connecting

5.1 Connecting peripherals

Note before connecting

NOTICE

Connect only peripheral devices approved for industrial applications to EN 61000-6-2:2005.
--

Note

Hot-plug peripheral devices (USB) may be connected while the PC is in operation.

CAUTION

Peripheral devices that are incapable of hot-plugging may only be connected after the device has been disconnected from the power supply.

CAUTION

Strictly adhere to the specifications in the manuals for the peripheral devices.
--

NOTICE

The connected or built-in peripherals should not introduce a negative field voltage into the device.
--

A negative field voltage greater than 0.5 V to ground on the + 3.3 VDC / + 5 VDC / + 12 VDC power rail due to a connected or integrated component can prevent normal operation or even destroy the computer.
--

When measuring the negative field voltage, remember the following:
--

- | |
|--|
| <ul style="list-style-type: none">• The computer must be switched off and the power cable should be plugged in.• During the measurement, all cables from the plant to the computer should be connected.• All other components in the plant must be active. |
|--|

5.2 Connecting the 100 - 240 V AC Power Supply

Note before connecting the device

Note

The varying voltage power supply module is designed for operation on 120/230/240 V AC networks. The setting of the voltage range takes place automatically.

 WARNING

Do not connect or disconnect power and data cables during thunderstorms.

 WARNING

The device is designed for operation on grounded power supply networks (TN networks to VDE 0100, Part 300, or IEC 60364-3).

Operation on ungrounded or impedance-grounded power networks (IT networks) is prohibited.

 WARNING

The permitted nominal voltage of the device must conform with local mains voltage.

CAUTION

The mains connector must be disconnected to fully isolate the device from mains. Ensure easy access to this area.

A master mains disconnect switch must be installed if the device is mounted in a switch cabinet.

Always ensure free and easy access to the power inlet on the device or that the safety power outlet of the building installation is freely accessible and located close to the device.

Note

The power supply contains an active PFC (Power Factor Correction) circuit to conform to the EMC guidelines.

Uninterruptible AC power systems (UPS) must supply a sinusoidal output voltage in the normal and buffered mode when used with SIMATIC PCs with an active PFC.

UPS characteristics are described and classified in the standards EN 50091-3 and IEC 62040-3. Devices with sinusoidal output voltage in the normal and buffered mode are identified with the classification "VFI-SS-...." or "VI-SS-....".

Localized information

For countries other than the USA and Canada:

230 V supply voltage

This device is equipped with a safety-tested power cable which may only be connected to a grounding outlet. If you choose not to use this cable, you must use a flexible cable of the following type: Min 18 AWG conductor cross-section and 15-A / 250-V shockproof connector. The cable set must be compliant with the safety regulations and stipulated IDs of the country where the system is to be installed.

For the USA and Canada:

For the United States and Canada, a CSA or UL-listed power cord must be used.

The connector must be compliant with NEMA 5-15.



120 V AC power supply

To be used is a flexible power cord approved to UL and with CSA label, and which has the following features: Type SJT with three leads, min. 18 AWG conductor cross-section, max. 4.5 m in length and parallel ground contact connector 15 A, min. 125 V.

240 VAC power supply

Use a flexible power cord which is approved to UL and CSA, and which has the following features: Type SJT with three conductors, min. 18 AWG conductor cross-section, max. length 4.5 m, and tandem grounded connector 15 A, min. 250 V.

Connecting

How to connect the device to the 120 V AC / 230 V AC power supply	
<p>1 Ensure that the ON/OFF switch is in "0" position (Off) when you plug in the power cord in order to avoid unintentional startup of the device.</p>	
<p>2 Connect the IEC connector</p>	
<p>3 Connecting the power cord to the power socket</p>	
<p>4 Fasten the cable with the supplied power plug latch ①, if necessary.</p>	

5.3 Connecting the (24 V) DC power supply

Note before connecting the device

 WARNING

Only connect the device to 24 V DC power supply systems which meet the requirements of a safe extra-low voltage (SELV); in addition, a protective conductor must be connected. The conductors must withstand the short-circuit current of the 24 V DC power source, so that a short-circuit will not damage the cable. Only connect cables with a minimum cross-section of 1.3 mm² (AWG16) and a maximum cross-section of 3.3 mm² (AWG12).

NOTICE

The 24 V DC power source must be adapted to the input data of the device (see specifications).

Connecting

Steps for connecting the device to the 24 V DC power supply		
1	Ensure that the ON/OFF switch is in the '0' (OFF) position to prevent unintentional startup of the device when connecting it to the 24 V power supply.	
2	Switch off the 24 V DC power source.	
3	Insert the DC power plug. ① DC 24 V ② ground ③ protective conductor	
4	Fasten the cable with the supplied power plug latch, if necessary.	

Note

Reverse-polarity protection

The DC power supply (24V) has a mechanism to protect against reverse polarity. In the event the 24 V DC lines are reversed (24 V DC nominal (-15% / +20%) and connected to ground, the device will not sustain any damage. The device will simply fail to turn on. After the power supply has been connected correctly, the device will again be ready to operate.


5.4 Connecting equipotential bonding

The equipotential bonding terminal (M4 thread) on the device (large surface, large-area contact) must be connected to the PE conductor of the cabinet or system in which the device is to be installed. The minimum cross-section is 5 mm².

The equipotential bonding terminal is necessary to protect the device and improves the discharge of interference generated by external power cables, signal cables or cables to the I/O modules.

Connecting equipotential bonding

Connect the equipotential bonding terminal on the device (large surface, large-area contact) to the central grounding point of the cabinet in which the device is installed. The minimum cross-section is 5 mm².



Commissioning

6.1 Requirements for commissioning

CAUTION
Risk of damage to the device!
Make sufficient allowances for the device to acquire room temperature before you put it into use. If condensation has developed on the device wait at least 12 hours before you switch it on.

Note

The device features an off/off switch and an on/off button.

By default, the BIOS Setup entry "After Power Failure" is set to "Power On". This means that the device is turned on using the on/off switch.

If the BIOS Setup entry is set to "Stay Off" or "Last state" and the on/off switch is set to "I" (ON), the device can only be turned on by pressing the on/off button.

-
- Connect the peripherals, such as the keyboard, mouse, monitor and the power supply, before putting the device into operation.
 - The operating system you ordered for your device is already installed on the hard disk.

6.2 Basic commissioning - initial startup

The PC operating system is automatically set up the **first** time you switch on the device.
Procedure:

1. Set the ON / Off switch to I position (On). The PC performs a POST. During the self-test, this message appears:

Press <F2> go to SETUP Utility

Press <F12> go to Bootmanager

2. Wait until this message is cleared, then follow the instructions on the screen.
3. Type in the Product Key as required. You find this key on the "Certificate of Authentication", in the "Product Key" line.

NOTICE
The PC may not be switched off when you run setup. Do not change the default BIOS settings, otherwise the operating system setup may become corrupted.

4. Automatic restart

After you have entered all necessary information and after the operating system setup is completed, the PC is automatically restarted and displays the user interface of the relevant operating system.

When you switch on the PC now, the user interface of the operating system or logon dialog of the operating system (with Windows Embedded Standard 2009) is automatically opened when the startup routine is completed.

6.3 Reinstalling the software

6.3.1 General installation procedure

If your software gets corrupted, you can reinstall your software using the Recovery CD, the Documentation and Drivers CD and the Restore DVD.

Recovery CD:

Contains the tools for setting up hard disk drives and the operating system.

Documentation and Drivers CD:

Contains the documentation and the hardware drivers.

Restore DVD:

Contains a hard disk image file with the original factory software (operating system with installed hardware drivers).

Troubleshooting

7.1 General problems

This chapter provides you with tips on how to localize and troubleshoot frequently occurring problems.

Problem	Possible cause	Remedy
The device is not operational	There is no power supply to the device.	<ul style="list-style-type: none"> Check the power supply, the network cable and the power plug. Check if the On/Off switch is in the correct position.
	Device is being operated outside the specified ambient. conditions	<ul style="list-style-type: none"> Check the ambient conditions. After transport in cold weather, wait approximately 12 hours before switching on the device.
Windows no longer boots	Settings in the BIOS Setup are incorrect	<ul style="list-style-type: none"> Check the settings in the BIOS Setup "SATA Configuration" submenu Check the setting in the BIOS Setup Boot menu.
The external monitor remains dark.	The monitor is switched off.	Switch on the monitor.
	The monitor is in "power save" mode.	Press any key on the keyboard.
	The brightness button has been set to dark.	Increase the screen brightness. For detailed information, refer to the monitor operating instructions.
	The power cord or the monitor cable is not connected.	<ul style="list-style-type: none"> Check whether the power cord has been properly connected to the monitor and to the system unit or to the grounded shockproof outlet. Check whether the monitor cable has been properly connected to the system unit and to the monitor.
		If the monitor screen still remains dark after you have performed these checks, please contact your technical support team.
The mouse pointer does not appear on the screen.	The mouse driver is not loaded.	Check if the mouse driver is correctly installed.
	The mouse is not connected.	Check whether the mouse lead is connected to the system unit. If you are using an adapter or extension for the mouse lead, check the connectors. Should the mouse cursor still not be visible on-screen after completing these checks and measures, contact technical support.

7.1 General problems

Problem	Possible cause	Remedy
Wrong time and/or date on the PC.		<ol style="list-style-type: none"> 1. Press <F2> during the boot sequence to open BIOS Setup. 2. Set the time and date in the setup menu.
Although the BIOS setting is OK, the time and data are still wrong.	The backup battery is dead.	Replace the backup battery.
USB device not responding.	The USB ports are disabled in your BIOS.	Use a different USB port or enable the port.
	Operating system does not support the USB port.	Enable USB Legacy Support for the mouse and keyboard. For other devices you need the USB drivers for the respective operating system.
DVD: The front loader does not open.	The device is switched off or the open/close button is disabled by a software application.	Emergency removal of the data medium: <ol style="list-style-type: none"> 1. Switch off the device 2. Insert a pointed object, a pin for example, or an opened paper clip into the emergency extraction opening of the drive. Apply slight pressure to the contact until the front loader opens. 3. Pull the loader further out.
The RAID software reports the following errors: <ul style="list-style-type: none"> • The RAID plug-in failed to load, because the drive is not installed. • The Serial ATA plug-in failed to load, because the driver is not installed correctly. • The Intel® Matrix Storage Console was unable to load a page for the following reason: <ul style="list-style-type: none"> – A plug-in did not provide a page for the selected device – A plug-in failed to load 	RAID is not activated RAID is activated	In this case, the messages have no negative influence on the device function and can be ignored. Acknowledge the messages. Re-install the software from the supplied Documentation and Drivers DVD.
After changing the hard disk, the system does not boot from the RAID array	RAID array does not have highest boot priority	Set the RAID array to be first in the boot order
After changing the hard disk, "unused" is indicated for the relevant SATA port	The system was booted without a functioning hard disk (the removable cartridge was possibly not turned on)	Reboot the system with a functioning hard disk
Computer does not boot or "Boot device not found" is displayed	The boot device is not first in the boot priority in the BIOS setup or is excluded as a boot device	Change the boot priority of the boot device in the Boot menu of the BIOS setup or permit boot device in the boot priority

Dimensional drawings

8.1 Dimensional drawings of the device




Figure 8-1 Dimensional drawing for mounting with angle bracket

8.1 Dimensional drawings of the device




Figure 8-2 Dimensional drawing for mounting without angle bracket

NOTICE

When mounting devices with optical drives or WinAC backup batteries change the fitting depth.




Figure 8-3 Dimensional drawings for vertical mounting (model without DVD burner and without WinAC backup battery)

NOTICE

When mounting devices with optical drives or WinAC backup batteries change the fitting depth.




Figure 8-4 Dimensional drawing for installation with the vertical mounting kit for PC port access from the front

Appendix

A.1 Guidelines and declarations

Notes on CE marking

 The following applies to the SIMATIC product described in this documentation:

EMC directive

The devices fulfill the requirements for the EC directive "2004/108/EEC Electromagnetic Compatibility" and are designed for the following applications as per the CE marking:

Fields of application	Requirement for	
	Emitted interference	Immunity to interferences
Residential, business and trade areas and small businesses.	EN 61000-6-3: 2007	EN 61000-6-1: 2007
Industry	EN 61000-6-4: 2007	EN 61000-6-2: 2005

The device is also compliant with EN 61000-3-2:2006 (harmonic currents) and EN 61000-3-3:1995 +A1:2001 +A2:2005 (voltage fluctuation and flicker) standards.

Low-voltage directive

The devices comply with the requirements of the EC Directive 2006/95/EC "Low Voltage Directive". Conformance with this directive has been verified according to EN 60950-1: 2006 +A11:2009.

Declaration of Conformity

The EC declaration of conformity and the corresponding documentation are made available to authorities in accordance with the EC directives stated above. Your sales representative can provide these on request.

Note the installation guidelines

The installation guidelines and safety instructions given in this documentation have to be noted during commissioning and operation.

Connecting peripherals

Noise immunity requirements to EN 61000-6-2 are met if connected peripherals are suitable for industrial applications. Peripheral devices are only be connected via shielded cables.

A.2 Certificates and approvals

Information on the rating plate

Note

The currently valid approvals are to be found on the device rating plate.

ISO 9001 certificate

The Siemens quality management system for all production processes (development, production and sales) meets DIN ISO 9001:2000 requirements.

This has been certified by DQS (the German society for the certification of quality management systems).

Q-Net certificate no.: DE-001108 QM

Software License Agreement

The device is shipped with preinstalled software. Please observe the respective license agreements.

Approvals for the USA, Canada and Australia

Product safety


The following approval is available for the device:

The logo consists of a circle containing the letters 'UL'. To the left of the circle is the letter 'C' and to the right is the letter 'US'.	Underwriters Laboratories (UL) to Standard UL 60950-1, Report E11 5352 and Canadian Standard C22.2 no. 60950-1 (I.T.E), or to UL508 and C22.2 no. 142 (IND.CONT.EQ)
---	---

EMC

USA	
Federal Communications Commission Radio Frequency Interference Statement	This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
Shielded Cables	Shielded cables must be used with this equipment to maintain compliance with FCC regulations.
Modifications	Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.
Conditions of Operations	This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CANADA	
Canadian Notice	This Class A digital apparatus complies with Canadian ICES-003.
Avis Canadian	Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

AUSTRALIA	
	This product meets the requirements of the standard EN 61000-6-3:2007 Generic standards - Emission standard for residential, commercial and light-industrial environments.

cULus approval, Hazardous Location



HAZ. LOC.

CULUS Listed 7RA9 IND. CONT. EQ. FOR HAZ. LOC.

Underwriters Laboratories Inc., to

- UL 508 (Industrial Control Equipment)
- CSA C22.2 No. 142 (Process Control Equipment)
- ANSI/ISA 12.12.01 (Hazardous Location)
- CSA-213 (Hazardous Location)

APPROVED for Use in

- Cl. 1, Div. 2, GP. A, B, C, D T4A
- Cl. 1, Zone 2, GP. IIC T4

Read the following information

Note

This product must be installed according to the NEC (National Electric Code) stipulations.

When used in environments according to class I, division 2 (see above), the device must be mounted in an enclosure that corresponds to at least IP54 according to EN 60529.

A.3 Service and support

You can find additional information and support for the products described on the Internet at the following addresses:

- Technical support
- Support request form
- After-sales information system for SIMATIC PC / PG
- SIMATIC Documentation Collection
- Your local representative
- Training center
- Industry Mall

When contacting your local representative or Technical Support, please have the following information at hand:

- Order number of the device (MLFB)
- BIOS version (industry PC) or image version (HMI device)
- Installed additional hardware
- Installed additional software

Tools & downloads

Please check regularly if updates and hotfixes are available for download to your device. The downloads are available on the Internet under "After Sales Information System SIMATIC PC/PG" (see above).

See also

Contacts (<http://www.siemens.com/automation/partner>)

SIMATIC Guide manuals (<http://www.siemens.com/simatic-tech-doku-portal>)

SITRAIN homepage (<http://www.sitrain.com>)

Online support request form: (<http://www.siemens.com/automation/support-request>)

Industry Automation and Drive Technologies - Homepage
(<http://www.siemens.com/automation/service&support>)

Industry Mall, the ordering system for automation and drive technology
(<http://mall.automation.siemens.com>)

After sales information system from SIMATIC IPC (<http://www.siemens.com/asis>)

Index

2

24 V DC power supply, 14
Connecting, 33

A

AC power supply, 13

B

Bottom, 8

C

CE marking, 45
Certificates, 46
Certifications, 46
Certifications and approvals, 19
COA label, 18
Compact Flash card, 11
Connecting
 24 V DC power supply, 33
 Peripherals, 29, 45
 Power supply 120/230 V AC, 30
Connection components, 11

D

Declaration of Conformity, 45
Device
 Unpacking, 17
Diagnostics
 Troubleshooting, 39
Dimensional drawings
 Device, 41
Display interfaces, 12
DVI/VGA port, 11

E

EMC, 47
EMC directive, 45
Equipotential bonding terminal, 35
ETHERNET interface, 11

F

First commissioning, 38
Front view, 7

I

Identification data, 18
IEC power connector, 13
Installing the device, 23
Interfaces, 11
 COM, 11
 ETHERNET, 11
 Operator panels, 12
 PROFIBUS/MPI, 11
 USB, 11
 VGA, 11

L

Localized information, 31
Low-voltage directive, 45

M

Monitoring
 Status displays, 15

O

On/off button, 10
On/Off switch, 9
Operating system
 First commissioning, 38
Operator panels, 12

P

- Peripherals, 29
 - Connecting, 45
- Permitted mounting positions, 20
- Power supply, 13, 30
 - IEC power connector, 13
- PROFIBUS/MPI interface, 11

R

- Rating plate, 18, 46
- Rear view, 7
- Restart, 38

S

- Screw-mounting the brackets, 24
- Serial interface, 11
- Side view, 8
- Status display, 16
- Status displays, 15
- Supply voltage, 31

T

- Transport, 17
- Troubleshooting/FAQs, 39

U

- USB interface, 11

V

- Vent slots, 19
- Vertical mounting, 24
 - Front interfaces, 27
- VGA port, 11