

SINAMICS DCC V16 Supported engineering fuctions

siemens.com/startdrive

© Siemens 2020


SINAMICS DCC V16 Supported engineering functions



in V16

	DCC configuration		
Create of	Support of	Handling of blocks	
20 sheets per chart	DCB Standard (Standard library)	Drag and Drop	
One chart per Drive Object	DCB Extension (Library from DCB Studio)	Copy/past/delete	
Multiple chart per Drive Object	DCC library (typicals)	Easy publishing of pins	
Chart partition (never)	Project library for DCB Extension	Min/Max limiting of published pins	
Multiple execution group per chart	Global library for DCB Extension	Interconnection pin/pin and pin/basis system	
	Integrated online helps	Change the sequence in execution group	
One execution group per chart	Implicit compile during the configuration		
Sub chart without published pins	Undo/Redo	Openness	
Sub chart with published pins	Parameter groups for published pins by DCC	Read/write published pins	Supported i >=V15.1
		Chart configuration	
		Chart handling	New in V16
		Import of library for DCB Extension	Not support

SINAMICS DCC V16 Supported engineering functions



Support of

Switch the language from DCC Editor

Series commissioning without license

Device know how protection and write protection

Know how protection from chart

SIEMENS Ingenuity for life

Online **Download / Upload** Display the consistency by build the connection Download with one/multiple DCC chart Implicit download of DCB Standard/Extension libraries Upload with original project

Upload with empty project

Overview of libraries (DCB Standard/DCB Extension)

TIA Portal

Functions

TIA Portal UMAC


TIA Portal cloud connector

Supported in >=V15.1

New in V16

Not supported in V16

SINAMICS DCC V16 Supported engineering functions





Supported in >=V15.1

New in V16

Not supported in V16

© Siemens 2020

Page 4