



Validity

1

Installation

2

# SIMATIC HMI Hardware Support Package Basic Panel 4" Color

System Manual

## Legal information

### Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

#### **DANGER**

indicates that death or severe personal injury **will** result if proper precautions are not taken.

#### **WARNING**

indicates that death or severe personal injury **may** result if proper precautions are not taken.

#### **CAUTION**

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

#### **CAUTION**

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

#### **NOTICE**

indicates that an unintended result or situation can occur if the relevant information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

### Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

### Proper use of Siemens products

Note the following:

#### **WARNING**

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

### Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

# Table of contents

1	Validity.....	5
2	Installation.....	7



# Validity

## Validity

The Hardware Support Package for SIMATIC HMI KP/KTP400 Basic 4" color is valid for WinCC V11 SP2 with installed Update 2:

## Installation

The HSP for SIMATIC HMI KP/KTP400 Basic 4" color also installs the following HMI devices:

- KP400 Basic color PN
- KTP400 Basic color PN

To install the HSP for SIMATIC HMI KP/KTP400 Basic 4" color, please follow the instructions in the "Installation" section.



# Installation

## Requirement

The HSP for SIMATIC HMI KP/KTP400 Basic 4" color requires the following installations:

- WinCC V11 SP2
- Update 2 for WinCC V11 SP2

The "HSP\_V11SP2\_0002\_001\_BasicP\_kpkt400c.isp11" file must be available on the configuration PC.

## Installing HSP in the TIA Portal

1. Open the TIA Portal.
2. Select "Help > Installed software" in the menu. The "Installed software" dialog box opens.
3. Click "Additional information for installed software".  
Then "Detail information" dialog box opens.
4. Click "Installation of support packages".
5. Click the "Add from file system" button.
6. Select the directory of the "HSP\_V11SP2\_0002\_001\_BasicP\_kpkt400c.isp11" file in the file system.
7. Click "Open". The file is added in the TIA Portal.
8. Activate the "HSP HMI Basic Panel 4" Color" in the "Detail information" dialog.
9. Click the "Install" button. A dialog box opens.
10. Click "Next". Installation starts. The TIA Portal is closed.

After successful installation, the "Detail information" dialog shows the HSP for SIMATIC HMI KP/KTP400 Basic 4" color as installed.